Passky KDM52PLY6B01R1

Passky 52-inch Ceiling Fan with Light User Manual

Model: KDM52PLY6B01R1

Introduction

This manual provides detailed instructions for the safe installation, operation, and maintenance of your Passky 52-inch Ceiling Fan with Light. Please read this manual thoroughly before installation and retain it for future reference. This ceiling fan is designed for both indoor and outdoor use (not directly exposed to rain) and features a remote control, reversible DC motor, dimmable LED light, and multiple speed settings.

Safety Information

Always follow basic safety precautions when installing and operating this appliance to reduce the risk of fire, electric shock, and personal injury.

- Ensure the power is turned off at the circuit breaker before installation or maintenance.
- All wiring must be in accordance with national and local electrical codes.
- The mounting structure must be capable of supporting the fan's weight (14.3 pounds).
- Do not connect the fan to a dimmer switch or fan gear switch, as this will lead to abnormal operation. Use only the provided remote control.
- Keep hands, clothing, and other objects clear of the fan blades when the fan is operating.
- This fan is suitable for indoor and covered outdoor spaces. Do not expose directly to rain.

Package Contents

Verify that all components are present before beginning installation.

- Ceiling Fan Unit
- Light Kit
- Remote Control
- Mounting Hardware
- Instruction Manual (this document)
- AAA Batteries (2, for remote control)



Image: Overview of included components for the Passky 52-inch Ceiling Fan.

Setup and Installation

Installation requires basic electrical knowledge. If you are unsure, consult a qualified electrician. A step-by-step illustrated guide is provided in the physical manual. Ensure the mounting location can support the fan's weight and is within 8-10 feet of ceiling height for optimal performance.

Pre-Installation Checks

- Turn off power at the main circuit breaker.
- Ensure the electrical box is securely mounted and rated for ceiling fan support.
- Unpack all components and inspect for damage.

Mounting the Fan

1. Attach the mounting bracket to the electrical box using the provided screws.
2. Assemble the downrod and canopy to the motor housing.
3. Carefully lift the fan assembly and hang it from the mounting bracket.

Wiring Connections

Connect the fan's electrical wires to the household wiring according to the wiring diagram in the physical manual. Ensure all connections are secure and insulated with wire nuts.



Image: Important note on switch compatibility. Only conventional on/off switches are supported; dimmer or fan gear switches are not compatible.

Attaching Fan Blades and Light Kit

1. Attach the fan blades to the motor housing. Note that blades are double-sided (black and walnut) for aesthetic choice.
2. Connect and secure the light kit to the fan assembly.
3. Install the LED light panel and light cover.




Image: The Passky ceiling fan installed in various room settings, including living room, bedroom, and terrace, highlighting its suitability for different environments.

Operating Instructions

Your Passky ceiling fan is controlled by the included remote control. Ensure the remote has 2 AAA batteries installed.



Image: Remote control layout with functions: ALL OFF, Light ON/OFF, Fan OFF, Fan Speed 1-6, Change Color Temperature, Adjust Brightness, Natural Wind, Forward/Reverse, and 1/4/8 Hour Timer.

Remote Control Functions:

Button	Function
ALL OFF	Turns off both the fan and the light.
Light ON/OFF	Turns the light on or off.
Fan OFF	Turns off only the fan.
Fan Speed 1-6	Adjusts fan speed from 1 (lowest) to 6 (highest). Also turns on the fan if it's off.
Change Color Temperature	Cycles through 3 color temperatures: 3000K (warm light), 4000K (cool white), 6000K (daylight white).
Adjust Brightness (+/-)	Adjusts light brightness from 10% to 100%.
Natural Wind	Activates a fluctuating wind mode to simulate natural breezes.
F/R (Forward/Reverse)	Changes the direction of fan blade rotation. Forward (downward airflow) for cooling in summer, Reverse (upward airflow) for circulating warm air in winter.
1H/4H/8H Timer	Sets the fan to turn off automatically after 1, 4, or 8 hours.

Fan Speed and Airflow

The fan offers 6 adjustable speeds. Levels 1-2 provide a low, comfortable wind, levels 3-4 offer a medium natural wind, and levels 5-6 deliver a strong cooling wind.



Image: Explanation of the 6 wind speed settings and their corresponding airflow types.

Reversible DC Motor

The reversible DC motor allows for year-round use. In summer, set the fan to rotate counter-clockwise for a cooling downward airflow. In winter, set it to rotate clockwise for an upward airflow that helps circulate warm air trapped near the ceiling.



Image: Visual representation of the reversible DC motor function for summer cooling and winter warming.

Customizable LED Light

The integrated LED light offers dimmable brightness from 10% to 100% and three color temperature options: 3000K (warm light), 4000K (cool white), and 6000K (daylight white). Adjust these settings to suit your preference and activity.



Image: Demonstration of the customizable LED light's color temperature options and infinite dimming range.

Memory Function

The fan and light feature a memory function. When you turn off the power by remote or wall switch, the fan and light settings (color temperature, brightness, and fan speed) will be saved and restored to the previous settings when turned

back on.



Image: Explanation of the fan and light memory function, showing how settings are retained after power cycling.

Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your ceiling fan.

- **Cleaning:** To clean the fan, wipe with a soft, damp cloth. Do not use abrasive cleaners or solvents, as they may damage the finish.
- **Blade Cleaning:** Dust the fan blades regularly to prevent dust buildup, which can affect balance and airflow.
- **Tightening Screws:** Periodically check all screws on the fan and mounting hardware to ensure they are tight. Loose screws can cause wobbling or noise.
- **Lubrication:** The fan's DC motor is permanently lubricated and does not require additional oiling.

Troubleshooting

Before attempting any repairs, ensure the power is disconnected at the circuit breaker.

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; Loose wire connections; Remote control battery low or not paired.	Check circuit breaker and wall switch. Ensure all wiring connections are secure. Replace remote batteries or re-pair remote according to instructions.
Light does not work	Loose wire connection to light kit; LED panel issue; Remote control issue.	Check light kit wiring. Ensure light is turned on via remote. If problem persists, contact customer support.
Fan wobbles	Loose fan blades or mounting screws; Unbalanced blades.	Ensure all blade screws and mounting screws are tight. Check if blades are bent or damaged. Use a balancing kit if necessary (not included).
Noisy operation	Loose screws; Motor hum (normal for DC motors, but should be minimal); Obstruction.	Tighten all screws. Ensure no wires or objects are touching the fan blades or housing. The fan is designed for quiet operation (approx. 30dB).

Problem	Possible Cause	Solution
Remote control not working	Low or dead batteries; Remote not paired; Obstruction between remote and receiver.	Replace batteries. Ensure remote is pointed at the fan's receiver. Re-pair the remote if necessary (refer to physical manual for pairing steps).

Specifications

Feature	Detail
Brand	Passky
Model Name	KDM52PLY6B01R1
Product Dimensions	52"L x 52"W x 12.6"H
Item Weight	14.3 Pounds
Color	Black
Material	Engineered Wood (Blades)
Power Source	AC 120V Power, DC motor
Voltage	120 Volts
Wattage	50 watts (Fan), 24 watts (Light)
Light Source Type	LED
Brightness	2000 Lumens
Color Temperature	3000K, 4000K, 6000K (Adjustable)
Dimming	10%-100% Dimmable
Control Method	Remote Control
Fan Speeds	6 Speeds
Motor Type	Reversible DC Motor
Timer Function	1/4/8 Hours
Indoor/Outdoor Usage	Indoor & Covered Outdoor (Not directly exposed to rain)
Airflow	5000 CFM

Warranty and Support

Passky provides comprehensive support for your ceiling fan.

- **Warranty:** The product is backed by a 24-month worry-free service.
- **Technical Support:** 24-hour technical support is available. For assistance, please refer to the contact information provided in your physical manual. Email responses are available 24/7, and phone customer service hours are Monday through Friday.

- **Missing Parts:** If any components are missing from your package, please contact customer service immediately for assistance.



Image: Warranty details: 2 years for the whole fan, 10 years for the motor. Contact support for missing accessories or manual issues.

© 2025 Passky. All rights reserved.
For more information, visit Passky Store

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

What are the pairing instructions for the Passky KDM52PLY5B01R1-2 ceiling fan remote?

To pair or re-pair the remote control for your Passky ceiling fan, follow these general steps typically used for this model's DC motor receiver:Power Cycle: Turn off the main power to the fan using...

Read full answer