



[Manuals.plus](#) /

› [Zvyteay](#) /

› Zvyteay 13 Gallon Tilt-Out Trash Can Cabinet User Manual

## Zvyteay 13 Gallon Tilt Out Trash Can Cabinet

# Zvyteay 13 Gallon Tilt-Out Trash Can Cabinet User Manual

Model: 13 Gallon Tilt Out Trash Can Cabinet

## 1. INTRODUCTION

---

This manual provides instructions for the assembly, operation, and maintenance of your Zvyteay 13 Gallon Tilt-Out Trash Can Cabinet. Please read these instructions carefully before assembly and use to ensure proper function and longevity of the product.



Image 1.1: The Zvyteay 13 Gallon Tilt-Out Trash Can Cabinet in a brown finish, with the front panel tilted open to reveal an internal trash bin.

## 2. SETUP AND ASSEMBLY

The Zvyteay Tilt-Out Trash Can Cabinet requires self-assembly. All necessary hardware and detailed instructions are included in the packaging. Follow the provided step-by-step guide for proper construction.

### 2.1 Unpacking and Inspection

1. Carefully unpack all components from the box.
2. Verify that all parts and hardware listed in the instruction manual are present and undamaged. Contact customer service immediately if any parts are missing or damaged.

### 2.2 Assembly Instructions

Refer to the separate assembly manual provided with your product for detailed, illustrated steps. Ensure all connections are secure to prevent wobbling.

# Trash Can Capacity: 13 Gallon

## DIMENSION



Image 2.1: Diagram illustrating the dimensions of the cabinet: 22.1 inches (L) x 13.8 inches (W) x 31 inches (H), and internal dimensions for the trash can.

**Note:** The cabinet is designed to accommodate a standard 13-gallon trash can (not included).

### 3. OPERATING INSTRUCTIONS

The tilt-out design allows for convenient access to the internal trash bin while keeping it concealed when closed. The top surface provides additional utility.

#### 3.1 Using the Tilt-Out Mechanism

1. To open, gently pull the handle located on the top of the front panel. The panel will tilt forward and down.
2. Place or remove your 13-gallon trash can from the internal compartment.
3. To close, push the front panel upwards until it securely latches into the upright position.



Prevent family members(Kids&Pets) from opening it



Image 3.1: The cabinet with the tilt-out door closed, demonstrating its ability to keep contents hidden and inaccessible to children and pets.

### 3.2 Multi-Purpose Use

Beyond its primary function as a trash or recycling bin enclosure, the cabinet offers versatile utility:

- **Kitchen Waste Bin:** Conceals a 13-gallon trash can, reducing odors and maintaining a tidy kitchen appearance.
- **Recycling Center:** Can be used to hide a recycling bin.
- **Laundry Hamper:** The internal space can hold a laundry basket for dirty clothes.
- **Pet Food Storage:** Provides a discreet storage solution for pet food bags or containers.
- **Additional Surface Space:** The durable top surface can be used to place small appliances like coffee makers, microwaves, or decorative items.

# Other Ways To Use



**Basket for dirty clothes**



**Food storage for pets**

Image 3.2: Two examples of alternative uses for the cabinet: on the left, it holds a laundry basket; on the right, it stores pet food.

## 4. MAINTENANCE

Regular maintenance will help preserve the appearance and functionality of your cabinet.

### 4.1 Cleaning

- Wipe the wooden surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- For spills, clean immediately to prevent staining or water damage.
- Ensure the metal hinges and handle are kept dry to prevent rust.

### 4.2 Inspection

- Periodically check all screws and connections to ensure they remain tight. Tighten if necessary.
- Inspect the tilt-out mechanism for smooth operation.



Image 4.1: Close-up views highlighting the durable wood top, high-quality metal buckle for the tilt mechanism, farmhouse-style barn door design, and a bracket for preventing dumping.

## 5. TROUBLESHOOTING

- **Cabinet feels wobbly:** Ensure all assembly screws are fully tightened. If the issue persists, disassemble and reassemble carefully, ensuring all parts are correctly aligned.
- **Tilt-out door does not close smoothly:** Check for any obstructions in the mechanism or if the internal trash can is interfering with the door's movement. Ensure hinges are clean and free of debris.
- **Odor persists:** While the cabinet helps contain odors, ensure the internal trash can is regularly emptied and cleaned. Consider using odor-absorbing products inside the bin.

## 6. SPECIFICATIONS

Feature	Detail
Product Dimensions	22 x 13.8 x 31 inches
Item Weight	17.62 Kilograms (38.85 Pounds)

Feature	Detail
Brand	Zvyteay
Capacity	13 Gallons (for internal trash can)
Color	Brown
Opening Mechanism	Tilt-Out
Recommended Uses	Indoor (Kitchen, Living Room)
Finish Type	Wooden
Material	High quality wood material

## 7. WARRANTY INFORMATION

---

Specific warranty details for the Zvyteay 13 Gallon Tilt-Out Trash Can Cabinet are typically provided at the point of purchase or within the product packaging. Please refer to any documentation included with your purchase or contact the seller directly for information regarding warranty coverage and terms.

## 8. CUSTOMER SUPPORT

---

For any product-related issues, missing parts, or assembly assistance, please contact Zvyteay customer service. Contact information can usually be found on the product packaging or the seller's official website.