

Vaczon VCZ011BK

Vaczon 48 Inch Ceiling Fan with Lights and Remote Control & APP User Manual

Model: VCZ011BK

1. IMPORTANT SAFETY INFORMATION

Please read and understand this entire manual before attempting to assemble, operate, or install the product. Failure to follow these instructions could result in electric shock, fire, or serious personal injury.

- **Electrical Safety:** All electrical connections must be made by a qualified electrician. Disconnect power at the main circuit breaker before installation or servicing. Ensure all wiring complies with national and local electrical codes.
- **Mounting:** The ceiling fan must be mounted to a structurally sound ceiling joist or outlet box capable of supporting the fan's weight (minimum 35 lbs).
- **Blade Clearance:** Ensure there is at least 7 feet (2.1 meters) of clearance from the floor to the fan blades and at least 30 inches (76 cm) from the wall to the blade tips.
- **Light Source:** Do not look directly into the LED light source when the fan is operating.
- **Cleaning:** Always turn off the power to the fan before cleaning. Use a soft, damp cloth. Do not use abrasive cleaners.
- **Certifications:** This product is FCC, DOE, and ETL certified, ensuring safety and quality standards.

2. PACKAGE CONTENTS

Carefully unpack all components and ensure you have received all items listed below. If any parts are missing or damaged, contact Vaczon customer support immediately.

- Ceiling Fan Motor Housing
- Fan Blades (5 pieces, reversible Matte Black / Maple Grain)
- LED Light Kit
- Downrod (6 inches)
- Mounting Bracket

- Remote Control with Wall Mount
- Hardware Pack (screws, wire nuts, washers)
- User Manual




Image: All components included in the Vaczon 48-inch ceiling fan package, including the fan body, reversible blades (matte black and maple grain), LED light, and remote control.

3. SPECIFICATIONS

Feature	Specification
Brand	Vazon
Model Number	VCZ011BK
Color	Matte Black-Maple Grain
Size	48 inches

Product Dimensions (D x W x H)	48"D x 48"W x 13.77"H
Number of Blades	5
Motor Type	DC Motor (Reversible)
Number of Speeds	6
Air Flow Capacity	3234 CFM (Max)
Noise Level	As low as 25dB (Whisper Quiet)
Light Type	Integrated LED
Color Temperature	3000K, 4500K, 6000K (Adjustable)
Wattage	38 Watts
Voltage	120 Volts
Control Method	Remote Control, APP Control
Mounting Type	Downrod Mount (6-inch downrod included)
Installation Type	Hardwired
Indoor/Outdoor Usage	Indoor (Covered Patio)

48
inch



Side A: Matte Black



Side B: Maple Wood



Two installation angles



Flat Ceiling

Slopped Ceiling
($\leq 15^\circ$)

Room Size



12ft.x12ft.to18ft.x18ft.

Image: Detailed dimensions of the 48-inch fan, illustrating the 13.77-inch height and 6-inch downrod. It also shows compatibility with flat ceilings and sloped ceilings (up to 15 degrees), and recommended room sizes from 12ft x 12ft to 18ft x 18ft.

4. SETUP AND INSTALLATION

This section provides general guidance for installing your Vaczon ceiling fan. For detailed, step-by-step instructions, refer to the separate installation guide included in your package or the official video tutorials.

4.1 Pre-Installation Checklist

- Ensure power is disconnected at the circuit breaker.
- Verify the mounting location can support the fan's weight.
- Gather necessary tools (screwdriver, wire strippers, ladder, etc.).

4.2 Mounting the Fan

1. Secure the mounting bracket to the ceiling outlet box or joist.
2. Assemble the downrod to the motor housing. The included downrod is 6 inches.
3. Hang the fan assembly onto the mounting bracket.

4.3 Electrical Connections

- Connect the fan's electrical wires to the household wiring according to the wiring diagram in the installation guide.
- Ensure all connections are secure using wire nuts.

4.4 Attaching Blades and Light Kit

1. Attach the fan blades to the motor housing. The blades are reversible with Matte Black on one side and Maple Grain on the other.
2. Install the integrated LED light kit.

5. OPERATING INSTRUCTIONS

Your Vaczon ceiling fan can be operated using the included remote control or a compatible smartphone application.

5.1 Remote Control Functions

The remote control provides full functionality for your ceiling fan and light.

- **Power On/Off:** Turns the fan and light on or off.
- **Fan Speed:** Adjusts between 6 fan speeds.
- **Light On/Off:** Controls the LED light independently.
- **Color Temperature:** Cycles through 3000K (Warm White), 4500K (Natural White), and 6000K (Cool White) light settings.
- **Timer:** Sets the fan to turn off automatically after 2, 4, or 8 hours.
- **Reverse Function:** Changes the direction of blade rotation for summer (downward airflow) or winter (upward airflow).

Silent Soft Breeze Sleep With you




Image: The multi-function remote control for the Vaczon ceiling fan, highlighting buttons for fan speed, timing, reversible motor, 6 speeds, eye-protecting LED light, and 3 color temperature (3CCT) light.

5.2 Reversible DC Motor

The fan features a reversible DC motor for year-round comfort. Use the reverse function on the remote control to switch modes.

- **Summer Mode:** Blades rotate counter-clockwise, pushing cool air down.

- **Winter Mode:** Blades rotate clockwise, drawing cool air up and circulating warm air down.

ETL Certification Reversible DC Motor

Enjoy Year Round Comfort




Image: An illustration demonstrating the ETL certified reversible DC motor function, showing downward airflow for cooling in summer and upward airflow for warming in winter.

5.3 LED Lighting

The integrated LED light provides eye-friendly illumination with adjustable color temperatures.

- **3 Color Temperatures:** Easily switch between 3000K, 4500K, and 6000K to match your preference or room ambiance.
- **Eye Protection:** Designed with transparent lamp beads to reduce blue light and flickering, protecting your eyes.

Upgrade lens lamp beads



Image: The ceiling fan's LED light demonstrating its 3 adjustable color temperatures (3000K, 4500K, 6000K) and 1850 Lumen output, controlled by the remote.

LED Transparent Eye Protection Lamp Beads




Image: The fan's LED Transparent Eye Protection Lamp Beads feature, highlighting benefits such as eye protection, flicker-free lighting, eye-friendly LED, and reduced blue light.

5.4 Quiet Operation

The energy-efficient DC motor ensures quiet operation, making it suitable for bedrooms and living areas.

- Noise levels as low as 25dB (whisper quiet).

Multi-Function Remote Control

One-button remote control, control at will



Image: The Vaczon ceiling fan operating silently, with a graphic illustrating noise levels from 25dB (whisper) to 50dB (chatting), emphasizing its quiet performance for a peaceful environment.

5.5 Airflow Performance

The fan delivers powerful airflow for optimal air circulation.

- Maximum airflow of 3234 CFM.



Image: The Vaczon ceiling fan in operation, demonstrating its powerful airflow with a maximum air volume of 3234 CFM, indicating efficient air circulation.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your ceiling fan.

- **Cleaning:** To clean the fan, turn off the power at the circuit breaker. Use a soft, lint-free cloth to wipe down the

blades and motor housing. Do not use water directly on the fan or harsh chemical cleaners.

- **Blade Screws:** Periodically check all blade screws for tightness. Over time, they may loosen due to fan vibration.
- **Light Kit:** The LED light is integrated and designed for long life. If replacement is ever needed, contact Vaczon customer support.

7. TROUBLESHOOTING

If you experience issues with your ceiling fan, refer to the following common problems and solutions before contacting customer support.

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; Loose wire connections; Remote control battery low.	Check circuit breaker; Verify all wire connections are secure; Replace remote control battery.
Light does not work	Loose wire connection to light kit; LED driver issue.	Check light kit wiring; Contact customer support if LED driver is suspected.
Fan wobbles	Loose blade screws; Unbalanced blades; Loose mounting bracket.	Tighten all blade screws; Ensure blades are correctly installed; Verify mounting bracket is secure.
Remote control not responding	Remote battery low; Remote not paired with fan.	Replace remote battery; Refer to pairing instructions in the full manual.

8. WARRANTY AND SUPPORT

Vaczon products are designed for quality and durability. This product is backed by a standard manufacturer's warranty. For specific warranty details, please refer to the warranty card included with your purchase or contact Vaczon customer support.

8.1 Return Policy

This product is eligible for a 30-day return policy from the date of purchase, allowing for a refund or replacement.

8.2 Customer Support

For technical assistance, warranty claims, or missing parts, please contact Vaczon customer support:

- **Email:** support@vaczon.com (Example)
- **Phone:** 1-800-VACZON (Example)
- **Website:** www.vaczon.com (Example)

Note: Contact information provided is illustrative. Please refer to your product packaging or official Vaczon website for accurate support details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question