



Manuals.plus /

› Kid Trax /

› Kid Trax Royal Princess 6V Ride On Toy Instruction Manual - Model KT24003AT

Kid Trax KT24003AT

Kid Trax Royal Princess 6V Ride On Toy Instruction Manual

Model: KT24003AT

1. IMPORTANT SAFETY INFORMATION

WARNING: Adult supervision is required at all times. This product is designed for toddlers aged 18-30 months with a maximum weight capacity of 44 lbs (20 kg). Ensure the child is within the recommended age and weight limits for safe operation.

- Always ensure the child wears appropriate safety gear, such as a helmet, when operating the ride-on toy.
- Operate the toy on flat, level surfaces away from stairs, swimming pools, and other hazards.
- Do not operate near streets, motor vehicles, or steep inclines.
- Keep hands, hair, and loose clothing away from moving parts.
- Only use the provided charger and battery. Do not modify the electrical system.

2. PRODUCT OVERVIEW

The Kid Trax Royal Princess 6V Ride On Toy offers a fun and safe riding experience for young children. Featuring a charming princess theme, this electric ride-on is designed for easy operation with a simple forward button and a gentle maximum speed of 1.5 mph. Its durable construction ensures a reliable ride, while the included 6V battery and charger provide hassle-free recharging.



Image: The Kid Trax Royal Princess 6V Ride On Toy, showcasing its pink and purple design with princess graphics.

Your browser does not support the video tag.

Video: An overview of the Disney Princess Electric Ride-on, highlighting its features and a child enjoying the ride.

3. SETUP AND ASSEMBLY

Assembly is required for this product. Please follow the instructions carefully. Ensure all parts are present before beginning assembly.

1. **Unpack Components:** Carefully remove all parts from the packaging. Verify that all components listed in the manual are present.
2. **Install Rear Wheels:** Attach the rear wheels to the axle, ensuring they are securely fastened according to the diagram in your printed manual.
3. **Install Front Wheel and Fork:** Secure the front wheel to the fork assembly, then attach the fork to the main body of the ride-on toy.
4. **Attach Handlebars:** Connect the handlebars to the steering column, ensuring they are aligned and tightened.
5. **Connect Battery:** Locate the battery compartment, typically under the seat. Connect the battery terminals as instructed. Ensure a secure connection.
6. **Secure Seat:** Place the seat back onto the ride-on toy and secure it in place.

Your browser does not support the video tag.

Video: A general assembly guide for a kids' motorcycle ride-on toy, demonstrating common steps for attaching wheels, handlebars, and

connecting the battery.

4. OPERATING INSTRUCTIONS

Operating the Kid Trax Royal Princess 6V Ride On Toy is simple and intuitive for toddlers.

- **Power On:** Ensure the battery is fully charged and properly connected.
- **Forward Motion:** To move forward, press and hold the large Forward Button located on the handlebar. The toy will move at a safe speed of 1.5 mph.
- **Stopping:** Release the Forward Button to stop the toy.
- **Steering:** Use the handlebars to steer the toy left or right.



Image: Close-up of the easy-to-use Forward Button on the handlebar, designed for small hands.

5. MAINTENANCE

Proper maintenance ensures the longevity and safe operation of your ride-on toy.

- **Charging:** Use only the provided plug-in charger. Charge the battery fully before first use and after each play session. Do not overcharge (typically no more than 18 hours).
- **Cleaning:** Wipe the toy with a damp cloth to clean. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the toy in a dry, cool place away from direct sunlight and moisture. If storing for extended

periods, ensure the battery is fully charged and disconnect it.

- **Tires:** The Power Trax rubber traction strip tires provide good grip. Inspect them periodically for wear and tear.



**Includes 6V
Battery
& Charger**

Kid Trax

Image: The included 6V battery and plug-in charger, essential for powering the ride-on toy.

6. TROUBLESHOOTING

If your ride-on toy is not functioning correctly, refer to these common issues:

- **Toy does not move:** Check if the battery is fully charged and properly connected. Ensure the Forward Button is pressed firmly.
- **Slow speed:** The battery may be low on charge. Recharge the battery completely.
- **Intermittent power:** Check all electrical connections for looseness. Ensure the battery is securely in place.
- **Charging indicator not working:** Verify the charger is properly plugged into both the wall outlet and the toy.

If problems persist, contact customer support.

7. SPECIFICATIONS

Feature	Detail
Brand	Kid Trax
Model Number	KT24003AT
Age Range	18-30 Months
Maximum Weight Capacity	44 lbs (20 kg)
Maximum Speed	1.5 mph
Battery	6V Rechargeable
Material	Plastic
Item Dimensions (L x W x H)	27.17" x 17.52" x 18.11"
Item Weight	12.79 Pounds



Image: Visual representation of the ride-on toy's dimensions (18.11" W, 27.17" L, 17.52" H).



18-30 Months

**44 lbs
MAX
WEIGHT**



Kid Trax

Image: Graphic indicating the recommended age range of 18-30 months and a maximum weight of 44 lbs.

8. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation included with your product packaging. Kid Trax products typically come with a limited warranty covering manufacturing defects.

For customer support, replacement parts, or further assistance, please visit the official Kid Trax website or contact their customer service department. Keep your model number (KT24003AT) and proof of purchase handy when contacting support.