



[Manuals.plus](#) /

› [SONGMICS](#) /

› SONGMICS 160L 3-Compartment Laundry Hamper with Lid and Removable Bags, Model RLH013B01

SONGMICS RLH013B01

SONGMICS 160L 3-Compartment Laundry Hamper

Model: RLH013B01

INTRODUCTION

Thank you for choosing the SONGMICS 160L 3-Compartment Laundry Hamper. This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your new laundry hamper. Please read these instructions carefully before use and retain them for future reference.

SONGMICS
by SONGMICS HOME



Image: A woman placing laundry into the SONGMICS 3-compartment laundry hamper, demonstrating its use.

SAFETY INSTRUCTIONS

- Keep all packaging materials away from children to prevent suffocation hazards.
- Do not overload the hamper beyond its maximum static load capacity of 15 kg. Overloading may cause damage or instability.

- Ensure all components are correctly assembled before use to prevent collapse.
- Avoid placing the hamper near open flames or heat sources.
- Do not allow children to climb on or play with the hamper.
- If any parts are missing or damaged, contact customer support immediately. Do not attempt to assemble or use the product with damaged parts.

PACKAGE CONTENTS

Please check that all components are present before assembly:

- 1 x Laundry Hamper Body (600D Oxford fabric)
- 1 x Lid with handle
- 3 x Removable Inner Bags with drawstrings and handles
- 7 x Fiberglass Support Rods
- 5 x Sorting Labels (DARK, LIGHT, COLOR, TOWELS, OTHERS)
- Assembly Instructions

SETUP AND ASSEMBLY

The SONGMICS laundry hamper is designed for quick and tool-free assembly.

1. **Unfold the Hamper Body:** Carefully unfold the main hamper body.
2. **Insert Support Rods:** Insert the 7 fiberglass support rods into the designated sleeves along the corners and edges of the hamper body. Ensure they are fully seated to provide stability.
3. **Place Inner Bags:** Insert the three removable inner bags into the compartments of the hamper.
4. **Attach Sorting Labels:** Apply the desired sorting labels (DARK, LIGHT, COLOR, TOWELS, OTHERS) to the front of the hamper, corresponding to each compartment.
5. **Position the Lid:** Place the lid on top of the hamper. The lid features a handle for easy opening.




Image: Detailed view of the hamper's robust construction, highlighting metal wire frames and fiberglass support rods for stability.

When not in use, the hamper can be easily folded flat for compact storage.

OPERATING INSTRUCTIONS

- **Sorting Laundry:** Use the three compartments and corresponding labels to sort your laundry by color, fabric type, or other preferences (e.g., Darks, Lights, Colors).
- **Using the Lid:** The integrated lid helps to conceal dirty laundry, prevent odors, and protect contents from dust. Use the small handle on the lid for easy opening and closing.
- **Removing Inner Bags:** When a compartment is full, simply lift the inner bag using its handles. The drawstring closure allows you to secure the contents for transport to your washing machine.



Image: Lid handle for easy access.



Image: Drawstring closure on inner bag.



Image: Side handle for portability.

3 herausnehmbare Innensäcke

Für einen leichten Transport



Praktische Griffe



Mit Kordelzug,
maschinenwaschbar

Image: A woman carrying a removable inner laundry bag, demonstrating its portability and machine-washable feature.

MAINTENANCE

- **Cleaning the Hamper Body:** The outer hamper body, made of 600D Oxford fabric, can be wiped clean with a damp cloth and mild detergent. Do not machine wash or tumble dry the main hamper body.
- **Washing Inner Bags:** The removable inner bags are machine-washable. Wash them with similar colors on a gentle

cycle with cold water. Air dry or tumble dry on low heat.

- **Regular Inspection:** Periodically check the fiberglass rods and fabric for any signs of wear or damage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Hamper is unstable or wobbly.	Fiberglass rods not fully inserted or damaged.	Ensure all 7 fiberglass rods are fully inserted into their sleeves. If rods are damaged, contact customer support for replacements.
Strong chemical odor.	New product odor from manufacturing materials.	Allow the hamper to air out in a well-ventilated area for several days. The odor should dissipate over time.
Inner bags do not fit correctly.	Bags are not properly aligned or inserted.	Ensure each inner bag is fully expanded and correctly placed within its compartment.
Lid does not close properly.	Hamper is overfilled or lid is misaligned.	Do not overfill the hamper. Adjust the lid to ensure it sits evenly on the hamper body.

SPECIFICATIONS

Feature	Detail
Brand	SONGMICS
Model	RLH013B01
Color	Ink Black
Capacity	160 Liters
Product Dimensions (L x W x H)	64 cm x 33 cm x 75 cm
Material	600D Oxford Fabric, Polyester, Steel, Cardboard, Fiberglass Rods, PU Synthetic Leather
Item Weight	1.7 Kilograms
Special Features	Foldable, 3 Compartments, Removable Inner Bags, Machine-Washable Inner Bags, Lid, Sorting Labels
UPC	194343335018



Max. statische
Belastbarkeit

Farben	Fassungsvermögen	Abmessungen
	160 L	64 x 33 x 75 cm (L x B x H)
	210 L	84 x 33 x 75 cm (L x B x H)

Image: Product dimensions and maximum load capacity.

WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the purchase documentation or contact your retailer. You can also visit the official SONGMICS website for further assistance.

Website: [SONGMICS Official Store](#)



© 2026 SONGMICS. All rights reserved.