

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Gamrombo](#) /
- › [Gamrombo Wired Controller for Xbox 360 \(2-Pack\) User Manual](#)

Gamrombo Wired Controller for Xbox 360

Gamrombo Wired Controller for Xbox 360 (2-Pack) User Manual

Model: Wired Controller for Xbox 360

1. INTRODUCTION

Thank you for choosing the Gamrombo Wired Controller for Xbox 360. This manual provides essential information for setting up, operating, and maintaining your new controllers. These controllers are designed for use with Microsoft Xbox 360, Xbox 360 S, Xbox 360 E consoles, and PC systems running Windows 11/10/8/7. The wired connection ensures a stable, latency-free gaming experience. Each controller features dual vibration feedback and a 2.5mm audio jack for enhanced immersion and communication.



Image 1.1: The Gamrombo Wired Controller is compatible with Xbox 360 E, Xbox 360 Slim, Xbox 360, and Windows PC systems.

2. PRODUCT FEATURES

- **Wide Compatibility:** Fully compatible with Microsoft Xbox 360, Xbox 360 S, Xbox 360 E consoles, and PC systems (Windows 11/10/8/7). *Note: Not compatible with Xbox One, Xbox Series S, or Xbox Series*

X.

- **Wired Connection:** Provides a direct, latency-free connection for immediate response and stable gameplay.
- **Dual Vibration Feedback:** Integrated rumble motors deliver immersive feedback based on in-game actions, enhancing the gaming experience.
- **2.5mm Audio Jack:** Allows connection of compatible headsets for in-game audio and communication.
- **Ergonomic Design:** Shaped to fit comfortably in the palm, reducing hand fatigue during extended gaming sessions.
- **Responsive Controls:** Features sensitive buttons, precise joysticks, and an accurate D-pad for reliable input.
- **Two-Pack:** Includes two controllers, ideal for multiplayer gaming with friends and family.




Image 2.1: The controller features dual motor vibration feedback for an enhanced gaming experience.



Image 2.2: The ergonomic design of the controller ensures comfort during long gaming sessions.

3. SETUP

The Gamrombo Wired Controller is designed for simple plug-and-play functionality.

1. **Connect to Console/PC:** Locate an available USB port on your Xbox 360 console or PC.
2. **Insert USB Cable:** Firmly insert the USB connector of the controller's cable into the USB port.

3. **System Recognition:** Your console or PC should automatically detect and configure the controller. For PC, drivers may install automatically; if not, Windows Update can assist.
4. **Ready to Play:** Once recognized, the controller is ready for use. The central guide button will illuminate, indicating a successful connection.



Image 3.1: The controller offers accurate response and is plug-and-play for easy setup.

4. OPERATING INSTRUCTIONS

Once connected, the Gamrombo Wired Controller functions similarly to an official Xbox 360 controller.

- **Basic Controls:** Use the joysticks for movement and camera control, the D-pad for directional input, and the action buttons (A, B, X, Y) for in-game actions.
- **Guide Button:** Press the central guide button to access the Xbox Guide on your console or the Steam Big Picture Mode/Xbox Game Bar on PC.
- **Headset Connection:** Plug a compatible 2.5mm headset into the audio jack located at the bottom of the controller for voice chat or game audio.
- **Vibration Feedback:** The dual vibration motors will activate automatically in supported games, providing tactile feedback for impacts, explosions, and other in-game events.



Image 4.1: The controller features an intuitive button layout for excellent performance.

5. MAINTENANCE

Proper care will extend the life of your Gamrombo Wired Controller.

- **Cleaning:** Use a soft, dry cloth to wipe down the controller. For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution. Avoid harsh chemicals or abrasive materials.
- **Cable Care:** Do not sharply bend, twist, or pull the cable. Store the cable neatly when not in use to prevent damage.
- **Storage:** Store the controller in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Drops:** Protect the controller from drops and impacts, which can damage internal components.

6. TROUBLESHOOTING

If you encounter issues with your Gamrombo Wired Controller, refer to the following common solutions:

- **Controller Not Recognized:**
 - Ensure the USB cable is fully inserted into the port.
 - Try connecting the controller to a different USB port on your console or PC.
 - Restart your console or PC.
 - For PC, check Device Manager to see if the controller is listed and if there are any driver issues. Update drivers if necessary.
- **Vibration Not Working:**
 - Verify that the game you are playing supports vibration feedback.
 - Check in-game settings to ensure vibration is enabled.
 - Test the controller on another game or system to isolate the issue.
- **Audio Jack Issues:**
 - Ensure your 2.5mm headset is fully plugged into the controller's audio jack.
 - Confirm that your headset is functioning correctly by testing it with another device.
 - Check audio settings on your console or PC to ensure the controller's audio output is selected.
- **Joystick Sensitivity:** Please note that while the joysticks are responsive, this controller is *not suitable for games that require extremely precise joystick operation*, as mentioned in the product features.

7. SPECIFICATIONS

Feature	Detail
Model	Wired Controller for Xbox 360
Compatibility	Xbox 360, Xbox 360 S, Xbox 360 E, PC (Windows 11/10/8/7)
Connection Type	Wired USB
Cable Length	Approximately 5.8 feet (1.77 meters)
Audio Jack	2.5mm
Vibration	Dual Motor Vibration Feedback
Package Dimensions	6.85 x 5.59 x 4.92 inches

Item Weight	1.3 Pounds (0.59 kg)
Manufacturer	Gamrombo

8. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your purchase or contact Gamrombo customer service directly. You can typically find contact details on the manufacturer's official website or through the retailer where the product was purchased.

Please retain your proof of purchase for any warranty claims.