

[Manuals.plus](#) /

> [JALL](#) /

> JALL 10" Large Digital Wall Clock User Manual

JALL PH10

JALL 10" Large Digital Wall Clock User Manual

Model: PH10 | Brand: JALL

INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, and maintenance of your JALL 10" Large Digital Wall Clock. Designed for clarity and versatility, this clock features a large LED display with RGB color options, an alarm, countdown timer, temperature display, and automatic Daylight Saving Time (DST) adjustment. Please read this manual thoroughly to ensure proper use and longevity of your device.

The JALL Digital Wall Clock is designed for clear visibility and ease of use, integrating multiple functions into a single, sleek unit.

Key Features:

- **10-inch Large LED Display:** Provides excellent readability from various distances and angles.
- **RGB Color Options:** Customize display and night light colors with up to 8 vibrant options.
- **Automatic Brightness Adjustment:** Sensors adjust display brightness based on ambient light.
- **Daylight Saving Time (DST) Adjustment:** Automatically updates for DST changes.
- **Alarm Function:** Set multiple alarms for daily reminders.
- **Countdown/Count-up Timer:** Useful for various activities like workouts or cooking.
- **Temperature Display:** Shows ambient room temperature.
- **Night Light:** Integrated subtle illumination for nighttime navigation.
- **Remote Control:** Conveniently manage all settings from a distance.



Figure 2: The clock's display integrates time, date, day of the week, seconds, and temperature for a comprehensive view.

SETUP

1. Power Connection

The JALL Digital Wall Clock is primarily powered by the included 5V/2A power adapter and 11.5-foot cord. It is not battery-operated for primary function.

1. Connect the power cord to the DC-5V port on the back of the clock.
2. Plug the power adapter into a standard electrical outlet.
3. The clock display will illuminate.

Battery Backup: For retaining settings during power outages, insert two AAA batteries (not included) into the battery compartment on the back of the clock. These batteries do not power the display.

Not Battery Operated




Figure 3: Power connection and battery backup for the clock. Note that AAA batteries are for memory retention only.

2. Mounting Options

The clock can be wall-mounted or placed on a flat surface using its integrated stand.

- **Wall Mounting:** Use the provided screws and anchors to securely mount the clock on a wall. Ensure the power cord can reach an outlet.
- **Tabletop Placement:** Utilize the built-in stand on the back of the clock for stable placement on a desk, shelf, or nightstand.

Easy to set



Figure 4: The clock can be easily set up on a wall or tabletop.

OPERATING INSTRUCTIONS

All functions of the clock are controlled via the included remote control. Familiarize yourself with the remote's buttons for optimal use.

Remote Control

Easy to set

Able to change seconds/ TEMP display




Figure 5: The remote control allows for easy adjustment of clock settings.

1. Setting Time and Date

1. Press the **TIME SET** button on the remote. The time digits will flash.
2. Use the **+** and **-** buttons to adjust the hour.
3. Press **OK** to confirm the hour and move to minutes.
4. Adjust minutes using **+** and **-**, then press **OK**.
5. Continue this process for setting the year, month, and date.
6. Press **OK** to exit time/date setting mode.
7. To switch between 12H and 24H format, press the **12H/24H** button.

2. Display Colors (RGB)

The clock offers multiple display colors for the time and date, and a separate night light color.

- Press the **Display Colors** button to cycle through available display colors.

- Press the **freeze** button to stop the color cycling and keep the current color.



Figure 6: Explore various colorful display modes for the clock digits.

3. Night Light Functionality

The clock features a customizable night light around its perimeter.

- Press the **Light** button to cycle through different night light colors.
- Press the **sync** button to synchronize the night light color with the main display color.
- Use the **DIMMER** buttons to adjust the brightness of the night light.

Warm Night Light



Multiple vivid night lighting effects



one click synchronization with display mode



10 brightness level adjustable



Figure 7: The clock's night light offers multiple colors and brightness levels.

4. Automatic Brightness (Auto Dimmer)

The clock can automatically adjust its brightness based on ambient light conditions.

- Press the **AUTO DIMMER** button to activate or deactivate this feature.
- When active, the clock will dim in darker environments to protect your eyes and save energy.

Auto Dimming

Auto adjust brightness according to the environment light to protect your eyes



Figure 8: The auto-dimming feature adjusts display brightness automatically.

5. Daylight Saving Time (DST)

The clock supports automatic adjustment for Daylight Saving Time.

- Press the **AUTO DST** button to enable or disable this feature.
- When enabled, the clock will automatically adjust its time during spring forward and fall back.

Auto DST (Daylight Saving Time)

No more annoying to change time in spring and autumn



Figure 9: Automatic DST adjustment simplifies time changes.

6. Alarm Function

Set alarms for daily reminders.

1. Press the **ALARM SET** button. The alarm time will flash.
2. Use **+** and **-** to set the desired alarm hour and minutes.
3. Press **OK** to confirm.
4. Press **ALARM ON/OFF** to activate or deactivate the alarm. An alarm icon will appear on the display when active.

7. Countdown and Count-up Timer

The clock includes versatile timer functions.

- **Countdown:** Press the **COUNT DOWN** button. Use **+** and **-** to set the desired time (up to 99 minutes). Press **OK** to start. The clock will beep when the countdown finishes.
- **Count-up:** Press the **COUNT UP** button. The timer will start from 00:00 and count upwards (up to 99 minutes).

Press **OK** to pause/resume.



Figure 10: The countdown and count-up timers are useful for various activities.

8. Temperature Display

The clock displays the ambient temperature.

- Press the **°C/°F SEC** button to switch between Celsius (°C) and Fahrenheit (°F) temperature units.
- This button also toggles the display of seconds on the main time display.

9. Official Product Video

Watch this official product video for a visual guide on the JALL 10" Large Digital Wall Clock's features and operation.

Your browser does not support the video tag.

Video 1: Overview of the JALL 10" Large Digital Wall Clock, demonstrating its various functions and display options.

Maintenance

To ensure the longevity and optimal performance of your JALL Digital Wall Clock, follow these maintenance guidelines:

- **Cleaning:** Gently wipe the display and casing with a soft, dry, lint-free cloth. Avoid using abrasive cleaners, solvents, or spray cleaners directly on the clock, as they may damage the surface.
- **Placement:** Place the clock in a location away from direct sunlight, extreme temperatures, and high humidity to prevent damage to electronic components and maintain display clarity.
- **Power:** Always use the provided power adapter. Do not attempt to power the clock with other adapters unless specified by the manufacturer.

Troubleshooting

Problem	Possible Cause	Solution
Clock display is off.	No power supply; power adapter disconnected.	Ensure the power adapter is securely plugged into the clock and a working electrical outlet.
Remote control is not working.	Batteries in remote are dead or incorrectly inserted; remote not pointed at clock.	Replace remote control batteries. Ensure correct polarity. Point remote directly at the clock's sensor.
Time/Date is incorrect after power outage.	Backup batteries (AAA) are not installed or are dead.	Install fresh AAA batteries for memory retention. Reset time and date manually if necessary.
Temperature reading seems inaccurate.	Clock is placed near a heat source or vent; internal sensor needs time to stabilize.	Relocate the clock away from direct heat/cold sources. Allow several hours for the sensor to acclimate to the room's ambient temperature.
Display colors are not changing.	Color freeze function is active.	Press the freeze button on the remote to deactivate the color freeze function.

Specifications

Feature	Detail
Brand	JALL
Model Number	PH10
Display Type	Digital LED
Display Size	10 inches (Diameter)
Product Dimensions	10"W x 10"H
Power Source	Corded Electric (5V/2A adapter included)
Battery Backup	2 x AAA batteries (not included) for memory retention
Mounting Type	Wall Mount, Tabletop

Feature	Detail
Special Features	Alarm, Auto Dimmable, Daylight Saving, Countdown/Count-up Timer, RGB Color, Temperature Display
Material	Plastic
Item Weight	1.83 pounds

WARRANTY AND SUPPORT

JALL products are manufactured with high-quality standards. For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official JALL website. Keep your purchase receipt as proof of purchase for any warranty claims.

© 2025 JALL. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DWMGY7SM>

More documents and user manuals: <https://manuals.plus/>