

[manuals.plus](#) /

› [Bodum](#) /

› [BODUM OTTONI Electric Milk Frother 12309-01JP-80 User Manual](#)

**Bodum 12309-01JP-80**

## **BODUM OTTONI Electric Milk Frother 12309-01JP-80 User Manual**

Model: 12309-01JP-80

### **1. INTRODUCTION**

Thank you for choosing the BODUM OTTONI Electric Milk Frother. This device is designed to effortlessly create barista-quality milk foam for a variety of beverages, including cappuccinos, lattes, and hot chocolates. Its user-friendly design and multiple functions make it a versatile addition to any kitchen. Please read this manual carefully before first use to ensure safe and optimal operation.



Image: The BODUM OTTONI Electric Milk Frother ready to prepare beverages.

## 2. IMPORTANT SAFETY INSTRUCTIONS

To prevent personal injury or damage to the appliance, always follow basic safety precautions:

- Read all instructions thoroughly before operating the appliance.
- Do not immerse the electrical base unit, cord, or plug in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from the outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
- Do not use outdoors.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.

- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach the plug to the appliance first, then plug the cord into the wall outlet. To disconnect, turn any control to "off," then remove the plug from the wall outlet.
- Do not use the appliance for other than intended use.
- Avoid contact with moving parts.

### 3. PARTS OVERVIEW

The BODUM OTTONI Electric Milk Frother consists of the following main components:

- **Milk Container:** Stainless steel interior with non-stick coating.
- **Lid:** Transparent lid with a removable frothing whisk.
- **Frothing Whisk:** Disk-shaped whisk for creating foam.
- **Base Unit:** Contains the heating element and control button.



“おいしい”温度で濃密なクリーミー泡  
3つのバリエーションが楽しめる電動ミルク泡立て器

Image: Front view of the BODUM OTTONI Electric Milk Frother, highlighting its design.

## 4. SETUP

Before first use, ensure all packaging materials are removed. Wash the milk container, lid, and frothing whisk with warm, soapy water, then rinse thoroughly and dry. Place the frothing whisk securely at the bottom of the milk container. Position the base unit on a stable, flat surface near a power outlet.

## 5. OPERATING INSTRUCTIONS

The BODUM OTTONI Electric Milk Frother features a simple one-button operation with three distinct modes:

1. **Hot Foam Mode:** Ideal for cappuccinos and lattes. This mode heats and froths milk to a rich, creamy texture. It can also warm milk without frothing.
2. **Hot Chocolate Mode:** Specifically designed for preparing delicious hot chocolate.
3. **Cold Foam Mode:** Perfect for iced coffees, cold lattes, or other chilled beverages. This mode froths milk without heating.

### Steps for Use:

- Ensure the frothing whisk is correctly placed in the milk container.
- Pour milk into the container. Observe the MAX fill lines for frothing (225ml) and heating (400ml) to prevent overflow.
- Place the lid securely on the milk container.
- Place the milk container onto the base unit.
- Press the power button once to cycle through the available modes. The indicator light will change to reflect the selected mode.
- The frother will automatically stop when the selected program is complete.

ボタンひとつの簡単操作

3つのモードを搭載

ホットフォームモード、コールドフォームモード

ホットチョコレートモード



Image: A cup of hot chocolate, demonstrating the frother's capabilities.

大容量で  
おもてなしにも便利

最大225ml（ホットミルクフォーム）  
～400ml（ホットミルク）



Image: The milk frother demonstrating its capacity for hot milk foam (225ml) and hot milk (400ml).

## 6. MAINTENANCE AND CLEANING

Regular cleaning ensures the longevity and performance of your milk frother.

- Always unplug the appliance before cleaning.
- The stainless steel milk container features a non-stick coating to prevent milk from sticking, making cleaning easy.
- The milk container, lid, and disk-shaped frothing whisk are dishwasher-safe for convenient cleaning.
- Wipe the exterior of the base unit with a damp cloth. Do not immerse the base unit in water.
- Ensure all parts are completely dry before reassembling and storing.

シンプルな構造で  
お手入れも簡単

取り外し可能なミルク容器、リッド、  
泡立てホイッパーは、食器洗い乾燥機使用可能



Image: The detachable milk container, lid, and whisk, illustrating ease of cleaning.

光沢が美しい耐久性に優れた

## ステンレス製の本体

—

本体の内側はミルクなどのこびりつきを防ぐ

ノンスティック加工



Image: Close-up of the non-stick interior, designed for easy cleaning and durability.

## 7. TROUBLESHOOTING

If you encounter issues with your milk frother, refer to the following common problems and solutions:

- Device not turning on:** Check that the power cord is securely plugged into a working outlet and that the milk container is correctly placed on the base unit.
- Milk not frothing or insufficient foam:** Ensure the milk level is between the MIN and MAX frothing lines. Use cold milk for cold foam. Verify that the frothing whisk is properly inserted at the bottom of the container.
- Milk overflowing:** Do not exceed the maximum fill line indicated inside the milk container.
- Burnt smell:** This may indicate milk residue. Thoroughly clean the interior of the milk container as per the maintenance instructions.

If the problem persists, please contact customer support.

## 8. SPECIFICATIONS

Feature	Detail
Brand	Bodum
Model Name	OTTONI
Model Number	12309-01JP-80
Material	Stainless Steel
Color	Black
Package Dimensions	26.2 x 14.7 x 14.5 cm
Item Weight	0.98 Kilograms
Care Instructions	Dishwasher Safe (Container, Lid, Whisk)
Special Features	3 Modes (Hot Foam, Hot Chocolate, Cold Foam), Automatic Temperature Control, Non-stick Interior, Boil-dry Protection

## 9. WARRANTY AND SUPPORT

The BODUM OTTONI Electric Milk Frother comes with a 1-year warranty. In case of any malfunction under normal use within the warranty period, free repair services will be provided. For detailed information on warranty terms and conditions, please refer to the warranty section in your product packaging or contact Bodum customer support.



対象家電

# 1年保証

購入後も安心のアフターフォロー

取扱説明書、本体貼付ラベル等の注意書きに従った  
使用状態で、保証期間内に故障した場合  
無料修理させていただきます

※ 詳しくは取扱説明書に記載されている  
アフターサービスのページをご確認ください

Image: General warranty information for Bodum appliances.

© 2026 Bodum. All rights reserved.