

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [UIXE](#) /
- › [UIXE Accent Chair \(2-Seat, Orange\) Instruction Manual](#)

UIXE f332d019-8d1e-4322-8daf-9c407ae3d32d

UIXE Accent Chair (2-Seat, Orange) Instruction Manual

Model: f332d019-8d1e-4322-8daf-9c407ae3d32d

1. INTRODUCTION

Thank you for choosing the UIXE Accent Chair. This manual provides essential information for the safe assembly, operation, and maintenance of your new chair. Please read these instructions carefully before beginning assembly and retain them for future reference.



Image: Front view of the UIXE Accent Chair in Orange.

2. SAFETY INFORMATION

WARNING: Assembly may require tools and caution. Ensure cushions are securely attached to prevent detachment and potential suffocation hazard.

- Always assemble the chair on a soft, clean surface to prevent damage.
- Ensure all bolts and screws are tightened securely before use. Periodically check and re-tighten as necessary.
- Do not stand on the chair.
- Keep small parts away from children during assembly.
- Maximum weight capacity: 440 lbs.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly. The chair set is delivered in 2 boxes, which may arrive at different times.

1. Chair Back x 1
2. Chair Seat x 1
3. Chair Legs x 4
4. Left Back Wing x 1
5. Right Back Wing x 1
6. Seat Cushion x 1
7. Screws Bag x 1 (Contains various screws and washers)
8. Assembly Tool x 1 (Hex key)

4. DIMENSIONS

The following are the approximate dimensions of the UIXE Accent Chair:

- Overall Product Dimension: 27.5" W x 27.5" D x 34.5" H
- Seat Depth: 21.5"
- Seat Width: 20"
- Seat Height: 19"
- Armrest Width: 3.45"
- Cushion Thickness: 4.5"



Image: Detailed dimensional drawing of the accent chair.

Note: Manual measurements may have an error of 1-2 cm. Product colors may vary slightly due to screen differences.

5. SETUP AND ASSEMBLY INSTRUCTIONS

Assembly of the UIXE Accent Chair is straightforward. Follow these steps carefully:

1. **Unpack Components:** Carefully remove all parts from the packaging. Place them on a soft, clean surface to avoid scratches.
2. **Attach Chair Legs:** Locate the four chair legs. Align each leg with the pre-drilled holes on the underside of the chair seat. Secure them using the provided screws and assembly tool. Ensure they are tightened firmly.
3. **Attach Back Wings:** Slide the Left Back Wing and Right Back Wing onto the sides of the Chair Back. Ensure they are properly aligned with the slots.
4. **Connect Chair Back to Seat:** Align the assembled chair back with the back of the chair seat. Secure it using the remaining screws and the assembly tool.

5. **Place Seat Cushion:** Position the Seat Cushion onto the chair seat. Ensure it is seated properly and securely.
6. **Final Check:** Verify that all connections are tight and the chair is stable before use.



Image: Two assembled accent chairs in a room.

6. OPERATING INSTRUCTIONS

The UIXE Accent Chair is designed for comfortable seating in various indoor environments. Its ergonomic design with a wide backrest and seat, made of highly elastic sponges and springs, provides maximum comfort.

- **Placement:** Suitable for living rooms, bedrooms, playrooms, dorms, or office spaces.
- **Usage:** Ideal for reading, relaxing, watching movies, playing games, or engaging in conversations.
- **Comfort:** The fabric finish and solid wood legs offer a blend of style and stability.



Image: A single accent chair positioned in a room.

7. MAINTENANCE AND CARE

To ensure the longevity and appearance of your UIXE Accent Chair, follow these care guidelines:

- **Cleaning:** The linen cotton fabric is smooth and splash-proof. For spills, blot immediately with a clean, dry cloth. For general cleaning, vacuum regularly using an upholstery attachment to remove dust and debris.
- **Stain Removal:** For tougher stains, use a mild fabric cleaner following the product instructions. Test on

an inconspicuous area first.

- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fabric fading. Position the chair away from direct sun or use curtains/blinds.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners or harsh chemicals, as these can damage the fabric and finish.
- **Leg Care:** Periodically check the tightness of the chair legs and re-tighten if necessary.



Image: Side profile of the accent chair, showcasing its design.

8. TROUBLESHOOTING

If you encounter any issues with your UIXE Accent Chair, refer to the following common solutions:

- **Wobbling Chair:** Check all leg connections and ensure they are securely tightened. If the floor is uneven, consider using furniture pads or shims under the legs.
- **Loose Cushion:** Ensure the seat cushion is properly aligned and seated within the chair frame.

- **Squeaking Noises:** Re-tighten all screws and bolts. If the noise persists, apply a small amount of lubricant to the joints.
- **Fabric Stains:** Refer to the "Maintenance and Care" section for cleaning instructions.



Image: Back view of the accent chair, highlighting its tufted back design.

9. SPECIFICATIONS

Feature	Detail
---------	--------

Brand	UIXE
Model Number	f332d019-8d1e-4322-8daf-9c407ae3d32d
Color	Orange
Size	2SEAT (Set of 2)
Product Dimensions	27.5"D x 27.5"W x 34.5"H
Back Style	Tufted Back
Special Feature	Arm Rest, Cushion Availability, Ergonomic
Unit Count	2.0 Count
Pattern	Solid
Age Range (Description)	Adult
Included Components	Chair Seat, Seat Cushion, Assembly Tool, Product Manual, 2 Arm Pads
Indoor/Outdoor Usage	Indoor
Seat Depth	22 inches
Fill Material	Sponge
Leg Style	Tapered Leg
Reclining Position Count	1
Chair Backrest Width	27.5 Inches
Form Factor	Upholstered
Material	Wood (Frame)

10. WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the documentation included with your purchase or contact UIXE customer service directly. Keep your proof of purchase for any warranty claims.

For further assistance, please visit the [UIXE Store on Amazon](#).