

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [Bushnell](#) /

› Bushnell Golf Tour Hybrid Laser Rangefinder User Manual

Bushnell Tour Hybrid

Bushnell Golf Tour Hybrid Laser Rangefinder User Manual

Model: Tour Hybrid (Part Number: 202500)

INTRODUCTION

The Bushnell Golf Tour Hybrid Laser Rangefinder is an advanced device designed to provide golfers with precise distance measurements using both laser and GPS technologies. This hybrid approach ensures accuracy and comprehensive course information, helping you make informed decisions on every shot. It combines the pinpoint accuracy of a laser rangefinder with the convenience of GPS-provided front, center, and back distances to the green.



Image: Side view of the Bushnell Golf Tour Hybrid Laser Rangefinder, showcasing its compact design and blue accents.

KEY FEATURES

- **Tour Series Laser with Onboard GPS & Slope:** Provides precise laser distances and GPS-derived yardages.
- **GPS-Provided Front/Center/Back Distances:** Displays key distances directly in the viewfinder for comprehensive course awareness.
- **Slope Compensation:** GPS distances are automatically adjusted for elevation changes when the Slope feature is enabled.
- **Slope-Switch Technology:** Allows for quick and easy toggling between compensated (slope) and non-compensated (tournament legal) distances.
- **Pinseeker with Visual JOLT Technology:** Provides a vibrating pulse and a red ring flash when the laser locks onto the flag, confirming target acquisition.
- **Integrated BITE Magnetic Cart Mount:** A powerful magnet built into the device allows for secure attachment to a golf cart or metal surface.
- **Extended Ranging Capability:** Capable of ranging flags from over 500 yards away.



Image: The Bushnell Golf Tour Hybrid Laser Rangefinder showcasing its integrated BITE magnetic cart mount on the side.

SETUP

1. Battery Installation

The Tour Hybrid requires one Disposable Lithium CR-123 Battery (3V). To install or replace the battery:

1. Locate the battery compartment cover, typically on the underside or side of the device.
2. Twist or slide the cover to open it.
3. Insert the CR-123 battery, ensuring the positive (+) and negative (-) terminals are aligned correctly as indicated inside the compartment.
4. Close the battery compartment cover securely.

2. Initial Power On and App Connection

Upon first use, or after battery replacement, the device will power on. For optimal functionality, including loading course data for GPS front/center/back readouts, it is recommended to connect your Tour Hybrid to the Bushnell Golf app on your smartphone. The app provides additional features such as hole layouts and score tracking.

- Download the Bushnell Golf app from your device's app store.
- Follow the in-app instructions to pair your Tour Hybrid via Bluetooth.
- Ensure course data is downloaded for the courses you intend to play.

OPERATING INSTRUCTIONS

1. Powering On and Ranging

To power on the device and obtain a laser distance measurement, press the power/fire button (usually located on the top of the unit). Aim the reticle at your desired target and press the button again. The distance will be displayed in the viewfinder.

2. Understanding the Viewfinder Display

The Tour Hybrid's viewfinder provides a wealth of information at a glance. It displays both laser-measured distances and GPS-provided front, center, and back distances to the green. When Slope is enabled, all distances, including GPS, will be compensated for elevation changes.





Image: A close-up view of the Bushnell Tour Hybrid's reticle display, showing digital readouts for front, center, and back distances, along with the primary laser-measured distance and slope compensation.

TOUR HYBRID RETICLE



SLOPE COMPENSATED LASER AND FRONT, BACK, CENTER GPS DISTANCES

Image: A detailed diagram illustrating the various indicators and readouts within the Bushnell Tour Hybrid's reticle, including GPS distances, laser distance, slope, Pinseeker, Bluetooth, and battery level.

3. Slope-Switch Technology

The Slope-Switch feature is located on the side of the device. Slide the switch to enable or disable slope compensation. When enabled, the device will provide "play as" distances adjusted for uphill or downhill shots. When disabled, it provides line-of-sight distances, making it legal for tournament play.

4. Pinseeker with Visual JOLT

To use Pinseeker, aim the crosshairs at the flagstick. Press and hold the power/fire button. The device will automatically identify the flagstick from background objects. Once locked onto the flag, the device will vibrate (JOLT) and a red ring will flash in the display, confirming the distance to the flag.

5. BITE Magnetic Mount

The integrated BITE magnetic mount allows you to conveniently attach the rangefinder to any metal surface, such as a golf cart frame or club head, for easy access during your round.

MAINTENANCE

1. Cleaning the Optics

Gently wipe the lenses and body with a soft, clean microfiber cloth. For stubborn smudges, a small amount of lens cleaning fluid designed for optics can be applied to the cloth, not directly to the lens. Avoid abrasive materials or harsh chemicals.

2. Battery Care

Replace the CR-123 battery when the low battery indicator appears in the display. If the device will not be used for an extended period, it is advisable to remove the battery to prevent leakage and potential damage.

3. Storage

Store the rangefinder in its premium carry case when not in use to protect it from dust, dirt, and physical damage. Store in a cool, dry place away from direct sunlight and extreme temperatures.

4. Water Resistance

The Tour Hybrid is weather-resistant with an IPX6 rating, meaning it can withstand powerful water jets. While it is designed to endure rain and splashes, it should not be submerged in water.

TROUBLESHOOTING

- **No Display/Device Not Powering On:** Check the battery. Ensure it is correctly inserted and has sufficient charge. Replace if necessary.
- **Inaccurate Distance Readings:**
 - Ensure the target is within the measuring range (5 to 1,300 yards).
 - Verify that the lens is clean and free from obstructions.
 - Confirm that you are locking onto the intended target, especially when using Pinseeker.
 - For GPS distances, ensure your device is properly synced with the Bushnell Golf app and that course data is up to date.
- **No JOLT/Visual JOLT Not Activating:** Ensure you are holding the button down long enough for the Pinseeker to lock onto the flag.
- **Bluetooth Connectivity Issues:**
 - Ensure Bluetooth is enabled on your smartphone and the rangefinder.
 - Try unpairing and re-pairing the device in the Bushnell Golf app settings.
 - Restart both the rangefinder and your smartphone.

SPECIFICATIONS

Brand	Bushnell
Model Name	Tour Hybrid
Part Number	202500
Color	Gray

Material	Plastic
Item Weight	1.2 Pounds
Measuring Range	5 to 1,300 yards
Battery Type	Disposable Lithium CR-123 Battery (3V)
Item Package Dimensions	6.02 x 4.72 x 4.61 inches
UPC	029757025500
Manufacturer	Bushnell Golf
Model Year	2025

WARRANTY AND SUPPORT

Warranty Information

The Bushnell Golf Tour Hybrid Laser Rangefinder comes with a 2-Year Manufacturer's Warranty. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

Customer Support

For further assistance, technical support, or warranty service, please visit the official Bushnell website or contact their customer service department. Refer to the contact information provided in your product packaging or on the Bushnell Golf website.