



[Manuals.plus](#) /

> [INNOD](#) /

> INNOD 43-inch Tall Shoe Storage Cabinet with Doors - Assembly and User Manual

INNOD shoe cabinet

INNOD 43-inch Tall Shoe Storage Cabinet with Doors - Assembly and User Manual

Model: shoe cabinet | Brand: INNOD

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your INNOD 43-inch Tall Shoe Storage Cabinet. This cabinet is designed to organize footwear efficiently in entryways, hallways, or living rooms, featuring adjustable shelves and a modern design.

2. SAFETY INFORMATION

- Always assemble the cabinet according to the provided instructions.
- Ensure the cabinet is properly mounted to the floor to prevent tipping.
- Do not overload the shelves; the cabinet can hold up to 25 pounds.
- Always lift with your legs when handling heavy items to prevent injury.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all components are present and undamaged. The package should include:

- Cabinet panels (top, bottom, sides, back)
- Adjustable shelves (6 total)
- Doors (2 total)
- All necessary hardware (screws, dowels, hinges, handles, anti-tip kit)
- Assembly instructions guide

4. ASSEMBLY INSTRUCTIONS

Assembly is required for this product. Follow the included detailed instruction guide for step-by-step assembly. An electric screwdriver is recommended to save time during assembly.

Image 1: Cabinet dimensions showing 43 inches height, 32 inches width, and 15 inches depth, with internal shelf spacing.



Image 2: The assembled shoe storage cabinet positioned in an entryway, highlighting its freestanding design, adjustable shelves, ventilation doors, and stable support legs.



Image 3: The shoe cabinet integrated into a modern entryway with plants and stairs, demonstrating its aesthetic appeal and functional placement.

Your browser does not support the video tag.

Video 1: This video demonstrates the assembly process or key features of the shoe cabinet, providing visual guidance for setup. (Duration: 1:17)

5. OPERATING INSTRUCTIONS

5.1 Adjusting Shelves

The cabinet features adjustable shelves to accommodate various shoe types and sizes, including boots, high heels, sneakers, and slippers. To adjust a shelf:

1. Empty the shelf of all contents.
2. Carefully lift the shelf to remove it from its support pins.
3. Relocate the support pins to the desired pre-drilled holes on the side panels.
4. Place the shelf back onto the support pins, ensuring it is level and secure.

Flexible Shoe Storage




Image 4: Illustration of the flexible shoe storage, showing how adjustable shelves can accommodate different types of footwear like slippers, sneakers, high-heels, children's shoes, and boots.

5.2 Using the Doors

The cabinet is equipped with doors that provide a neat and enclosed storage solution. The doors are designed for smooth operation. Ensure they are properly aligned during assembly for optimal performance.

Versatile Design



Image 5: A comparison image highlighting the versatile design of the INNOD shoe cabinet with its doors open, showcasing ample storage, next to a smaller, less versatile cabinet.

Your browser does not support the video tag.

Video 2: This video likely demonstrates the functionality of the cabinet doors, shelf adjustment, or overall usage. (Duration: 1:35)

6. MAINTENANCE

- **Cleaning:** Wipe the cabinet surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the engineered wood finish.
- **Dusting:** Regularly dust the cabinet to maintain its appearance.
- **Spills:** Clean up spills immediately to prevent staining or damage to the wood.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they remain tight. Tighten if necessary.

7. TROUBLESHOOTING

7.1 Doors Not Aligning Properly

If the cabinet doors do not close seamlessly or appear misaligned after assembly:

- **Check Hinges:** Ensure all hinges are securely fastened to both the door and the cabinet frame.
- **Adjust Hinges:** Most cabinet hinges have adjustment screws that allow for minor vertical, horizontal, and depth adjustments. Refer to your assembly guide for specific instructions on adjusting the hinges. Make small adjustments and test the door closure until alignment is satisfactory.
- **Level Surface:** Ensure the cabinet is placed on a level surface. An uneven floor can cause the cabinet frame to twist slightly, affecting door alignment. Use shims if necessary to level the cabinet.

8. SPECIFICATIONS

Brand	INNOD
Model Name	shoe cabinet
Product Dimensions	14"D x 31.5"W x 42"H
Material	Engineered Wood
Color	Wood (Oak finish)
Number of Shelves	6 (Adjustable)
Mounting Type	Floor Mount (Freestanding with anti-tip kit recommended)
Item Weight	25 Pounds
Assembly Required	Yes
Recommended Uses	Shoes, Entryway, Hallway, Front Door

9. WARRANTY AND SUPPORT

For any questions regarding assembly, missing parts, or product issues, please contact INNOD customer support. This product typically includes a 30-day return policy. Refer to your purchase documentation for specific warranty details.

For further assistance, please visit the [INNOD Store on Amazon](#).