

Aspiron E4ASPVAC1200

Aspiron Canister Vacuum Cleaner E4ASPVAC1200 User Manual

Model: E4ASPVAC1200

1. IMPORTANT SAFETY INSTRUCTIONS

When using an electrical appliance, basic precautions should always be followed, including the following:

- Read all instructions before using this vacuum cleaner.
- Always unplug the appliance from the electrical outlet immediately after using and before cleaning.
- Do not use outdoors or on wet surfaces.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or appliance with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce airflow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not use without dust cup and/or filters in place.
- Turn off all controls before unplugging.
- Use extra care when cleaning on stairs.

2. PRODUCT OVERVIEW

The Aspiron Canister Vacuum Cleaner E4ASPVAC1200 is designed for efficient cleaning of various surfaces. It features a powerful motor, a multi-stage filtration system, and convenient accessories for comprehensive home and car cleaning.

Key Features:

- **Powerful Suction:** 1200W motor generating over 455AW/24Kpa suction for deep cleaning.
- **3-Stage Filtration System:** Includes a central cyclonic system, HEPA-H10 inlet filter, and an outlet sponge to trap fine dust and prevent secondary pollution.
- **Large Dust Cup:** 3.7QT (3.5 Liters) bagless and washable dust cup for extended cleaning without frequent emptying.
- **Automatic Cord Rewind:** Convenient pedal-activated cord retraction for easy storage.
- **Versatile Attachments:** Universal floorhead, crevice nozzle, small dust brush, pet powermate attachment, and upholstery brush.
- **Lightweight and Maneuverable:** Compact design weighing 14.9 lbs for easy handling and storage.
- **Variable Speed Control:** Adjustable suction power for different cleaning needs.

Components:

1. Main Unit (Canister)
2. Flexible Hose
3. Telescopic Wand
4. Universal Floorhead
5. Crevice Nozzle
6. Small Dust Brush
7. Pet Powermate Attachment
8. Upholstery Brush
9. HEPA-H10 Inlet Filter
10. Outlet Sponge
11. Dust Cup

3. SETUP AND ASSEMBLY

Follow these steps to assemble your Aspiron Canister Vacuum Cleaner:

1. **Attach the Hose:** Insert the flexible hose into the suction inlet on the main unit until it clicks securely into place.
2. **Assemble the Wand:** Connect the telescopic wand to the handle end of the flexible hose. Ensure it is firmly attached.
3. **Attach the Floorhead:** Connect the universal floorhead to the other end of the telescopic wand.
4. **Insert Accessories:** For specific cleaning tasks, attach the desired accessory (crevice nozzle, small dust brush, pet powermate, or upholstery brush) directly to the handle end of the hose or the telescopic wand.

Powerful Suction

Efficient motor generates powerful suction for a deep clean

23.5
Kpa

23.5 Kpa

455
AW

≥455AW
Input Power



1200W
Rated Power



100000
RPM



Image: The Aspiron Canister Vacuum Cleaner fully assembled, ready for use.

4. OPERATING INSTRUCTIONS

Powering On/Off:

- Plug the power cord into a suitable electrical outlet. The vacuum cleaner has a 20 ft cord, providing a 33 ft cleaning radius.

- Press the power button located on the main unit to turn the vacuum cleaner on or off.




Image: The vacuum cleaner showing its extended power cord and the automatic cord rewind pedal.

Adjusting Suction Power:

- The vacuum cleaner features variable speed control. Rotate the dial on the main unit to adjust the suction power from minimum to maximum, depending on the cleaning task and surface type.



Image: A detailed view of the suction control dial, allowing adjustment from minimum to maximum power.

Using Attachments:

- **Universal Floorhead:** Suitable for both hard floors and low-pile carpets.
- **Crevice Nozzle:** Ideal for cleaning tight spaces, corners, and edges.
- **Small Dust Brush:** Use for delicate surfaces, curtains, and upholstery.
- **Pet Powermate Attachment:** Designed for effective removal of pet hair from upholstery and carpets.
- **Upholstery Brush:** For cleaning furniture and other fabric surfaces.



Image: A display of the various cleaning tools included with the vacuum cleaner.

Automatic Cord Rewind:

- To retract the power cord, gently step on the cord rewind pedal located on the main unit. The cord will automatically retract into the vacuum cleaner.

5. MAINTENANCE

Regular maintenance ensures optimal performance and extends the life of your vacuum cleaner.

Emptying the Dust Cup:

- When the dust cup is full or suction power decreases, it's time to empty it.
- Press the dust cup release button and carefully remove the dust cup from the main unit.
- Position the dust cup over a trash bin and open the bottom lid to release the debris.
- Close the lid securely and reattach the dust cup to the vacuum cleaner.



Image: Demonstrating the process of emptying the dust cup into a waste receptacle.

Cleaning the Filters:

The Aspirin E4ASPVAC1200 features a 3-stage filtration system, including a washable HEPA-H10 inlet filter and an outlet sponge.

1. **HEPA-H10 Inlet Filter:** Remove the dust cup and locate the HEPA filter. Gently tap it to remove loose dust. For a deeper clean, rinse it under cool running water. Ensure it is completely dry before reinserting.
2. **Outlet Sponge:** The outlet sponge can also be removed and rinsed under cool water. Allow it to air dry completely before placing it back.
3. **Dust Cup:** The entire dust cup is washable. Rinse it with water and ensure it is thoroughly dry before reassembling.



Image: The washable dust cup being cleaned under running water.



Image: The HEPA filter and outlet sponge, which are part of the vacuum's filtration system.

Important: Never operate the vacuum cleaner without the dust cup and all filters properly installed and completely dry.

6. TROUBLESHOOTING

If you encounter issues with your vacuum cleaner, refer to the following table for common problems and solutions.

Problem	Possible Cause	Solution
Vacuum cleaner does not turn on.	Not plugged in; power outlet not working; power button not pressed.	Ensure the plug is securely in the outlet. Check the power outlet with another appliance. Press the power button firmly.
Loss of suction.	Dust cup full; filters clogged; hose/attachments blocked.	Empty the dust cup. Clean or replace filters. Check hose and attachments for blockages and remove them.
Unusual noise.	Blockage in hose/brush roll; foreign object in motor area.	Turn off and unplug the vacuum. Check for and remove any blockages. If noise persists, contact customer support.
Cord does not rewind.	Cord is tangled; rewind mechanism jammed.	Gently pull out a small amount of cord and press the rewind pedal again. Ensure the cord is not tangled.

7. SPECIFICATIONS

Feature	Specification
Brand	Aspiron
Model Name	E4ASPVAC1200
Power Source	Corded Electric
Wattage	1200 watts
Maximum Suction	455AW / 24Kpa

Feature	Specification
Dust Cup Capacity	3.7 QT (3.5 Liters)
Filter Type	HEPA-H10 Filter
Cord Length	20 ft
Cleaning Radius	33 ft
Item Weight	14.9 Pounds
Item Dimensions (L x W x H)	17"L x 12"W x 9"H
Surface Recommendation	Hard Floor, Low-Pile Carpet
Special Features	3-Stage Filtration, Flexible Brush Head, Height Adjustable Wand, Large Cleaning Radius, XL-Capacity Dust Cup, Automatic Cord Rewind

8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included with your product or visit the official Aspiron website. You can also contact Aspiron customer service for assistance with product inquiries, troubleshooting, or replacement parts.

Manufacturer: Aspiron

UPC: 779602201169

ASIN: B0DWSFD2RH