

[Manuals.plus](#) /

› [WLIVE](#) /

› WLIVE Fabric Dresser Set User Manual (3, 4, and 9 Drawer Models)

WLIVE 3, 4, and 9 Drawer Dresser Set

WLIVE Fabric Dresser Set User Manual

Models: 3-Drawer, 4-Drawer, 9-Drawer Storage Organizer Units

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your WLIVE Fabric Dresser Set. Please read this manual thoroughly before assembly and use to ensure proper function and safety. Keep this manual for future reference.

SAFETY INFORMATION

- Always follow assembly instructions carefully.
- Ensure all parts are securely fastened before use.
- Do not overload drawers. Refer to specifications for weight limits.
- Use the included anti-tipping accessories to secure the dresser to a wall, especially for taller units or in households with children. This prevents accidental tipping.
- Keep small parts away from children during assembly.
- Place the dresser on a level surface to ensure stability. Adjustable feet can be used to compensate for uneven floors.

PACKAGE CONTENTS

Before beginning assembly, verify that all components listed in the packaging are present and undamaged. If any parts are missing or damaged, contact WLIVE customer service.

Typical components include:

- Steel frame components
- Wooden top board(s)
- Fabric drawers (various sizes depending on model)
- Handles for drawers
- Assembly hardware (screws, bolts, Allen wrench)
- Anti-tipping kit
- Adjustable plastic feet (or casters for some models)

SETUP AND ASSEMBLY

Assembly is designed to be straightforward. It is recommended to assemble the unit on a soft, clean surface to prevent scratches.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out. Identify each component using the provided parts list.
2. **Assemble Frame:** Connect the steel frame components according to the diagrams in your specific model's instruction sheet. Ensure all screws are tightened securely but do not overtighten.
3. **Attach Top Board:** Secure the wooden top board(s) to the assembled frame using the designated screws.
4. **Install Drawer Handles:** Attach the handles to the front of each fabric drawer.
5. **Insert Drawers:** Fold and insert the fabric drawers into their respective slots within the frame.
6. **Install Anti-Tipping Kit:** For safety, especially with children present, attach the anti-tipping strap to the back of the dresser and secure it to a wall stud using the provided hardware. Follow the specific instructions included with the anti-tipping kit.
7. **Adjust Feet/Casters:** If your model includes adjustable feet, adjust them to ensure the dresser is level and stable. If casters are included, ensure they are securely attached and locked if desired.



Image 1: Overview of the WLIVE Fabric Dresser Set, featuring the 3-drawer, 4-drawer, and 9-drawer configurations. Each unit has a rustic brown wood grain print top and fabric drawers with black metal handles, supported by a black steel frame.






Image 2: A detailed view of the WLIVE 3-Drawer Dresser, highlighting the rustic brown wood grain top, black fabric sides, and three fabric drawers with black handles. The unit is on casters.







Image 3: A detailed view of the WLIVE 4-Drawer Dresser, showcasing its rustic brown wood grain top and four fabric drawers. The unit features a black steel frame and adjustable feet.



Image 4: A detailed view of the WLIVE 9-Drawer Dresser, featuring a rustic brown wood grain top and nine fabric drawers. A television is placed on top, demonstrating its use as a media console. The unit has a black steel frame and adjustable feet.

OPERATING INSTRUCTIONS

Your WLIVE Fabric Dresser is designed for versatile storage in various rooms.

- **Drawer Use:** Gently pull and push the fabric drawers using the handles. Avoid forcing drawers, especially if they feel stuck, to prevent damage.
- **Weight Distribution:** Distribute items evenly within drawers to maintain balance and prevent strain on the fabric. Place heavier items in lower drawers if possible.
- **Top Surface:** The wooden top surface can be used for lamps, clocks, books, or decorative items. Ensure items placed on top do not exceed the specified weight capacity.
- **Mobility (3-Drawer with Casters):** If your 3-drawer unit has casters, unlock them to move the dresser. Lock the casters when the dresser is in its desired position to prevent accidental movement.



Image 5: The WLIVE 3-Drawer Dresser positioned next to a bed in a bedroom, demonstrating its function as a bedside table or compact storage unit. The top surface holds a lamp and decorative items, while the drawers are partially open, revealing stored contents.



Image 6: The WLIVE 9-Drawer Dresser shown with an integrated LED lighting strip under the top surface, controlled via a smartphone app. This image illustrates the potential for ambient lighting and smart features, enhancing the dresser's functionality beyond basic storage.

MAINTENANCE AND CARE

- **Cleaning the Frame and Top:** Wipe the steel frame and wooden top with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the finish.
- **Cleaning Fabric Drawers:** The non-woven synthetic fabric drawers can be spot cleaned with a mild detergent and a damp cloth. Allow them to air dry completely. Do not machine wash or tumble dry.
- **Regular Checks:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **Avoid Excessive Moisture:** While the wooden top is water-resistant, prolonged exposure to moisture should be avoided. Wipe up spills immediately.

TROUBLESHOOTING

Problem: Dresser feels wobbly or unstable.

Solution: Ensure the dresser is on a level surface. Adjust the plastic feet (if applicable) to stabilize the unit. Verify all frame screws are securely tightened. Ensure the anti-tipping kit is properly installed and secured to a wall stud.

Problem: Drawers are difficult to open or close.

Solution: Check if the drawers are overloaded. Redistribute contents if necessary. Ensure the fabric drawers are fully unfolded and correctly inserted into their slots. Inspect for any obstructions within the drawer slot.

Problem: Missing parts during assembly.

Solution: Double-check all packaging materials. If parts are genuinely missing, contact WLIVE customer service with your purchase information and the specific missing part numbers.

SPECIFICATIONS

WLIVE Fabric Dresser Set Specifications

Feature	3-Drawer Model	4-Drawer Model	9-Drawer Model
Overall Dimensions (W x D x H)	15.7" x 11.8" x 29.6"	15.7" x 11.8" x 38.7"	47.0" x 13.46" x 31.3"
Top Weight Capacity	66 lbs	66 lbs	66 lbs
Per Drawer Weight Capacity	5.5 lbs	5.5 lbs	11 lbs
Materials	Steel Frame, Water-Resistant Wood Top, Non-Woven Synthetic Fabric Drawers		
Color/Finish	Rustic Brown Wood Grain Print / Black Frame		
Special Features	Casters, Anti-Tipping Kit	Adjustable Feet, Anti-Tipping Kit	Adjustable Feet, Anti-Tipping Kit, (Optional: Integrated Power Outlet/USB, LED Lighting)



Image 7: Dimensional diagram for the WLIVE 3-Drawer Dresser, illustrating its width (15.7"), depth (11.8"), and height (29.6"). It also shows the drawer dimensions and weight capacities for the top (66 lbs) and individual drawers (5.5 lbs).




Image 8: Dimensional diagram for the WLIVE 4-Drawer Dresser, illustrating its width (15.7"), depth (11.8"), and height (38.7"). It also shows the drawer dimensions and weight capacities for the top (66 lbs) and individual drawers (5.5 lbs).



Image 9: Dimensional diagram for the WLIVE 9-Drawer Dresser, illustrating its width (47.0"), depth (13.46"), and height (31.3"). It also shows the drawer dimensions and weight capacities for the top (66 lbs) and individual drawers (11 lbs).

WARRANTY INFORMATION

WLIVE products typically come with a limited warranty. For specific details regarding the warranty period and coverage for your WLIVE Fabric Dresser Set, please refer to the warranty card included with your product or visit the official WLIVE website. Keep your proof of purchase for warranty claims.

CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact WLIVE customer service. Have your product model number and purchase date ready when contacting support.

WLIVE Customer Service:

- Refer to your product packaging or the WLIVE official website for the most current contact information.

- Online support may be available through the WLIVE brand store on Amazon or their dedicated support portal.

© 2025 WLIVE. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DWSHRQ81>

More documents and user manuals: <https://manuals.plus/>