

Manuals.plus /

> Gizoon /

> Gizoon 6 Drawer Dresser User Manual

Gizoon AP40-W

Gizoon 6 Drawer Dresser User Manual

Model: AP40-W | Brand: Gizoon

INTRODUCTION

The Gizoon 6 Drawer Dresser is designed to provide spacious and stylish storage for your home. Its robust construction and thoughtful features ensure both functionality and aesthetic appeal. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to help you make the most of your new dresser.



Image: The Gizoon Modern 6 Drawer Dresser, showcasing its sleek design.

KEY FEATURES

- **Spacious Storage:** Six large drawers (13.3" D x 21.3" W x 5.2" H) with a 30 lbs capacity each, ideal for clothes, documents, and miscellaneous items. The top board supports up to 50 lbs.
- **Durable Construction:** Crafted from wood with a timeless black finish and robust wooden frame for superior stability.

- **Modern Design:** Sleek lines, black metal handles, and delicate sealing edges resist cracking.
- **Smooth Operation:** Drawers glide effortlessly on silent metal tracks.
- **Safety Features:** Equipped with an anti-tipping device for enhanced family safety.
- **Versatile Placement:** Suitable for bedrooms, living rooms, entryways, and hallways.



Image: Easy-pull metal handles and smooth drawer rails for effortless access.



Image: Anti-tipping device for safety and the dresser's elegant, sturdy base.

SETUP AND ASSEMBLY

Assembly of the Gizoon 6 Drawer Dresser is designed to be straightforward. Please follow the instructions carefully. It is recommended to have 2-3 people for assembly. Ensure you have a clear workspace and verify all components against the parts list before starting.

Assembly Video Guide

Video: Official "How to Install" guide for the Gizoon 6 Drawer Dresser. This video provides a step-by-step visual walkthrough of the entire assembly process, including attaching rails, constructing the frame, and assembling drawers. It highlights key connection points and proper tool usage.

Pre-Assembly Checklist

- Unpack all components and lay them out on a soft, clean surface to prevent scratches.
- Verify all parts and hardware against the included parts list. If any parts are missing or damaged, contact customer service immediately.
- Ensure you have the provided screwdriver (or an electric screwdriver for efficiency, not included).
- Wear gloves to prevent injury during handling.









-  Ships in **1 box** — all parts included
-  **Recommended:** 2-3 people
But time varies by experience
-  **Assembly Requirements:** Requires a screwdriver (included)
-  **For Efficiency:** Electric screwdriver can be used (not included)
-  **Tip:** Adequate workspace recommended, please take inventory of all components before you starting!
Wear gloves to prevent injury
-  Contact us for any assembly questions

Image: A person reviewing the assembly instructions and components before beginning the setup.

General Assembly Steps (Refer to video for detailed visuals):

1. Attach drawer slides to the side panels of the dresser frame.
2. Assemble the main frame of the dresser, connecting the top, bottom, and side panels.
3. Secure the back panel to the dresser frame.
4. Assemble each of the six drawers by connecting the front, back, and side pieces, then inserting the bottom panel.
5. Attach the metal handles to the front of each drawer.
6. Install the anti-tipping device to the back of the dresser and secure it to a wall stud.
7. Carefully insert each assembled drawer into its corresponding slot on the dresser frame.

OPERATING INSTRUCTIONS

Drawer Usage:

To open a drawer, gently pull the metal handle. To close, push the drawer firmly until it is fully seated within the frame. The smooth metal tracks ensure easy operation.

Anti-Tipping Device:

The anti-tipping device is a crucial safety feature. Ensure it is properly installed and secured to a wall stud to prevent accidental tipping, especially in households with children or pets. Regularly check that the device remains firmly attached.

MAINTENANCE

- **Cleaning:** Wipe the dresser surfaces with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as they may damage the finish.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they are tight. Re-tighten if necessary to maintain stability.
- **Drawer Rails:** If drawers become stiff, a small amount of silicone lubricant can be applied to the metal tracks.
- **Avoid Overloading:** Do not exceed the maximum weight capacity of 30 lbs per drawer and 50 lbs for the top surface to prevent damage.

TROUBLESHOOTING

- **Wobbly Dresser:** Ensure all screws are tightened. Check that the dresser is on a level surface. Adjust if necessary.
- **Drawers Not Sliding Smoothly:** Check that the drawer rails are correctly aligned and securely fastened. Apply silicone lubricant if needed.
- **Missing or Damaged Parts:** If you find any missing or damaged parts upon opening the package, please contact Gizoon customer service immediately.

SPECIFICATIONS

Brand	Gizoon
Model	AP40-W
Product Dimensions	16"D x 47"W x 30"H
Color	Black
Number of Drawers	6
Drawer Dimensions (Each)	13.3" D x 21.3" W x 5.2" H
Drawer Weight Capacity	30 lbs
Top Board Weight Capacity	50 lbs
Material	Wood, Metal Handles
Assembly Required	Yes (Self-installation)

Product Size



Top Board 50lbs
Weight Capacity



Image: Detailed product dimensions and weight capacities.

WARRANTY AND SUPPORT

For any assistance during the assembly process, questions about product functionality, or to report missing/damaged parts, please do not hesitate to reach out to Gizon customer service. Your satisfaction is our priority.

Customer Service Email: support.us@soforoom.com

Please refer to your purchase documentation for specific warranty details.