

Manuals.plus /

› King Lucky /

› King Lucky i21 Open Ear Clip-on Earbuds User Manual

King Lucky B0DWSQFRZK

King Lucky i21 Open Ear Clip-on Earbuds User Manual

INTRODUCTION

The King Lucky i21 Open Ear Clip-on Earbuds are designed for comfort, secure fit, and high-quality audio while maintaining awareness of your surroundings. Featuring Bluetooth 5.4 technology and advanced ENC noise-cancelling, these earbuds provide a reliable and clear audio experience for various activities. This manual provides instructions for setup, operation, maintenance, and troubleshooting to ensure optimal use of your earbuds.

WHAT'S IN THE BOX

Your King Lucky i21 Open Ear Clip-on Earbuds package includes:

- One pair of King Lucky i21 Open Ear Clip-on Earbuds
- One Charging Case
- User Manual

SETUP

1. Initial Charge

Before first use, fully charge the earbuds and charging case. Place the earbuds into the charging case and connect the case to a power source using a compatible USB cable. The indicator lights on the case will show charging status. A full charge typically takes approximately 2 hours for the case.



Image: Earbuds in charging case showing battery life and charging times.

2. Pairing with Your Device

1. Ensure both earbuds are charged.
2. Open the charging case. The earbuds will automatically power on and enter pairing mode, indicated by a flashing light on one of the earbuds.
3. On your device (smartphone, tablet, etc.), go to Bluetooth settings and turn Bluetooth on.
4. Search for available devices and select '**King Lucky i21**' (or similar name) from the list.
5. Once connected, the earbud indicator light will turn off or show a steady light, and you will hear a confirmation tone.

Wide compatibility

Multi-device compatibility,
suitable for various Bluetooth devices



Image: Illustration of Bluetooth pairing process and wide device compatibility.

3. Wearing the Earbuds


The King Lucky i21 earbuds feature an upgraded C-shaped bridge design for a secure and comfortable open-ear fit. Gently clip the earbuds onto your ear, ensuring the speaker is positioned near your ear canal without entering it. This design allows you to enjoy high-quality audio while remaining aware of your surroundings.

Hard-hitting C-shaped design

where strength meets style the perfect partner for your workout



Image: A user wearing the C-shaped clip-on earbud, demonstrating its secure fit.



Clip on DESIGN

A comfortable and stylish choice



Secure fit



Keep ear clean



No Ear bone
pain limitation



Not affect
wearing glass

Image: Benefits of the clip-on design, including secure fit and comfort for glasses wearers.

OPERATING INSTRUCTIONS

Power On/Off

The earbuds power on automatically when removed from the charging case and power off when placed back into the case and the lid is closed.

Music Playback (Touch Controls)

- **Play/Pause:** Tap once on either earbud.
- **Next Track:** Double-tap the right earbud.
- **Previous Track:** Double-tap the left earbud.

Call Management (Touch Controls)

- **Answer/End Call:** Tap once on either earbud during an incoming call or active call.
- **Reject Call:** Press and hold either earbud for 2 seconds during an incoming call.

Volume Control

Volume control is typically managed through your connected device. Please adjust the volume directly on your smartphone, tablet, or other Bluetooth-enabled device.

ENC Noise Cancelling

The earbuds feature ENC (Environmental Noise Cancellation) technology for clear calls in noisy environments. This feature is automatically active during phone calls to reduce background noise for the person on the other end.

The World Is Your Stage!

These earbuds are perfect for various occasions: leisure time, work, commuting, studying, or just enjoying your daily routine.




Image: Users enjoying the earbuds in different daily activities, highlighting versatility.

MAINTENANCE

Cleaning

Gently wipe the earbuds and charging case with a soft, dry, lint-free cloth. Do not use abrasive cleaners, solvents, or immerse the earbuds or case in water. Ensure charging contacts are clean and dry.

Storage

Store the earbuds in their charging case when not in use to protect them from damage and maintain battery charge. Avoid storing in extreme temperatures (hot or cold) or high humidity.

Battery Care

To prolong battery life, avoid fully discharging the earbuds and charging case frequently. Charge regularly, even if not used for extended periods. Do not attempt to replace the battery yourself.

TROUBLESHOOTING

- **Earbuds not pairing:** Ensure both earbuds are charged and removed from the case. Turn off and on Bluetooth on your device. Forget the device from your Bluetooth list and try pairing again.
- **No sound from one earbud:** Place both earbuds back into the charging case, close the lid, wait a few seconds, then remove them. This can reset the connection between the earbuds.
- **Charging issues:** Check the charging cable and power adapter. Ensure the charging contacts on the earbuds and inside the case are clean and free of debris. Try a different USB port or charger.
- **Poor call quality:** Ensure the earbuds are properly seated on your ears. Move closer to your connected device. Avoid environments with strong electromagnetic interference.
- **Earbuds falling off:** Ensure the earbuds are correctly clipped onto your ear, following the C-shaped design. Experiment with slight adjustments for a more secure fit.

SPECIFICATIONS

Brand	King Lucky
Model Name	Clip on Earbuds Open Ear Earbuds
Model Number	B0DWSQFRZK
Connectivity Technology	Wireless (Bluetooth 5.4)
Ear Placement	Open Ear
Form Factor	On Ear
Noise Control	Active Noise Cancellation (ENC for calls)
Audio Driver Type	Dynamic Driver (12mm)
Frequency Range	20 Hz - 20,000 Hz
Battery Life (Single Charge)	Up to 6 Hours
Battery Life (with Charging Case)	Up to 50 Hours
Control Method	Touch
Water Resistance Level	Waterproof
Material	Plastic
Earbud Weight	Approx. 4.7g per earbud

Next-Gen Bluetooth 5.4

Faster, Smoother, More Reliable

48%

faster transmission

138%

better anti-interference



Image: Illustration of Bluetooth 5.4 technology for enhanced connectivity.

12mm Driver for immersive sound!

Large Drivers Deliver Deep Bass and Crisp Highs
DNS ensures every word is transmitted precisely for vivid calls.



Image: Detailed view of the 12mm dynamic driver for superior sound quality.

WARRANTY AND SUPPORT

King Lucky products are designed for reliability and performance. For detailed warranty information, technical support, or customer service inquiries, please refer to the official King Lucky website or contact customer support through your original purchase platform. Please retain your proof of purchase for any warranty claims.

You can visit the King Lucky store for more information: [King Lucky Store](#)