

[Manuals.plus](#) /

› [COLAMY](#) /

› COLAMY Upholstered Dining Chairs (Set of 6, Dark Brown) Instruction Manual

COLAMY VC-D6201-BRBK-FL-3B

COLAMY Upholstered Dining Chairs (Set of 6, Dark Brown) Instruction Manual

Model: VC-D6201-BRBK-FL-3B

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, maintenance, and care of your COLAMY Upholstered Dining Chairs. Please read this manual thoroughly before assembly and use to ensure proper function and longevity of your chairs.



Image: COLAMY Upholstered Dining Chairs (Set of 6) in a dining room.

SAFETY INFORMATION

- Always adjust the foot pegs before use to prevent floor damage and ensure stability.
- Follow the assembly instructions carefully to ensure safe and stable setup. Incorrect assembly can lead to instability and potential injury.
- Do not exceed the maximum recommended load of 300 pounds per chair.
- Keep all small parts and packaging materials away from children during assembly.
- Regularly check all bolts and connections to ensure they remain tight. Retighten as necessary.

PACKAGE CONTENTS

Before beginning assembly, verify that all components are present and undamaged.

- Dining Chair Bodies (6 units)
- Hardware Pack (screws, washers, hex wrench)
- User Manual (this document)



Image: Example of chair components and hardware.

SETUP AND ASSEMBLY INSTRUCTIONS

Assembly is designed to be straightforward. It is recommended to assemble the chairs on a soft, clean surface to prevent scratching.

1. **Identify Components:** Unpack all parts and identify the chair back, seat cushion, front legs, back legs, and hardware. Refer to the included hardware pack for screw types (A, B, C, etc.) and quantities.
2. **Attach Front Legs:** Secure the front legs to the underside of the seat cushion using the specified screws and the provided hex wrench. Ensure they are firmly attached.
3. **Attach Back Legs:** Align the back legs with the pre-drilled holes on the chair back and the seat cushion. It may be necessary to apply firm downward pressure on the seat cushion to help align the holes correctly. Insert and tighten the specified screws.
4. **Secure All Connections:** Once all legs are attached, gently place the chair upright. Double-check and tighten all screws to ensure the chair is stable and secure. Avoid overtightening.
5. **Adjust Foot Pegs:** Each chair is equipped with adjustable foot pegs. Turn these pegs at the bottom of each leg to level the chair and prevent wobbling. Adjust them until all four legs make even contact with the floor.



Image: Adjustable foot peg for leveling chairs.

OPERATING INSTRUCTIONS

The COLAMY dining chairs are designed for comfortable seating in dining rooms, kitchens, or other suitable areas.

- Ensure the chair is placed on a flat, stable surface before use.

- Sit centrally on the seat cushion to distribute weight evenly.
- Avoid standing on the chair or using it as a step stool.
- Do not drag the chairs across the floor; lift them to move to prevent damage to the chair legs and floor.



Image: Demonstrating the comfort of the high-density sponge cushion.

MAINTENANCE AND CARE

- **Cleaning:** To maintain the product's condition, wipe clean with a dry cloth. The PU leather material is easy to clean; for spills, wipe immediately with a damp cloth and then dry. Avoid the use of strong liquid cleaners, abrasive cleaners, or solvents, as these can damage the finish and upholstery.
- **Protection:** Avoid direct sunlight exposure and excessive heat to prevent fading or damage to the wood and PU leather.
- **Regular Inspection:** Periodically check all hardware connections and retighten if necessary to ensure the chair remains stable.



Image: Detail of the breathable PU leather material.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Chair wobbles after assembly.	Uneven leg length or loose connections.	Adjust the foot pegs on the bottom of each leg until the chair is stable. Ensure all screws are tightened evenly.
Difficulty aligning screw holes during assembly.	Components not fully seated or misaligned.	Apply firm downward pressure on the seat cushion while attaching the back legs to help align the holes. Loosen other screws slightly if needed, then retighten all once aligned.

Problem	Possible Cause	Solution
Squeaking noises during use.	Loose hardware connections.	Check and retighten all screws and bolts.

SPECIFICATIONS

Feature	Detail
Brand	COLAMY
Model Number	VC-D6201-BRBK-FL-3B
Color	Dark Brown
Material	Rubberwood, PU Leather, Memory Foam
Product Dimensions (L x W x H)	21.26 x 18.11 x 40.55 inches
Item Weight (per chair)	15.5 pounds
Maximum Recommended Load	300 Pounds
Special Features	Cushioned Seat, Ergonomic Design, Ladder High Back, Adjustable Foot Pegs
Included Components	Dining chairs body, hardware pack, user manual

WARRANTY AND SUPPORT

For warranty information or product support, please refer to the purchase documentation or contact COLAMY customer service directly. Contact details can typically be found on the manufacturer's official website or through your retailer.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question