



[Manuals.plus](#) /

> [Lenovo](#) /

> [Lenovo L22-4e Monitor User Manual](#)

Lenovo L22-4e

Lenovo L22-4e Monitor User Manual

Model: L22-4e | Brand: Lenovo

[Introduction](#) [Setup](#) [Operation](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your Lenovo L22-4e Monitor. Designed for office and general use, this 21.5-inch FHD IPS display offers a 100Hz refresh rate, 4ms MPRT, and 99% sRGB color space coverage. Its three-sided borderless design and ergonomic tilt stand enhance both aesthetics and user comfort. Please read this manual thoroughly to ensure optimal performance and longevity of your monitor.



Figure 1: Front view of the Lenovo L22-4e Monitor.

2. SETUP

2.1 Unpacking the Monitor

Carefully remove all components from the packaging. Ensure the following items are present:

- Monitor
- Tilt Stand
- Power Cable
- HDMI Cable
- Quick Setup Guide
- Warranty Information

2.2 Assembling the Stand

1. Place the monitor face down on a soft, clean surface to prevent scratches.
2. Attach the stand base to the stand neck. Secure it using the integrated key or screws provided.
3. Connect the assembled stand to the back of the monitor until it clicks into place or is securely fastened.




Figure 2: Monitor with the tilt stand assembled.

2.3 Connecting the Monitor

The Lenovo L22-4e Monitor supports HDMI and VGA connections.

1. Connect one end of the provided HDMI cable to the HDMI port on the monitor.
2. Connect the other end of the HDMI cable to the HDMI port on your computer or device.
3. Alternatively, use a VGA cable to connect the monitor to your device via the VGA port.
4. Connect the power cable to the monitor's power input, then plug the other end into a power outlet.
5. Press the power button on the monitor to turn it on.

Lenovo L22-4e Monitor



Figure 3: Rear view showing HDMI, VGA, and Power ports.

2.4 Initial Configuration

Upon first power-on, the monitor should automatically detect the input signal. If not, use the On-Screen Display (OSD) menu to select the correct input source.

3. OPERATION

3.1 On-Screen Display (OSD) Menu

The OSD menu allows you to adjust various monitor settings. Typically, a joystick or a series of buttons on the monitor's bezel controls navigation.

- **Brightness/Contrast:** Adjust the overall luminance and contrast levels.
- **Color Settings:** Modify color temperature, gamma, and individual RGB values. The monitor features 99% sRGB color space coverage for accurate color reproduction.
- **Input Source:** Manually select between HDMI and VGA inputs.

- **Picture Mode:** Choose from preset display modes optimized for different content types (e.g., Standard, Movie, Game).
- **Audio:** Adjust volume for the built-in speakers (if applicable) or connected headphones.



Crafted for clarity



A stylish monitor with a
3-side borderless display.

Figure 4: Monitor displaying data analytics, highlighting clarity and detail.

3.2 Ergonomic Adjustments

The tilt stand allows for comfortable viewing angles. Adjust the monitor's tilt (-5° to $+22^{\circ}$) to suit your posture and reduce strain.



Comfortable on the eyes



Reduces blue light emissions without causing color distortion.

Figure 5: Monitor demonstrating ergonomic tilt adjustment.

3.3 Eye Comfort Features

The Lenovo L22-4e monitor incorporates technology to reduce blue light emissions, minimizing potential eye strain during extended use without distorting colors.



Premium panel

3-sided
NearEdgeless

In-Plane
Switching (IPS)

Figure 6: Monitor highlighting reduced blue light emissions for eye comfort.

3.4 Performance Features

- **100Hz Refresh Rate:** Provides smoother visuals, reducing motion blur in fast-paced content.
- **4ms MPRT Response Time:** Minimizes ghosting for a clearer viewing experience.
- **IPS Display:** Offers wide 178° viewing angles and consistent color accuracy from various perspectives.



Colorful clarity

Color Gamut
99% sRGB

Color Support
16.7 Million

Figure 7: Monitor showcasing 4ms response time for clear visuals.

3.5 Video Demonstrations

Monitor for Workstation Overview

Your browser does not support the video tag.

This video provides an overview of the Lenovo monitor, highlighting its suitability for workstation environments and overall quality.

Space-Saving Design

Your browser does not support the video tag.

This video demonstrates the space-saving design of the Lenovo monitor, showcasing its compact footprint and sleek profile.

Monitor for Office Use

Your browser does not support the video tag.

This video illustrates the Lenovo monitor's features and benefits for an office environment, emphasizing productivity and display quality.

4. MAINTENANCE

4.1 Cleaning the Monitor

- Always power off the monitor and unplug it before cleaning.
- Use a soft, lint-free cloth lightly dampened with water or a non-abrasive screen cleaner.
- Do not spray cleaner directly onto the screen.
- Avoid using harsh chemicals, abrasives, or solvents.

4.2 Environmental Considerations

The Lenovo L22-4e monitor is packaged in 100% recyclable paper boxes to minimize environmental impact. Please dispose of packaging materials responsibly. For end-of-life product recycling, consult local regulations or Lenovo's recycling programs.

Connectivity




Figure 8: Monitor highlighting its sustainable packaging.

5. TROUBLESHOOTING

If you encounter issues with your Lenovo L22-4e Monitor, refer to the following common solutions:

- **No Power:** Ensure the power cable is securely connected to both the monitor and the power outlet. Verify the power outlet is functional.
- **No Signal:** Check that the video cable (HDMI or VGA) is firmly connected to both the monitor and your computer. Ensure the correct input source is selected in the OSD menu.
- **Flickering Screen:** Verify the video cable is not loose or damaged. Try a different video cable or port. Adjust the refresh rate in your computer's display settings.
- **Image Distortion/Poor Quality:** Ensure the monitor's native resolution (1920x1080) is selected in your computer's display settings. Adjust OSD settings like brightness, contrast, and color.
- **No Audio:** If using HDMI, ensure your computer's audio output is set to the monitor. Check the monitor's volume in the OSD menu.

For further assistance, consult the Lenovo support website or contact customer service.

6. SPECIFICATIONS

Feature	Detail
Brand	Lenovo
Model Number	67D5KCC6US
Screen Size	21.5 Inches
Screen Resolution	1920x1080 (FHD 1080p)
Max Screen Resolution	1920 x 1080 Pixels
Refresh Rate	100Hz
Response Time	4ms MPRT (Extreme Mode)
Panel Type	IPS
Color Gamut	99% sRGB
Contrast Ratio	1300:1
Viewing Angle	178° (Ultra-wide)
Aspect Ratio	16:9
Screen Surface	Matte
Connectivity	HDMI, VGA
Ergonomics	Tilt Stand (-5°/+22°), VESA Mount Support
Color	Raven Black
Item Weight	6.2 pounds
Product Dimensions (LxWxH)	6.85 x 19.26 x 14.94 inches

7. WARRANTY AND SUPPORT

7.1 Warranty Information

Your Lenovo L22-4e Monitor comes with a standard warranty. Please refer to the included Warranty Information document for details regarding coverage, terms, and conditions. Retain your proof of purchase for warranty claims.

7.2 Customer Support

For technical support, product inquiries, or service requests, please visit the official Lenovo support website or contact their customer service department. Contact information can typically be found in the Quick Setup Guide or on the Lenovo website.

