

HiFuture HEFC-FLEXFT

HiFuture FLEXCLIP AI Enhanced Open Ear Wireless Earphone

Model: HEFC-FLEXFT

INTRODUCTION

This manual provides essential information for the proper use and maintenance of your HiFuture FLEXCLIP AI Enhanced Open Ear Wireless Earphones. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.

The HiFuture FlexClip Open-Ear Wireless Earbuds are designed for comfort and situational awareness, featuring a secure, clip-on fit. They offer extended listening with 30 hours of battery life and crystal-clear calls thanks to AI ENC noise cancellation. The 12mm dynamic driver provides powerful bass and immersive sound, supported by Bluetooth 5.4 for a stable connection. With an IPX5 waterproof rating, these earbuds are suitable for active lifestyles.

PRODUCT OVERVIEW



Image: HiFuture FlexClip Open-Ear Wireless Earphones in Champagne Gold, resting in their charging case. The case is open, displaying the two earbuds with their distinctive open-ear design and metallic accents. A small green indicator light is visible on the front of the case.

Key Features:

- **Open-Ear Design:** Allows awareness of surroundings while listening to audio.
- **30 Hours Playtime:** Extended battery life for prolonged use.
- **AI ENC Noise Cancellation:** Enhances call clarity in noisy environments.
- **Bluetooth 5.4:** Provides a stable and seamless wireless connection.
- **IPX5 Waterproof Rating:** Resistant to sweat and splashes, suitable for active use.

SETUP

1. Charging the Earphones and Case

Before first use, fully charge the earphones and the charging case. Connect the provided USB-C cable to the charging port on the case and to a power source. The indicator light on the case will show charging status.

- A full charge typically takes approximately 1.5 hours for the earphones and 2 hours for the case.
- Ensure the charging contacts on the earphones and inside the case are clean and dry.

2. Pairing with Your Device

1. Open the charging case. The earphones will automatically enter pairing mode (indicator lights will flash).
2. On your device (smartphone, tablet, etc.), go to Bluetooth settings and turn on Bluetooth.
3. Search for available devices and select "HiFuture FLEXCLIP" from the list.
4. Once connected, the earphone indicator lights will turn off or show a steady light, and you will hear a confirmation tone.

Note: The earphones will automatically reconnect to the last paired device when taken out of the case, if Bluetooth is

enabled on the device.

3. Wearing the Earphones

The HiFuture FLEXCLIP earphones feature an open-ear design with a clip-on mechanism. Gently clip the earphone onto your ear, ensuring the speaker is positioned comfortably near your ear canal without blocking it. Adjust for a secure and comfortable fit.

OPERATING INSTRUCTIONS

Touch Controls:

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Volume Up:** Triple tap on the right earbud.
- **Volume Down:** Triple tap on the left earbud.
- **Answer/End Call:** Single tap on either earbud during an incoming call or active call.
- **Reject Call:** Press and hold either earbud for 2 seconds during an incoming call.
- **Activate Voice Assistant:** Press and hold either earbud for 3 seconds.

AI ENC Noise Cancellation:

The AI ENC (Environmental Noise Cancellation) feature is automatically active during calls to reduce background noise for clearer communication. No manual activation is required for this feature.

MAINTENANCE

Cleaning:

- Regularly clean the earphones and charging case with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents.
- Ensure charging contacts are free of dust and debris.

Storage:

- Store the earphones in their charging case when not in use to protect them and keep them charged.
- Avoid storing in extreme temperatures (hot or cold) or high humidity.

Battery Care:

- To preserve battery life, charge the earphones and case regularly, even if not used frequently.
- Avoid fully depleting the battery for extended periods.

TROUBLESHOOTING

Problem	Solution
---------	----------

Problem	Solution
Earphones not pairing.	Ensure earphones are charged. Turn off and on Bluetooth on your device. Forget "HiFuture FLEXCLIP" from your device's Bluetooth list and re-pair. Place earphones back in the case, close the lid, wait 5 seconds, then open to reset pairing mode.
No sound from earphones.	Check device volume and earphone volume. Ensure earphones are connected to the correct device. Try playing different audio content.
Charging case not charging.	Verify the USB-C cable is properly connected to both the case and the power source. Try a different charging cable or power adapter. Ensure the power source is active.
Call quality issues.	Ensure earphones are properly worn. Move closer to your connected device. Avoid environments with excessive background noise if possible.

SPECIFICATIONS

Model Name	HEFC-FLEXFT
Brand	HiFuture
Ear Placement	Open Ear
Form Factor	On Ear
Colour	Champagne
Playtime	Up to 30 hours (with charging case)
Noise Cancellation	AI ENC (Environmental Noise Cancellation)
Connectivity	Bluetooth 5.4
Waterproof Rating	IPX5
Package Dimensions	13.1 x 11.1 x 4.4 cm
Item Weight	180 g (Package Weight)
Country of Origin	China

WARRANTY INFORMATION

HiFuture products are typically covered by a limited manufacturer's warranty. For specific warranty terms, duration, and conditions applicable to your HiFuture FLEXCLIP earphones, please refer to the warranty card included in your product packaging or visit the official HiFuture website.

Please retain your proof of purchase for any warranty claims.

CUSTOMER SUPPORT

If you encounter any issues or have questions not covered in this manual, please contact HiFuture customer support. You can usually find contact information (email, phone, or support portal) on the official HiFuture website or through the retailer where you purchased the product.

For more information, visit the [HiFuture Store on Amazon](#).

© 2025 HiFuture. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question