

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Reebok](#) /

› [Reebok LS Edition Smartwatch RBK-SBLS-W User Manual](#)

Reebok RBK-SBLS-W

Reebok LS Edition Smartwatch User Manual

Model: RBK-SBLS-W

WELCOME

Thank you for choosing the Reebok LS Edition Smartwatch. This manual provides essential information for setting up, operating, and maintaining your device. Please read it carefully to ensure optimal performance and longevity of your smartwatch.

PRODUCT OVERVIEW

The Reebok LS Edition Smartwatch (Model RBK-SBLS-W) is designed for comfort and high performance, featuring a round OLED display and notification capabilities.

Package Contents

- Reebok LS Edition Smartwatch (White)
- Charging Cable
- Adjustable Strap

Device Components



Front view of the Reebok LS Edition Smartwatch, showing the round display with time, date, step count, and heart rate. The watch features a white case and a light grey fabric strap.

SETUP

Charging the Smartwatch

1. Connect the charging cable to the charging port on the back of the smartwatch.
2. Plug the other end of the charging cable into a USB power adapter (not included) or a computer's USB port.
3. The watch display will indicate charging status. Ensure the device is fully charged before first use.

Powering On/Off

To power on, press and hold the side button until the Reebok logo appears. To power off, navigate to the settings menu on the watch, select "Power Off," and confirm.

Pairing with Your Smartphone

1. Download the official Reebok Smartwatch application from your smartphone's app store.
2. Ensure Bluetooth is enabled on your smartphone.
3. Open the Reebok Smartwatch application and follow the on-screen instructions to search for and connect to your RBK-SBLS-W smartwatch.
4. Confirm the pairing request on both your smartphone and the smartwatch.

Note: The smartwatch is compatible with smartphones, tablets, and PCs. For optimal functionality, pairing with a smartphone is recommended.

OPERATING INSTRUCTIONS

Navigating the Interface

The Reebok LS Edition Smartwatch features an OLED touchscreen display.

- **Swipe Up/Down:** Scroll through menus and notifications.
- **Swipe Left/Right:** Access different widgets or quick settings.
- **Tap:** Select an item or open an application.
- **Side Button:** Press to return to the home screen or access the app list.

Receiving Notifications

Once paired with your smartphone, the smartwatch will display notifications for calls, messages, and other applications. Ensure notification permissions are enabled in the Reebok Smartwatch application on your phone.

Activity Tracking

The smartwatch includes a sensor for activity tracking. Access the activity tracking features through the main menu to monitor steps, heart rate, and other fitness data.

Customizing Watch Faces

Customize your watch face through the Reebok Smartwatch application on your smartphone. Select from available designs to personalize your device.

MAINTENANCE

Cleaning

Gently wipe the smartwatch and strap with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.

Water Resistance

The device is designed for daily wear but is not suitable for swimming or showering. Avoid prolonged exposure to water.

Storage

Store the smartwatch in a cool, dry place when not in use. Avoid extreme temperatures.

TROUBLESHOOTING

Smartwatch Not Powering On

Ensure the device is fully charged. Connect it to the charging cable and allow it to charge for at least 30 minutes before attempting to power it on again.

Unable to Pair with Smartphone

1. Ensure Bluetooth is enabled on both your smartphone and the smartwatch.
2. Make sure the smartwatch is within range of your smartphone.
3. Restart both your smartphone and the smartwatch.
4. Try unpairing and re-pairing the device through the Reebok Smartwatch application.

Notifications Not Appearing

Check the notification settings within the Reebok Smartwatch application on your smartphone. Ensure all necessary permissions are granted for the app to access notifications.

Inaccurate Activity Data

Ensure the smartwatch is worn snugly on your wrist. Calibrate the activity tracker through the companion application if available.

SPECIFICATIONS

| Feature | Detail |
|---------------------|---------------------------|
| Model | RBK-SBLS-W |
| Color | White |
| Display Type | OLED |
| Display Shape | Round |
| Material | Plastic |
| Dimensions | 1.6 x 4.5 x 17 cm |
| Weight | 70 g |
| Operating System | Wear OS 2.0 |
| Memory Storage | 64 MB |
| Battery Capacity | 150 mAh |
| Connectivity | Bluetooth |
| GPS | No |
| Compatibility | Smartphone, Tablet, PC |
| Special Features | Notifications, Sensor |
| Included Components | Charger, Adjustable Strap |



Close-up front view of the Reebok LS Edition Smartwatch, highlighting the display and the Reebok branding on the strap.



Side view of the Reebok LS Edition Smartwatch, showing the profile of the watch case and the texture of the adjustable fabric strap.

WARRANTY AND SUPPORT

Warranty Information

For information regarding the product warranty, please refer to the warranty card included in your product packaging or visit the official Reebok support website.

Customer Support

If you encounter any issues or have questions not covered in this manual, please contact Reebok customer support. Visit the [Reebok Brand Store](#) for more information and support resources.

Related Documents - RBK-SBLS-W

| | |
|-------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | <p>Reebok Open Flow Open Wearable Earphones User Manual</p> <p>User manual for the Reebok Open Flow Open Wearable Earphones (RBK1307), covering safety precautions, features, charging, pairing, usage, maintenance, and warranty information.</p> |
|  | <p>Reebok GB40s / GX40s Console Guide: User Manual</p> <p>This guide provides essential information for operating the Reebok GB40s and GX40s fitness equipment console. Learn about display functions, workout modes, and operational procedures for a versatile training experience.</p> |
|  | <p>Reebok Relay Smart Bracelet Instruction Manual</p> <p>Comprehensive instruction manual for the Reebok Relay Smart Bracelet, covering setup, features, sports modes, app usage, and care instructions.</p> |
|  | <p>Reebok JET300+ Treadmill User Manual & Bluetooth Guide</p> <p>Comprehensive user manual for the Reebok JET300+ treadmill, covering assembly, operation, safety, maintenance, and Bluetooth connectivity. Essential guide for owners.</p> |
|  | <p>Reebok Watch User Manual: Operation, Features, and Warranty</p> <p>Comprehensive guide to operating your Reebok watch, including setting the date and time, using the alarm and INDIGLO® night-light, understanding water resistance, adjusting the bracelet, and warranty information.</p> |
|  | <p>Reebok GX40s Cross Trainer User Manual</p> <p>Discover the Reebok GX40s Cross Trainer with this comprehensive user manual. Learn about safe operation, assembly, console features, and various workout modes for an effective home fitness experience.</p> |