Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HiPlay BFGGTXMK39-1

HiPlay ZD Toys 1/10 Anniversary Non-Luminous Edition Iron Man MK39 Action Figure Instruction Manual

Model: BFGGTXMK39-1

Introduction

Thank you for purchasing the HiPlay ZD Toys 1/10 Anniversary Non-Luminous Edition Iron Man MK39 Action Figure. This highly detailed collectible figure, also known as "Gemini," is designed to replicate Tony Stark's space armor suit from Iron Man 3. Standing approximately 7 inches tall, this figure features exceptional sculpting, premium paint application, and fully articulated joints, allowing for a wide range of dynamic poses. This manual provides essential information for the proper setup, operation, and care of your action figure.

Safety Information

- This product contains small parts and is not suitable for children under 15 years of age.
- Keep the figure away from extreme temperatures, direct sunlight, and high humidity to prevent damage.
- Avoid applying excessive force to joints or accessories, as this may cause breakage.
- Do not use harsh chemicals or abrasive materials for cleaning.

Package Contents

Carefully unpack the box and ensure all components are present. The package should include:



Image: The Iron Man MK39 figure displayed with all its interchangeable hands, repulsor effects, and display stand.

- Iron Man MK39 Action Figure (1)
- Interchangeable Hand Parts (Multiple pairs for various poses)
- Repulsor Blast Effect Parts (Multiple pieces for hands and feet)
- Display Stand with Articulated Arm (1)

Setup

1. **Unboxing:** Carefully remove the figure and accessories from their packaging.
2. **Attaching Hand Parts:** Gently pull off the default hand parts. Select the desired interchangeable hand parts and carefully push them onto the wrist pegs until secure.
3. **Attaching Repulsor Effects:** For dynamic action poses, insert the repulsor blast effect parts into the small holes on the palms of the hands and the soles of the feet. Ensure they are firmly attached.



Image: Iron Man MK39 figure in a mid-air pose, showcasing repulsor effects attached to hands and feet.

4. **Assembling the Display Stand:** Connect the base of the display stand to the articulated arm. Attach the figure clip to the articulated arm.
5. **Posing the Figure:** Use the articulated arm of the display stand to support the figure in various flying or action poses. Ensure the figure is securely clipped to prevent falls.



Image: Iron Man MK39 figure in a dynamic flying pose, supported by its clear display stand.

Operating

The Iron Man MK39 figure features extensive articulation for a wide range of posing options:

- **Joint Articulation:** The figure has multiple points of articulation in the neck, shoulders, elbows, wrists, torso, hips, knees, and ankles. Gently manipulate these joints to achieve desired poses.
- **Interchangeable Parts:** Swap out hand parts and repulsor effects to customize the figure's appearance and recreate iconic scenes.



Image: Front and back views of the Iron Man MK39 figure, highlighting its detailed armor and articulation points.

Maintenance

- **Cleaning:** Use a soft, dry cloth to gently wipe dust from the figure. For stubborn dirt, lightly dampen the cloth with water. Avoid using cleaning agents that may damage the paint or plastic.
- **Storage:** Store the figure in a cool, dry place away from direct sunlight and extreme temperatures. Keep it in its original packaging or a display case to protect it from dust and damage.

Troubleshooting

- **Loose Joints:** If a joint becomes loose, a small amount of clear nail polish or a specialized joint tightener can be applied to the joint and allowed to dry to increase friction.
- **Stiff Joints:** If a joint is too stiff, gently warm the area with a hairdryer on a low setting for a few seconds to soften the plastic before attempting to move it.
- **Difficulty Attaching Parts:** If accessories are difficult to attach, ensure proper alignment and apply gentle, even pressure. Do not force parts into place.

Specifications

Product Dimensions	2 x 3 x 7 inches
Item Weight	1 pound
Item Model Number	BFGGTXMK39-1
Material	PC/ABS
Scale	1/10
Manufacturer	ZD Toys

Warranty and Support

For any inquiries regarding your HiPlay ZD Toys Iron Man MK39 Action Figure, please refer to the retailer's return policy or contact HiPlay customer support directly. Keep your proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DWWKYCDB

More documents and user manuals: **https://manuals.plus/**