

## ZZB ZB10

# ZZB ZB10 10-Inch Android 15 Tablet User Manual

Model: ZB10 | Brand: ZZB

## INTRODUCTION

---

Welcome to the user manual for your new ZZB ZB10 10-inch Android 15 Tablet. This guide provides essential information to help you set up, operate, maintain, and troubleshoot your device. Please read this manual thoroughly to ensure optimal performance and longevity of your tablet.

## 1. SETUP

---

### 1.1 Package Contents

Before you begin, please verify that all items are present in your package:

- ZZB ZB10 10-inch Android Tablet
- Protective Case
- Stylus
- USB Type-C Charging Cable
- Power Adapter (not explicitly listed but implied for charging)
- User Manual (this document)

### 1.2 Charging the Tablet

For first-time use, fully charge your tablet.

1. Connect the USB Type-C cable to the tablet's charging port.
2. Connect the other end of the cable to the power adapter.
3. Plug the power adapter into a wall outlet.
4. The battery icon on the screen will indicate charging status. Allow several hours for a full charge.

# Large Capacity Batteries

Type-c charging port for fast charging, so you can stay online all day without worry

# 6000mAh



Image: The tablet screen showing media content, highlighting its large battery capacity for extended use.

## 1.3 Powering On and Off

- **To Power On:** Press and hold the Power button (usually located on the side or top edge) until the ZZB logo appears on the screen.
- **To Power Off:** Press and hold the Power button until a power-off menu appears. Select "Power off" and confirm.
- **To Restart:** From the power-off menu, select "Restart".

## 1.4 Initial Configuration

Upon first power-on, the tablet will guide you through the initial setup process for Android 15. Follow the on-screen prompts to:

- Select your language.
- Connect to a Wi-Fi network.
- Sign in with your Google account or create a new one.
- Set up screen lock (PIN, pattern, password).
- Review and accept terms and conditions.

## 2. OPERATING THE TABLET

---

### 2.1 Navigating the Interface

The ZZB ZB10 tablet uses a touch-based interface. Common gestures include:

- **Tap:** To select an item or open an app.
- **Tap and Hold:** To access contextual menus or move icons.
- **Swipe:** To scroll through pages or lists.
- **Pinch-to-Zoom:** To zoom in or out on images and web pages.

# 10.1 Inch IPS Display

1280\*800 resolution and a screen-to body ratio of 84%.With a largedazzling screen, every frame is a visual feast.



Image: The tablet showcasing its 10.1-inch IPS display with high resolution, ideal for visual content.

### 2.2 Connecting to Wi-Fi

To connect to the internet:

1. Go to **Settings > Network & internet > Wi-Fi**.
2. Turn on Wi-Fi.
3. Select your desired network from the list.
4. Enter the password if prompted and tap **Connect**.

# WiFi6 Bluetooth 5.0

Fast WiFi6 and efficient Bluetooth 5.0 wireless connectivity for uninterrupted access to the web and entertainment



Image: The tablet highlighting its fast Wi-Fi 6 and efficient Bluetooth 5.0 connectivity for seamless internet access and device pairing.

## 2.3 Bluetooth Pairing

To connect Bluetooth devices like headphones or speakers:

1. Go to **Settings** > **Connected devices** > **Bluetooth**.
2. Turn on Bluetooth.
3. Ensure your Bluetooth device is in pairing mode.
4. Select the device from the "Available devices" list and follow any on-screen prompts to complete pairing.

## 2.4 Installing Applications

Your tablet comes with Google Play Store pre-installed.

1. Open the **Play Store** app.
2. Search for the desired app.

3. Tap **Install** and follow the instructions.

## Android 15.0 OS + GMS Certification

Download Your Favorite APP From Google Play




Image: The tablet displaying its Android 15 operating system and the Google Play Store, indicating GMS certification for app downloads.

### 2.5 Using the Camera

The tablet features an 8MP rear camera and a 2MP front camera.

1. Open the **Camera** app.
2. Tap the shutter button to take a photo.
3. Switch between front and rear cameras using the camera switch icon.
4. Select video mode to record videos.



Image: A user engaged in a video call on the tablet, showcasing its utility for communication with the front camera.

## 2.6 Expanding Storage

The tablet supports microSD cards up to 1024GB for additional storage.

1. Locate the microSD card slot on the tablet (refer to the device diagram if available).
2. Carefully insert the microSD card into the slot until it clicks into place.
3. The tablet will detect the new storage. You may be prompted to format it for use.

## 2.7 Using the Stylus

The included stylus can be used for more precise input, drawing, or note-taking.

- Simply touch the stylus tip to the screen as you would with your finger.
- Some apps may offer enhanced stylus functionality.



Image: A user utilizing the included stylus for creative work on the tablet, demonstrating its precision input capabilities.

## 3. MAINTENANCE

---

### 3.1 Cleaning the Tablet

- Use a soft, lint-free cloth to gently wipe the screen and body.
- For stubborn smudges, slightly dampen the cloth with water or a screen cleaner designed for electronics.
- Avoid using harsh chemicals, abrasive materials, or excessive moisture.

### 3.2 Battery Care

- Avoid extreme temperatures, as they can degrade battery life.
- Do not leave the tablet fully discharged for extended periods.
- Use only the provided or certified charging accessories.

### 3.3 Software Updates

Periodically check for system updates to ensure your tablet has the latest features and security patches.

- Go to **Settings > System > System update**.
- Follow the on-screen instructions to download and install any available updates.

## 4. TROUBLESHOOTING

---

### 4.1 Tablet Not Powering On

- Ensure the tablet is sufficiently charged. Connect it to the charger for at least 30 minutes.
- Try a different charging cable and adapter to rule out faulty accessories.
- Perform a forced restart by holding the Power button for 10-15 seconds.

### 4.2 Wi-Fi Connection Problems

- Check if Wi-Fi is enabled in **Settings**.
- Restart your Wi-Fi router and the tablet.
- Forget the network in **Settings > Network & internet > Wi-Fi**, then reconnect.
- Ensure you are within range of the Wi-Fi signal.

### 4.3 Slow Performance

- Close unnecessary background applications.
- Clear cache for frequently used apps (**Settings > Apps > [App Name] > Storage & cache > Clear cache**).
- Free up storage space by deleting unused apps or files.
- Restart the tablet regularly.

### 4.4 Screen Issues (White/Black Screen, Random Rotation)

- Perform a forced restart of the tablet.
- Check if "Auto-rotate screen" is enabled or disabled in Quick Settings (swipe down from top of screen).
- If the issue persists, consider a factory reset (**Settings > System > Reset options > Erase all data (factory reset)**). **Warning: This will delete all data on your tablet. Back up important files first.**

## 5. SPECIFICATIONS

---

Feature	Specification
Model Name	ZB10
Operating System	Android 15
Display Size	10.1 Inches
Screen Resolution	1280 x 800 IPS HD
RAM	8GB (including 5GB extended memory)
Internal Storage (ROM)	32GB

Feature	Specification
Expandable Storage	Up to 1024GB via microSD card
Rear Camera	8 MP
Front Camera	2 MP
Battery Capacity	6000mAh
Average Battery Life	Up to 10-12 hours (usage dependent)
Wireless Connectivity	Wi-Fi 6 (802.11ax), Bluetooth 5.0
Charging Port	USB Type-C
Dimensions (LxWxH)	9.7 x 6.8 x 0.35 inches
Item Weight	2.01 pounds

## 6. WARRANTY AND SUPPORT

---

### 6.1 Warranty Information

Your ZZB ZB10 tablet is covered by a limited manufacturer's warranty. Please refer to the warranty card included in your product packaging or visit the official ZZB website for detailed terms and conditions. This warranty typically covers manufacturing defects but does not cover damage caused by misuse, accidents, or unauthorized modifications.

### 6.2 Customer Support

If you encounter any issues not covered in this manual or require further assistance, please contact ZZB customer support.

- **Online Support:** Visit the official ZZB website for FAQs, support resources, and contact forms.
- **Email Support:** Refer to your product packaging or the ZZB website for the customer service email address.