Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

WOPET WOPET 2024 Upgrade Automatic Cat Feeder for 2 Cats

WOPET Automatic Cat Feeder for 2 Cats - User Manual

Model: WOPET 2024 Upgrade Dual-Bowl Feeder

Product Overview

The WOPET Automatic Cat Feeder is designed to provide scheduled and portion-controlled meals for up to two cats simultaneously. This feeder ensures your pets receive fresh food at consistent times, promoting healthy eating habits. It features a large food storage capacity, a user-friendly control panel, and easy-to-clean components.




This image displays the WOPET Automatic Cat Feeder, featuring a main unit with a digital display, two stainless steel food bowls, and a pack of desiccant bags. The feeder is designed for automated pet feeding.

Key Features

- **Dual Feeding System:** Equipped with two stainless steel bowls, this feeder allows you to schedule meals for two pets simultaneously.
- **Programmable Meals:** Set up to 6 meals per day with adjustable portion sizes from 1 to 20 portions (approximately 12g per portion).
- **Freshness Preservation:** A 4L (17 cups) capacity food tank, built-in desiccant bag compartment, and triple seal design keep dry food fresh and crunchy.
- **Easy Maintenance:** Removable components including the tank lid, food tank, tank base, and bowls simplify cleaning.
- **User-Friendly Interface:** An intuitive LCD screen and control buttons allow for quick setup and programming.
- **Personalized Voice Recording:** Record a 10-second message to call your pets at meal times.

- **Secure Lid Lock:** Prevents curious pets from accessing the food outside of scheduled feeding times.



This image illustrates the WOPET Automatic Cat Feeder in use, with two cats eating from the dual stainless steel bowls. Text overlays highlight its 4L capacity and 12g per portion dispensing.



This image shows the WOPET Automatic Cat Feeder with two cats, demonstrating its ability to provide scheduled meals throughout the day. Example feeding times and portion sizes are displayed.

Package Contents

- 1 x WOPET Automatic Cat Feeder Unit
- 2 x Stainless Steel Bowls

- 4 x Pet Food Desiccant Bags
- 1 x Power Adapter
- 1 x User Manual (this document)

Setup Guide

1. Unpacking and Assembly

1. Remove all components from the packaging.
2. Place the main feeder unit on a flat, stable surface.
3. Insert the two stainless steel bowls into their designated slots at the base of the feeder.
4. Open the lid of the food tank.
5. Locate the desiccant bag holder inside the lid.
6. Insert one desiccant bag into the holder.



This image shows the desiccant bag being placed into its designated compartment located on the underside of the feeder's lid, ensuring food freshness.

7. Fill the food tank with dry pet food. Ensure the kibble size is between 2-12mm. Do not overfill.
8. Securely close the lid, ensuring the triple seal is engaged to maintain food freshness.

2. Power Connection


Connect the power adapter to the feeder's power port, typically located at the back or bottom of the unit. Plug the

adapter into a standard wall outlet. The feeder will power on, and the display will activate.

Operating Instructions

1. Control Panel Overview

The feeder's control panel consists of an LCD screen and several buttons for setting time, programming meals, and recording voice messages. Familiarize yourself with the button functions before proceeding.



This image provides a detailed view of the WOPET Automatic Cat Feeder's control panel, showing the digital display and various control buttons for programming.

2. Setting Current Time

1. Press and hold the "Set" button until the hour digit on the LCD screen begins to flash.
2. Use the "Up" and "Down" buttons to adjust the hour to the current time.
3. Press "Set" again to move to the minute digit, then use "Up" and "Down" to adjust the minutes.

4. Press "Set" one more time to confirm the current time setting.

3. Programming Meal Times and Portions

The feeder supports up to 6 scheduled meals per day.

1. Press the "Meal" button to enter meal programming mode. The display will show "Meal 1" and the time will flash.
2. Use the "Up" and "Down" buttons to set the desired feeding time for Meal 1.
3. Press "Set" to confirm the time. The portion size will then flash.
4. Use "Up" and "Down" to adjust the portion size (1-20 portions).
5. Press "Set" to confirm the portion size for Meal 1.
6. Repeat steps 1-5 for additional meals (Meal 2 through Meal 6) as required. If a meal is not set, it will not dispense food.

4. Manual Feeding

To dispense a single portion of food immediately, press the "Manual Feed" button. This will dispense one portion of food into the bowls.

5. Voice Recording

You can record a 10-second voice message that will play during each scheduled meal to call your pets.

1. Press and hold the "Record" button (indicated by a microphone icon) until you hear a single beep.
2. Speak your message clearly into the microphone.
3. Release the button when you have finished recording. The recording will automatically save and play during scheduled meals.
4. To delete the recording, press and hold the "Record" button until you hear two beeps.

Maintenance and Cleaning

1. Cleaning the Feeder

Regular cleaning is essential to ensure hygiene and proper operation of your feeder.

1. Before cleaning, disconnect the power adapter from the feeder.
2. Remove the food tank lid, food tank, tank base, and stainless steel bowls from the main unit.
3. Wash the stainless steel bowls with mild soap and water. Rinse them thoroughly and dry completely.
4. Wipe the food tank, tank base, and lid with a damp cloth. Do not submerge the main feeder unit (the part with electronics) in water.
5. Ensure all parts are completely dry before reassembling them to prevent moisture damage or mold growth.

2. Desiccant Bag Replacement

To maintain optimal food freshness, it is recommended to replace the desiccant bag every two weeks.

1. Open the food tank lid.
2. Remove the old desiccant bag from its holder located on the underside of the lid.
3. Insert a new WOPET desiccant bag into the holder.
4. Close the lid securely, ensuring it forms a tight seal.

Troubleshooting

Problem	Possible Cause	Solution
Feeder not dispensing food	Food tank is empty	Refill the food tank with dry pet food.
	Food is jammed in the dispenser chute	Check for blockages in the dispenser. Ensure kibble size is within the recommended 2-12mm range.
	Power issue	Verify the power adapter is securely connected to both the feeder and the wall outlet.
Display not working	No power supply	Check the power connection. Ensure the outlet is functional.
Food not fresh or crunchy	Desiccant bag needs replacement	Replace the desiccant bag every two weeks.
	Lid not sealed properly	Ensure the food tank lid is securely closed and the triple seal is fully engaged.

Product Specifications

- **Brand:** WOPET
- **Model:** WOPET 2024 Upgrade Automatic Cat Feeder
- **Material:** Stainless Steel (for bowls)
- **Food Tank Capacity:** 4 Liters / 17 Cups
- **Portion Size:** 1-20 portions (approx. 12g per portion)
- **Meals per Day:** Up to 6 programmable meals
- **Compatible Food:** Dry food only, kibble size 2-12mm
- **Special Features:** Programmable Timer, 10-second Voice Recorder, Dual Stainless Steel Bowls, Desiccant Bag Compartment

Warranty and Support

For detailed warranty information, technical support, or any product-related inquiries, please refer to the contact information provided on your product packaging or visit the official WOPET website.

You can also find additional resources and support by visiting theWOPET Store on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DWWY2GJT

More documents and user manuals: **https://manuals.plus/**