

TqcSXToXQ

M73 Wireless Earphones User Manual

Model: TqcSXToXQ

INTRODUCTION

Thank you for choosing the M73 Wireless Earphones. These earphones are designed to provide advanced connectivity and high-fidelity sound quality, offering an unparalleled audio experience. Featuring a mini design, liquid silicone ear tips for comfort, and fingerprint touch controls, they are ideal for extended wear, including during sleep. This manual will guide you through the setup, operation, and maintenance of your new earphones.

SAFETY INFORMATION

Please read all safety instructions carefully before using this product. Failure to follow these instructions may result in injury or damage to the device.

- Do not expose the earphones or charging case to extreme temperatures, humidity, or liquids.
- Avoid dropping, impacting, or disassembling the device.
- Keep out of reach of children and pets.
- Use only the provided or certified charging cables.
- Do not use the earphones at excessively high volumes for prolonged periods to prevent hearing damage.

PACKAGE CONTENTS

- M73 Wireless Earphones (Left and Right)
- Charging Case
- USB Type-C Charging Cable
- User Manual
- (Potentially) Different sized ear tips (liquid silicone)

PRODUCT OVERVIEW



Figure 1: M73 Wireless Earphones and Charging Case (White)

The image above displays the M73 Wireless Earphones nestled within their open charging case. The case features a digital display indicating the battery level. Both earphones are visible, showcasing their compact design and ear hooks for secure fit.



Figure 2: Individual Earphone and Charging Case

This image provides a closer look at one M73 earphone, detached from its charging case. It highlights the earphone's ergonomic shape and the charging contacts inside the case.

Components:

- **Earphones:** Left and Right, with integrated ear hooks and touch control areas.
- **Charging Case:** Houses and charges the earphones, features a digital battery display and a Type-C charging port.
- **LED Indicator:** On earphones and case, indicating charging status and connection.
- **Microphone:** For calls and voice assistant.

SETUP

1. Charging the Earphones and Case

Before first use, fully charge both the earphones and the charging case.

1. Place the earphones into the charging case. Ensure they are correctly seated; the LED indicators on the earphones should light up.
2. Connect the USB Type-C charging cable to the charging port on the case and the other end to a USB power adapter (not included) or a computer's USB port.
3. The digital display on the charging case will show the battery percentage during charging. Once fully charged, the display will indicate 100%.

2. Pairing with Your Device

The earphones will automatically enter pairing mode when removed from the charging case.

1. Open the charging case and remove both earphones. They will automatically power on and attempt to pair with each other.
2. On your device (smartphone, tablet, etc.), go to the Bluetooth settings.
3. Search for available devices and select "M73" from the list.
4. Once connected, a voice prompt will confirm the successful pairing. The earphones will automatically reconnect to the last paired device when removed from the case.

3. Wearing the Earphones

Little! Excellent sound quality

HiFi level sound quality

Liquid silicone



NEW

New product

Fingerprint touch | Type-C fast charging

Sleep Earphones

Figure 3: Earphone in Use

This image shows an M73 earphone being worn, highlighting its ergonomic design and how it sits comfortably in the ear, suitable for extended periods, including sleep.

1. Identify the Left (L) and Right (R) earphones.
2. Gently insert the earphone into your ear canal and rotate it slightly to ensure the ear hook sits securely around your earlobe.
3. Adjust for a comfortable and snug fit to optimize sound quality and passive noise isolation. The liquid silicone material is designed for comfort during prolonged wear.

OPERATING INSTRUCTIONS

The M73 earphones feature intuitive fingerprint touch controls for various functions.

Function	Action
----------	--------

Function	Action
Power On	Remove earphones from the charging case.
Power Off	Place earphones back into the charging case.
Play/Pause Music	Single tap on either earphone.
Next Track	Double tap on the Right earphone.
Previous Track	Double tap on the Left earphone.
Volume Up	Triple tap on the Right earphone.
Volume Down	Triple tap on the Left earphone.
Answer/End Call	Single tap on either earphone during an incoming call.
Reject Call	Press and hold either earphone for 2 seconds during an incoming call.
Activate Voice Assistant	Press and hold either earphone for 3 seconds (when not on a call).

Sleep Mode Features:

Designed for comfort during sleep, the M73 earphones offer immersive sound quality suitable for relaxation or masking ambient noise. Their mini design and liquid silicone ear tips ensure they remain comfortable even when lying down.

MAINTENANCE

Cleaning:

- Wipe the earphones and charging case with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents.
- Gently clean the charging contacts on both the earphones and the case with a dry cotton swab if necessary.

Storage:

When not in use, store the earphones in their charging case to protect them and keep them charged. Store in a cool, dry place away from direct sunlight.

Battery Care:

- To prolong battery life, avoid fully discharging the earphones and case frequently.
- Charge the device regularly, even if not in frequent use.

TROUBLESHOOTING

Problem	Solution
---------	----------

Problem	Solution
Earphones not pairing with device.	<ul style="list-style-type: none"> ◦ Ensure earphones are charged. ◦ Turn off Bluetooth on your device and turn it back on. ◦ Forget "M73" in your device's Bluetooth settings and re-pair. ◦ Place earphones back in the case, close the lid, wait a few seconds, then open and try again.
Only one earphone working.	<ul style="list-style-type: none"> ◦ Ensure both earphones are charged. ◦ Place both earphones back into the charging case, close the lid, and then remove them together to force re-synchronization.
Earphones not charging.	<ul style="list-style-type: none"> ◦ Check if the charging cable is securely connected to both the case and the power source. ◦ Ensure the charging contacts on the earphones and inside the case are clean and free of debris. ◦ Try a different USB port or power adapter.
Poor sound quality.	<ul style="list-style-type: none"> ◦ Ensure earphones are properly seated in your ears for a good seal. ◦ Clean any earwax or debris from the earphone nozzles. ◦ Move closer to your connected device to avoid interference.

SPECIFICATIONS

Feature	Detail
Model Number	TqcSXTtoXQ
Connectivity	Wireless (Bluetooth)
Charging Port	USB Type-C
Control Type	Fingerprint Touch Control
Ear Tip Material	Liquid Silicone
Audio Quality	HiFi Level, Hi-Res Audio Support
Design Feature	Mini Design, Sleep Specific
Dimensions (Case)	Approximately 6.5cm / 2.55in (width)

Sleep specific

Immersive sound quality



Mini design

Comfortable to wear for a long time

Figure 4: Charging Case Dimensions

This image illustrates the approximate width of the M73 charging case, measured at 6.5 cm or 2.55 inches, indicating its compact size.

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation provided with your purchase or contact the retailer/manufacturer directly. Keep your proof of purchase for warranty claims.