

[Manuals.plus](#) /

› [NIORSUN](#) /

› NIORSUN 27.6 Inch Battery Operated Wall Sconce (Set of 2) Instruction Manual

NIORSUN 27.6 Inch Wall Sconce

NIORSUN 27.6 Inch Battery Operated Wall Sconce Instruction Manual

Model: 27.6 Inch Wall Sconce

1. INTRODUCTION

Thank you for choosing the NIORSUN 27.6 Inch Battery Operated Wall Sconce. This product is designed to provide versatile and convenient lighting for various indoor spaces without the need for complex wiring. Featuring a rechargeable battery, adjustable brightness, three color temperature options, and both remote and touch control, this wall sconce offers a modern and functional lighting solution. Please read this manual carefully before installation and use to ensure optimal performance and safety.



Image 1: NORSUN 27.6 Inch Battery Operated Wall Sconce (Set of 2) installed in a modern living room.

2. PACKAGE CONTENTS

Please check the package contents upon opening. If any items are missing or damaged, contact customer support.

- 2 x NORSUN 27.6 Inch Wall Sconce
- 2 x Remote Control
- 2 x USB-C Charging Cable
- Mounting Hardware (screws, anchors)
- User Manual

3. SETUP AND INSTALLATION

The NIORSUN wall sconce is designed for easy, cordless installation. No electrical wiring is required.

1. **Choose Location:** Select a desired location on your wall. Ensure the surface is clean and dry.
2. **Mark Mounting Points:** Hold the sconce's backplate against the wall at the desired height and use a pencil to mark the screw holes.
3. **Drill Holes:** Use an appropriate drill bit to drill pilot holes at the marked points. Insert wall anchors if necessary for drywall or plaster.
4. **Mount Backplate:** Secure the sconce's backplate to the wall using the provided screws.
5. **Attach Sconce:** Align the sconce with the mounted backplate and secure it according to the design (e.g., twisting or clicking into place).
6. **Initial Charge:** Before first use, fully charge the sconce using the provided USB-C cable. Refer to the 'Charging' section for details.

4. OPERATING INSTRUCTIONS

The wall sconce can be controlled via the included remote control or by touch on the fixture itself.

4.1. Remote Control Functions

- **ON/OFF:** Press the power button to turn the light on or off.
- **Brightness Adjustment:** Use the '+' and '-' buttons to increase or decrease brightness (0%-25%-60%-100%).
- **Color Temperature (CCT) Adjustment:** Press the '2700K', '4000K', or '5000K' buttons to switch between warm white, neutral white, and cool white light.
- **Timer Function:** Press '1H', '2H', '3H', '4H', or '6H' to set the light to automatically turn off after the selected duration.

4.2. Touch Control Functions

The touch control area is located on the fixture's base.

- **Short Press:** A short press on the touch area will cycle through the brightness levels (0%-25%-60%-100%).
- **Long Press:** A long press on the touch area will cycle through the color temperature options (2700K-4000K-5000K).

WHY CHOOSE US



NIORSUN

Cordless and battery-operated

35H and longer lighting time

3CCT



OTHER

Hardwired

Only 8H

Only 3000K

Image 2: Illustration of touch control and remote control functions.



3 COLOR TEMPERATURE



Image 3: Visual representation of the three color temperature options (2700K, 4000K, 5000K) in different room settings.

Safe & Energy-Saving

The timed function enhances safety, comfort, and convenience, improving overall quality of life and ensuring a peaceful sleep.

Timer

1H

2H

3H

4H

6H



Image 4: Demonstration of adjustable brightness levels (20%, 60%, 100%).

5. CHARGING

The NIORSUN wall sconce features a built-in 5200mAh rechargeable battery.

- **Charging Port:** Locate the USB-C charging interface on the backplate of the sconce.
- **Connect Cable:** Connect the provided USB-C charging cable to the sconce and to a standard USB power adapter

(not included).

- **Charging Time:** A full charge typically takes 7-9 hours.
- **Working Time:** The battery provides an impressive runtime of 24 to 38 hours on a single charge, depending on brightness and color temperature settings.


Touch control



Short Press to **Adjust Brightness**



Long Press to **Change Color Temperature**



Remote control

CAN BE TIMED

The wireless remote control has multiple functions and is easy to carry, making control more attentive to your needs.

Image 5: Detailed view of the sconce, showing dimensions and the USB-C charging interface.

6. MAINTENANCE

To ensure the longevity and optimal performance of your NIORSUN wall sconce, follow these maintenance guidelines:

- **Cleaning:** Gently wipe the surface of the sconce with a soft, dry cloth. Avoid using abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Recharge the sconce when the light output becomes noticeably dim. If storing the sconce for an extended period, charge it to approximately 50% every few months.
- **Storage:** Store the sconce in a cool, dry place away from direct sunlight and extreme temperatures.

7. TROUBLESHOOTING

If you encounter any issues with your NIORSUN wall sconce, please refer to the following troubleshooting tips:

Problem	Possible Cause	Solution
Light does not turn on.	Battery is depleted.	Charge the sconce using the USB-C cable.
	Remote control battery is dead.	Replace the remote control battery (CR2025, not included).
Remote control is not working.	Remote is too far from the sconce.	Ensure the remote is within effective range (approx. 10-15 feet) and pointed towards the sconce.
	Obstruction between remote and sconce.	Remove any objects blocking the signal path.
Light output is dim.	Battery is low.	Recharge the sconce.
	Brightness setting is low.	Increase brightness using the remote or touch control.

8. SPECIFICATIONS

Feature	Specification
Brand	NIORSUN
Model	27.6 Inch Wall Sconce
Material	Aluminum
Battery Capacity	5200mAh
Color Temperatures (CCT)	2700K, 4000K, 5000K
Brightness Levels	0%, 25%, 60%, 100%
Charging Interface	USB-C
Charging Time	7-9 hours
Working Time	24-38 hours (depending on settings)
Dimensions	27.56 inches (Height) x 3.94 inches (Width)

9. WARRANTY AND SUPPORT

NIORSUN proudly stands behind its products. This wall sconce comes with a full**3-year service warranty**. This warranty covers any manufacturing defects or malfunctions that may occur within three years from the date of purchase. If your black wall lamp stops working or exhibits any defects within this period, please contact our customer support for assistance.

For further support, questions, or warranty claims, please refer to the contact information provided with your purchase or visit the official NIORSUN store on Amazon: [NIORSUN Store](#).

© 2026 NIORSUN. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DWX71H1T>

More documents and user manuals: <https://manuals.plus/>