FEZIBO 55x24 White (B0DWX93TKS)

FEZIBO Electric Standing Desk User Manual

Model: 55x24 White (B0DWX93TKS)
Brand: FEZIBO

1. Introduction

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your FEZIBO Electric Standing Desk. Designed for a healthier lifestyle, this adjustable height desk allows for seamless transitions between sitting and standing, promoting better circulation and reducing muscle tension.
The 55" x 24" desktop offers ample space for your workstation, supporting multiple monitors and office essentials. Constructed with a solid steel frame and aerospace-grade lifting column connectors, the desk ensures stability and durability for various activities.



Figure 1.1: The FEZIBO Electric Standing Desk, ready for use.

2. Key Features

- **Adjustable Height Range:** Effortlessly adjust desk height from 28.3" to 46.5" (72cm to 118cm).
- **Quiet Operation:** Motor operates at less than 50 dB for silent transitions.
- **Memory Presets:** Three customizable memory presets for quick height adjustments.
- **Spacious Desktop:** 55" x 24" surface accommodates dual monitors and other office equipment.
- **Robust Construction:** Solid steel frame and aerospace-grade lifting column connectors ensure stability.
- **Anti-Collision Technology:** Integrated safety feature to prevent collisions during height adjustment.
- **Integrated Hooks:** Two desk hooks for convenient storage of headphones or bags.

3. Setup and Assembly

Assembly of the FEZIBO Electric Standing Desk is designed to be straightforward. All necessary assembly tools and detailed instructions are included in the package. For a seamless setup process, please follow the step-by-step guide provided with your desk.

An installation video is available to further assist you with the assembly. Ensure all components are present and undamaged before beginning assembly.



Figure 3.1: Desk components and tools for assembly.

4. Operating Instructions

4.1 Height Adjustment

The FEZIBO Electric Standing Desk features an intuitive control panel for height adjustment. Use the **Up** (▲) and **Down** (▼) buttons to manually adjust the desk to your desired height. The desk moves at a speed of 1 inch per second, ensuring a smooth and quiet transition.




Figure 4.1: Desk control panel with height adjustment and memory buttons.

4.2 Memory Presets

The desk is equipped with three customizable memory presets (1, 2, 3) to store your preferred sitting and standing heights. To set a memory preset:

1. Adjust the desk to your desired height using the Up/Down buttons.
2. Press and hold one of the memory preset buttons (1, 2, or 3) until the display flashes or a beep is heard, indicating the height has been saved.

To recall a saved height, simply press the corresponding memory preset button (1, 2, or 3) once. The desk will automatically move to the saved position.

4.3 Reset Function

If the desk encounters an error or needs to be recalibrated, perform a reset. Press and hold the "UP" and "DOWN" buttons simultaneously for 5 seconds until the desk moves to its lowest position and then slightly rises, indicating a successful reset.

4.4 Anti-Collision System

The desk features an anti-collision system that automatically stops and slightly reverses the desk's movement if it encounters an obstacle during adjustment. This feature enhances safety during operation.



Figure 4.2: Anti-collision feature for enhanced safety.

5. Maintenance

To ensure the longevity and optimal performance of your FEZIBO Electric Standing Desk, follow these maintenance guidelines:

- **Cleaning:** Wipe the desktop and frame with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Cable Management:** Regularly check and organize cables to prevent tangling or damage, especially during height adjustments.
- **Motor Care:** The electric motor is designed for durability. Avoid overloading the desk beyond its weight capacity to prevent strain on the motor.
- **Regular Inspection:** Periodically check all screws and connections to ensure they remain tight and secure.

6. Troubleshooting

If you encounter any issues with your FEZIBO Electric Standing Desk, please refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Desk does not move.	Power cable disconnected; motor overload; control panel error.	Check power connection. Reduce load on desk. Perform a reset (see Section 4.3).
Desk moves unevenly or makes unusual noise.	Loose connections; uneven weight distribution; motor issue.	Ensure all screws are tight. Distribute weight evenly. Perform a reset. If problem persists, contact support.
Height presets not working.	Incorrectly saved presets; control panel error.	Re-save your desired heights (see Section 4.2). Perform a reset.
Anti-collision system triggers frequently.	Obstacles under or around the desk; sensor sensitivity.	Clear the area around the desk. Ensure no objects are interfering with movement.

If the issue persists after attempting these solutions, please contact FEZIBO customer support for further assistance.

7. Specifications

Feature	Detail
Brand	FEZIBO
Model	55x24 White (B0DWX93TKS)
Desktop Dimensions (W x D)	55 inches x 24 inches (139.7 cm x 60.96 cm)
Adjustable Height Range	28.3 inches to 46.5 inches (72 cm to 118 cm)
Color	White
Style	Modern
Base Material	Alloy Steel

Feature	Detail
Top Material Type	Wood
Finish Type	Laminated
Assembly Required	Yes
Noise Level	Under 50 dB



Figure 7.1: The desk's sturdy frame ensures stability.



Figure 7.2: Visual representation of the desk's wide height range.

8. Warranty and Support

FEZIBO is committed to providing high-quality products and excellent customer service. If you encounter any questions or

warranty issues during assembly or use of your electric standing desk, our dedicated support team is ready to assist you promptly. Please refer to the contact information provided in your product packaging or visit the official FEZIBO website for support details.

© 2025 FEZIBO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question