

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Casaria](#) /
- › [CASARIA Poly Rattan Stackable Garden Chairs - Instruction Manual](#)

### Casaria 109994

# CASARIA Poly Rattan Stackable Garden Chairs

Model: 109994

## 1. INTRODUCTION

---

Thank you for choosing CASARIA Poly Rattan Stackable Garden Chairs. These chairs are designed for comfortable outdoor seating, featuring weather-resistant poly rattan and a durable steel frame. This manual provides essential information for assembly, safe use, and maintenance to ensure the longevity of your chairs.



A single black poly rattan garden chair with armrests, showcasing its design suitable for outdoor use.

## 2. SAFETY INSTRUCTIONS

- **Maximum Load Capacity:** Do not exceed the maximum load capacity of 160 kg (approximately 352 lbs) per chair. Exceeding this limit may cause damage to the chair and lead to injury.
- **Stable Surface:** Always place the chairs on a flat, stable, and level surface to prevent tipping.
- **Regular Inspection:** Periodically check all screws and connections to ensure they are tight. Retighten if necessary.
- **Children:** Supervise children when they are using the chairs. Do not allow them to climb or play roughly on the chairs.
- **Weather Conditions:** While weather-resistant, it is recommended to store chairs indoors or under cover during extreme weather conditions (strong winds, heavy snow) to prevent damage.

# BEQUEM ENTSPANNEN



Detail of the chair's robust construction, highlighting the adjustable screw feet for stability and its 160 kg load capacity.

### 3. PACKAGE CONTENTS

Please check the package contents upon receipt to ensure all parts are present and undamaged:

- Set of 4 or 8 Garden Chairs (depending on your purchase)
- Assembly Hardware (screws, washers, Allen key)
- Assembly Instructions

### 4. SETUP AND ASSEMBLY

The chairs require minimal assembly. Follow these steps carefully:

1. **Unpack:** Carefully remove all components from the packaging.
2. **Identify Parts:** Lay out all parts and assembly hardware. Refer to the included assembly diagram to identify each piece.
3. **Initial Assembly:** Attach the chair legs to the seat frame using the provided screws and washers.

*Important:* Hand-tighten all screws loosely at this stage. Do not fully tighten yet.

4. **Align and Level:** Once all parts are loosely assembled, place the chair on a flat surface. Gently apply pressure to ensure all legs are evenly touching the ground.
5. **Final Tightening:** Once the chair is level, progressively tighten all screws firmly. Avoid over-tightening.
6. **Adjust Feet:** Use the adjustable screw feet on the chair legs to fine-tune stability on uneven surfaces.

For best results and to prevent stripping, it is advisable to grease screw threads with bar soap before assembly. Keep the frame loose during initial assembly and only torque the assembly once you are satisfied with the alignment.

## 5. OPERATING (USAGE)

These chairs are designed for comfortable seating in various outdoor environments:

- **Outdoor Use:** Ideal for gardens, patios, balconies, and camping.
- **Stackable Design:** The chairs are designed to be stackable for convenient, space-saving storage when not in use.

**SCHNELL VERSTAUT,  
SCHNELL AUFGEBAUT**

**Die Stühle lassen  
sich stapeln und  
platzsparend lagern**

**GEPRÜFTE  
QUALITÄT**



The illustration shows three stages of chair arrangement. On the left is a single black wicker-style chair. In the middle, two chairs are placed side-by-side. On the right, three chairs are stacked on top of each other. Two blue curved arrows point from the single chair to the two chairs, and from the two chairs to the stack of three chairs, indicating the process of stacking.

Illustration demonstrating how multiple chairs can be easily stacked to save space when not in use.

## 6. MAINTENANCE

Proper care will extend the life and appearance of your CASARIA garden chairs:

- **Cleaning:** The high-quality poly rattan can be easily cleaned with a damp cloth. For stubborn dirt, use a mild soap solution and rinse thoroughly. Avoid abrasive cleaners or harsh chemicals.
- **Winter Storage:** To prolong the lifespan of the chairs, especially the poly rattan and steel frame, it is recommended to store them indoors or under a protective cover during the winter months or periods of prolonged non-use.
- **UV Protection:** While UV-resistant, prolonged exposure to direct sunlight can cause fading over time. Consider using covers or storing in shaded areas when not in use.



Image emphasizing the chair's weatherproof poly rattan material and durable powder-coated steel frame.

## 7. TROUBLESHOOTING

If you encounter any issues with your chairs, consider the following:

- **Wobbling Chair:** Ensure all assembly screws are fully tightened. Adjust the screw feet on the bottom of

the legs to compensate for uneven surfaces.

- **Difficulty Stacking:** Ensure chairs are oriented correctly for stacking. Check for any obstructions or damage that might prevent proper stacking.
- **Loose Parts:** Regularly inspect and tighten any loose screws or connections.

## 8. SPECIFICATIONS

|                                       |  |
|---------------------------------------|--|
| <b>Brand</b>                          | Casaria  |
| <b>Model Number</b>                   | 109994   |
| <b>Overall Dimensions (H x W x D)</b> | 90 x 56 x 60 cm (35.4 x 22 x 23.6 inches)  |
| <b>Seat Height</b>                    | 46 cm (18.1 inches)  |
| <b>Armrest Height</b>                 | 66 cm (26 inches)  |
| <b>Seat Dimensions (W x D)</b>        | 36 x 46 cm (14.2 x 18.1 inches)  |
| <b>Weight per Chair</b>               | 4.8 kg (10.6 lbs)  |
| <b>Maximum Load Capacity</b>          | 160 kg (352 lbs)   |
| <b>Wicker Material</b>                | Polyethylene (PE)  |
| <b>Frame Material</b>                 | Powder-coated Steel  |
| <b>Special Features</b>               | Armrests, Stackable, Ergonomic, Lightweight, Space-saving, Adjustable Screw Feet |

# SITZT WIE ANGEKOSSEN

UV-beständig, wetterfest  
und pflegeleicht



Diagram illustrating the key dimensions of the garden chair: 90 cm height, 56 cm width, and 60 cm depth.

## 9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to your purchase documentation or contact the retailer/manufacturer directly. Keep your proof of purchase for any warranty claims.