Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bealife CT21

Bealife 11x11 Pop Up Gazebo Tent with Mosquito Netting Instruction Manual

Model: CT21

Introduction

Thank you for choosing the Bealife 11x11 Pop Up Gazebo Tent with Mosquito Netting. This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your gazebo. Please read these instructions carefully before use and retain them for future reference.

This gazebo is designed for outdoor versatility, offering shade and protection with its upgraded PU fabric and UV protection. It features zippered mesh sidewalls to keep insects out while ensuring air circulation. The spacious 121 square feet area comfortably accommodates 7-10 people.

Safety Information

- Ensure the tent is properly secured with the included sandbags, especially in windy conditions.
- Use caution to avoid fire or excessive heat exposure due to the UV-protective materials.
- Do not use this gazebo in extreme weather conditions such as heavy rain, strong winds, or snow.
- Keep all flame and heat sources away from the gazebo fabric.
- Always supervise children around the gazebo.
- Assembly requires at least two people for safety and ease.

Package Contents

Before assembly, verify that all parts listed below are present in your package. If any parts are missing or damaged, please contact customer support.



Image: All components of the gazebo package, including the top cover cloth, small cover cloth, mosquito nets, stakes, ropes, sandbags, canopy frame, and wheeled bag.

- 1 x Top Cover Cloth
- 1 x Small Cover Cloth
- 4 x Mosquito Net
- 8 x Stake
- 4 x Rope
- 4 x Sandbag (sand not included)
- 1 x Canopy Frame
- 1 x Wheeled Bag

Setup Instructions

Setting up your pop-up gazebo is designed to be straightforward and requires two people. No tools are required for basic

assembly.



Image: Visual guide for the four main setup steps: unfolding the frame ajar, attaching the canopy top, fully unfolding the frame, and attaching the mosquito nets.

1. **Step 1: Unfold the Tent Frame Ajar.** Remove the frame from the wheeled bag and partially unfold it.
2. **Step 2: Attach the Canopy Top.** Place the canopy cover over the partially unfolded frame. Ensure it is correctly oriented.
3. **Step 3: Unfold the Tent Frame Fully.** With the canopy top in place, continue to pull the frame outwards until it is fully extended and locked into position.
4. **Step 4: Attach the Mosquito Net.** Secure the zippered mesh sidewalls to the frame as needed.
5. **Secure the Gazebo.** Extend the legs to your desired height. Fill the sandbags with sand and attach them to the gazebo legs. Use the provided stakes and ropes to further secure the gazebo to the ground for added stability.

For a visual guide on the setup process, please watch the official product video:

Video: An official Bealife video demonstrating the assembly and features of the Pop Up Gazebo Tent with Mosquito Netting. Duration: 0:23.

Operating Instructions

Height Adjustment

The gazebo offers three adjustable heights: 8.7 feet, 9 feet, and 9.4 feet. To adjust the height, locate the securing buttons on each leg. Press the button and slide the leg to the desired height position until it clicks into place. Ensure all four legs are set to the same height for stability.




Image: Detailed view of the height adjustment mechanism, including the securing button and metal foot plate.

Mosquito Netting Usage

The gazebo includes four zippered mesh sidewalls. These can be installed or removed as needed. Zip them down for an open-air pavilion or zip them up to create a sheltered room that effectively blocks insects while maintaining air circulation.



Image: The gazebo with its mosquito netting providing an enclosed, insect-free space in a garden setting.

Maintenance

- **Cleaning:** Clean the canopy fabric and mesh sidewalls with mild soap and water. Do not use harsh chemicals or abrasive

cleaners. Allow all parts to dry completely before storage.

- **Storage:** When not in use, especially during off-season or anticipated severe weather, disassemble the gazebo and store it in its wheeled bag in a dry, protected area.
- **Inspection:** Periodically inspect the frame, fabric, and netting for any signs of wear, tear, or damage. Address any issues promptly to ensure continued safe use.

Troubleshooting

Gazebo is unstable:

Ensure all legs are fully extended and locked at the same height. Verify that sandbags are filled and properly attached, and that stakes and ropes are used to anchor the gazebo to the ground.

Canopy fabric does not fit correctly:

Check that the canopy top is oriented correctly and that the frame is fully extended before attempting to secure the fabric corners.

Difficulty with assembly/disassembly:

Ensure two people are assisting with the process. Refer to the setup instructions and video. If issues persist, contact customer support.

Specifications




Image: Dimensional overview of the gazebo, illustrating its 11x11 foot footprint, three height settings (8.5ft, 8.9ft, 9.2ft), and compact packed dimensions.

Feature	Detail
Brand	Bealife
Model Number	CT21
Material	Metal frame, PU fabric canopy
Color	Gray
Item Weight	19.48 Kilograms
Item Dimensions (L x W x H)	120"L x 120"W x 113"H (10ft x 10ft x 9.4ft)
Floor Area	121 Square Feet
Adjustable Heights	8.7 ft, 9 ft, 9.4 ft
UV Protection	Yes

Water Resistance Level	Water Resistant
Assembly Required	Yes

Warranty and Support

For any questions, concerns, or assistance with your Bealife 11x11 Pop Up Gazebo Tent, please contact Bealife customer support. Refer to your purchase documentation for specific warranty details and contact information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DWXL1G9R

More documents and user manuals: **https://manuals.plus/**