

Claiks CL-SDC-SZZSZ

Claiks 24-Inch Sit-Stand Workstation Instruction Manual

Model: CL-SDC-SZZSZ

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your Claiks 24-Inch Sit-Stand Workstation. Please read this manual thoroughly before use to ensure proper function and safety. This workstation is designed to convert a traditional desk into a height-adjustable ergonomic setup, promoting a healthier work environment.

SAFETY INFORMATION

- Ensure all components are securely fastened before placing equipment on the workstation.
- Do not exceed the maximum load capacity of 22 lbs (10 kg).
- Keep hands and fingers clear of moving parts during height adjustment.
- Place the workstation on a stable, level surface.
- Avoid placing liquids directly on the workstation surface to prevent damage.

SETUP AND ASSEMBLY

The Claiks 24-Inch Sit-Stand Workstation features tool-free assembly for quick setup.

1. **Unpack Components:** Carefully remove all parts from the packaging and verify against the parts list (not included in this manual, refer to packaging for full list).
2. **Attach to Desk:** Position the workstation on your existing desk. Utilize the dual fixation clamps to secure the unit firmly to the desk edge. Tighten the clamps until the workstation is stable and does not wobble.
3. **Place Monitor and Keyboard:** Place your monitor(s) on the upper platform and your keyboard and mouse on the lower tray. Ensure cables are routed safely and do not interfere with movement.



Figure 1: Workstation dimensions and maximum load capacity. The upper platform measures 23.6 inches by 13.6 inches, and the lower keyboard tray measures 23.6 inches by 9.8 inches. The maximum load is 22 lbs (10 kg).



Dual Fixation

Unparalleled Stability Reinforced



Pneumatic Height Adjustment

Ergonomic Excellence Redefined



Flexible Rotation

Max Maneuverability



Figure 2: Key features of the workstation. This image highlights the dual fixation clamps for stability, the pneumatic height adjustment mechanism, and the flexible rotation capability of the platforms.

OPERATING INSTRUCTIONS

The workstation allows for seamless transitions between sitting and standing positions.

- **Height Adjustment:** To adjust the height, gently press the levers located on the sides of the workstation. Apply slight upward or downward pressure to guide the platforms to your desired height. The upper platform adjusts from 13.2 inches to 19.7 inches, and the lower tray adjusts from 9.3 inches to 15.9 inches. Release the levers to lock the workstation in place.
- **Platform Rotation:** The platforms offer 180-degree rotation, allowing for flexible viewing angles and workspace configurations. Gently rotate the platforms to achieve the desired orientation.

More Flexible Usage

Not Limited to Fixed Lifting Paths



Figure 3: Flexible usage of the workstation. The platforms can be rotated to accommodate various setups and user preferences, not limited to a fixed lifting path.

Different Heights for All Ideas

Tailoring Workspaces to Every Vision



Figure 4: Workstations set at different heights. This image demonstrates the range of height adjustments available, allowing users to tailor their workspace for various tasks and ergonomic needs.

MAINTENANCE

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or solvents.
- **Inspection:** Periodically check all screws and clamps to ensure they remain tight and secure.
- **Gas Spring:** The pneumatic gas spring mechanism is designed for long-term use and generally requires no maintenance. If you notice any issues with height adjustment, refer to the troubleshooting section.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Workstation is difficult to raise or lower.	Obstruction or incorrect lever operation.	Ensure no objects are blocking the mechanism. When lowering, the unit may require a slight backward lean to clear the desk edge if positioned too close to a wall. Ensure both levers are fully engaged.

Problem	Possible Cause	Solution
Workstation feels unstable or wobbles.	Clamps are not sufficiently tightened or uneven load distribution.	Re-tighten the desk clamps securely. Distribute weight evenly across the platforms. Ensure the desk surface itself is stable.
Platforms do not rotate smoothly.	Friction or obstruction.	Check for any debris or obstructions around the rotation points. Ensure no cables are caught.

SPECIFICATIONS

Feature	Detail
Brand	Claiks
Model Number	CL-SDC-SZZSZ
Product Dimensions (D x W x H)	10.04" x 34.25" x 6.69"
Upper Platform Dimensions	23.6" x 13.6"
Lower Tray Dimensions	23.6" x 9.8"
Upper Platform Height Range	13.2" to 19.7"
Lower Tray Height Range	9.3" to 15.9"
Maximum Load Capacity	22 lbs (10 kg)
Color	Black
Material	Wood (Top), Metal (Base)
Special Feature	Adjustable Height, Flexible Rotation, Dual Fixation
Mounting Type	Tabletop Clamp
Item Weight	12.04 Kilograms

WARRANTY INFORMATION

This Claiks Sit-Stand Workstation is backed by a **5-year structural warranty**. This warranty covers defects in materials and workmanship under normal use. For specific terms and conditions, please refer to the warranty card included with your product or contact customer support.

CUSTOMER SUPPORT

For further assistance, technical support, or warranty claims, please contact Claiks customer service. Contact information can typically be found on the product packaging or on the official Claiks website.

Online Support: Visit the official Claiks website for FAQs and support resources.

Email Support: Refer to your product documentation for the customer service email address.