Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

kerry yoo K61

KerryYoo K61 Electric Drift Go-Kart Instruction Manual

Model: K61 | Brand: KerryYoo

Introduction

Thank you for choosing the KerryYoo K61 Electric Drift Go-Kart. This manual provides essential information for the safe assembly, operation, and maintenance of your new go-kart. Please read it thoroughly before use and retain it for future reference.

The KerryYoo K61 is designed to provide an exciting and immersive driving experience for children aged 6 to 12. Featuring a robust 24V 300W motor, adjustable speed modes, and specialized drift tires, it offers both thrilling performance and durable construction.



Image: The KerryYoo K61 Electric Drift Go-Kart in blue, showcasing its sleek design and ready for action.

Safety Information

Your safety and the safety of others are paramount. Always follow these guidelines:

- **Age and Weight Limits:** Suitable for children aged 6 to 12 years old. Maximum weight capacity is 110 lbs (50 kg).
- **Supervision:** Adult supervision is required at all times during operation.
- **Protective Gear:** Always wear a helmet, knee pads, and elbow pads.
- **Operating Environment:** Use on flat, dry surfaces away from traffic, pools, and other hazards. Avoid steep inclines or rough terrain.
- **Seat Belt:** Always ensure the adjustable seat belt is securely fastened before riding.

- **Battery Safety:** Do not allow the battery to fully drain. Recharge after each use or at least once per month during periods of irregular use to maximize battery life and prevent damage.

Package Contents

Upon unpacking, ensure all components are present and undamaged. Refer to the assembly video for a visual guide to all parts.

Video: Kerry Yoo 24V Go Kart installation video. This video provides a detailed step-by-step guide to unboxing and assembling your go-kart, including identifying all package contents.

Setup and Assembly

Assembly is required before first use. Follow the instructions carefully. For a visual guide, please refer to the 'Kerry Yoo 24V Go Kart installation video' in the Package Contents section.

1. **Unpack Components:** Carefully remove all parts from the packaging.
2. **Frame Assembly:** Connect the main frame sections as per the visual instructions in the assembly video.
3. **Steering Column Installation:** Secure the steering column to the main body.
4. **Steering Wheel Attachment:** Connect the steering wheel to the column, ensuring all wiring for controls is properly connected.
5. **Wheel Installation:** Attach the front and rear wheels, securing them with the provided fasteners. The rear wheels are designed for drifting.
6. **Seat Adjustment:** Adjust the seat to one of the three available positions (20.75" to 26.5") to comfortably fit the rider.
7. **Battery Connection:** Connect the battery terminals. Ensure a secure connection.
8. **Initial Charge:** Fully charge the go-kart before its first use.

Operating Instructions

Familiarize yourself with the controls before operating the go-kart.



Image: Close-up of the KerryYoo K61 Go-Kart's control panel, showing the power button, light switch, speed selector, and driving mode switch.

1. **Power On/Off:** Press the red power button on the control panel to turn the go-kart on or off.
2. **Lights:** Use the green/red switch to turn the LED headlights and brake lights on or off.
3. **Speed Modes:** Select between High and Low speed settings using the designated switch. The go-kart offers speeds between 4 and 8.5 MPH.
4. **Driving Modes:** Choose between 'Sport' and 'Drift' modes using the lever. 'Drift' mode utilizes the specialized rear tires for enhanced drifting capabilities.
5. **Acceleration and Braking:** Use the foot pedals for acceleration and braking.
6. **Steering:** Use the racing-style steering wheel to control direction.
7. **Audio System:** The built-in audio system supports USB, FM radio, and Bluetooth connectivity. Connect your device to play music during your ride.

Video: Kerry Yoo 24V Go Kart in action. This video demonstrates the go-kart's speed, drifting capabilities, and overall performance in various driving modes.

Maintenance

Regular maintenance ensures the longevity and optimal performance of your go-kart.

- **Battery Care:** To maximize battery life, avoid fully draining it. Recharge the battery after each use. If the go-kart is not used regularly, charge it at least once per month.
- **Cleaning:** Wipe down the go-kart with a damp cloth after use. Avoid using harsh chemicals or abrasive cleaners.
- **Storage:** Store the go-kart in a dry, cool place away from direct sunlight and moisture.
- **Tire Inspection:** Periodically check the tires for wear and tear. The high-density, wear-resistant PP foam rear tires do not require inflation.



Image: Visual reminder for battery maintenance, emphasizing regular charging to prolong battery life.

Troubleshooting

If you encounter issues with your go-kart, refer to the following common problems and solutions:

- **Go-Kart Not Moving:** Ensure the power button is on, the battery is charged, and all connections are secure. Check the forward/reverse button circuit.
- **Reduced Performance:** This may indicate a low battery charge. Recharge the battery fully.
- **Forward/Reverse Button Malfunction:** If the go-kart does not respond correctly to the forward/reverse button, the button itself or its wiring may be damaged.

Video: How to Test the Forward Button on a Go-Kart is Damaged. This video provides instructions on how to diagnose issues with the forward/reverse button circuit and what steps to take if it is damaged.

If troubleshooting steps do not resolve the issue, please contact KerryYoo customer support for assistance.

Specifications

Feature	Detail
Model	K61
Brand	KerryYoo
Product Dimensions (L×W×H)	48 x 30 x 21 inches
Item Weight	54 pounds
Recommended Age	6 years and up
Weight Capacity	110 lbs
Motor	24V 300W
Speed Range	4 to 8.5 MPH (4-speed modes)
Battery Life	40-70 minutes of driving range
Tire Type	Front EVA, Rear High-density PP foam
Connectivity	USB, FM Radio, Bluetooth

Warranty and Support

For warranty information, product support, or to inquire about replacement parts, please contact KerryYoo customer service directly through your purchase platform or the official KerryYoo website. Please have your purchase details and model number (K61) ready when contacting support.

© 2026 KerryYoo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DX1WCHP5

More documents and user manuals: **https://manuals.plus/**