

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Lenovo](#) /
- › [Lenovo Slim 7 14IMH9 Laptop User Manual](#)

Lenovo Slim 7 14IMH9

Lenovo Slim 7 14IMH9 Laptop User Manual

Model: Slim 7 14IMH9 (83D80000)

INTRODUCTION

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your Lenovo Slim 7 14IMH9 laptop. Please read this guide thoroughly to ensure optimal performance and longevity of your device.



Figure 1: Lenovo Slim 7 14IMH9 Laptop (Closed View)

SETUP

1. Unboxing and Initial Inspection

Carefully remove the laptop and all accessories from the packaging. Verify that all components are present:

- Lenovo Slim 7 14IMH9 Laptop
- 65W AC Adapter
- WWC 32GB USB Drive
- Documentation (this manual, warranty information)

2. Connecting to Power

Connect the 65W AC adapter to the laptop's USB-C Thunderbolt 4 port (either left or right side) and then to a power outlet. The battery will begin charging automatically.



Figure 2: Left Side Ports (HDMI, USB-C Thunderbolt 4)

3. Initial Power On and Windows 11 Pro Setup

Press the power button to turn on the laptop. Follow the on-screen instructions to complete the Windows 11 Pro setup. This includes selecting your region, connecting to a Wi-Fi network, and creating a user account.



Figure 3: Laptop Displaying Windows 11 Pro

4. Connecting to Wi-Fi

During the Windows setup, you will be prompted to connect to a wireless network. Select your network from the list and enter the password if required. The laptop supports Intel Wi-Fi 6E AX211 for fast and reliable wireless connectivity.

OPERATING YOUR LAPTOP

1. Touchscreen Functionality

The 14" WUXGA (1920 x 1200) display features multi-touch capabilities. You can interact with the operating system and applications using touch gestures similar to a tablet. The screen is glossy with an anti-fingerprint coating.

2. Keyboard and Touchpad

The laptop is equipped with a backlit keyboard for comfortable typing in various lighting conditions. The integrated touchpad supports multi-finger gestures for navigation.



Figure 4: Keyboard and Touchpad Layout

3. Ports and Connectivity

Your laptop offers a variety of ports for connecting external devices:

- **2x USB-C Thunderbolt 4 / USB4 40Gbps:** Supports power delivery, data transfer, and DisplayPort 1.4 for external monitors.
- **1x USB 3.2 Gen 1 (Always On and 5Gbps):** For connecting USB devices, with 'Always On' functionality to charge devices even when the laptop is off.
- **1x HDMI v2.1:** For connecting to external displays or projectors.
- **1x Headphone / microphone combo jack:** For audio input and output.



Figure 5: Right Side Ports (USB 3.2 Gen 1, Audio Jack)

4. Integrated Camera

The FHD 1080p + IR Camera with E-Shutter is located at the top of the display. The E-Shutter provides physical privacy. The IR camera supports Windows Hello for facial recognition login.

MAINTENANCE

1. Cleaning Your Laptop

To clean the display, use a soft, lint-free cloth lightly dampened with water or a screen cleaner. For the keyboard and chassis, use a soft, dry cloth. Avoid harsh chemicals or abrasive materials.

2. Battery Care

The laptop is equipped with a 65Wh Lithium-Ion battery. To maximize battery lifespan:

- Avoid extreme temperatures.
- Do not fully discharge the battery regularly.
- If storing the laptop for an extended period, ensure the battery is charged to approximately 50-60%.

3. Software Updates

Regularly update your Windows 11 Pro operating system and drivers to ensure optimal performance, security, and compatibility. You can check for updates via Windows Settings.

4. Storage Management

The 1TB NVMe M.2 SSD provides fast storage. Periodically review and delete unnecessary files to maintain free space and system performance.

TROUBLESHOOTING

This section addresses common issues you might encounter.

No Power / Laptop Not Turning On

- Ensure the AC adapter is securely connected to both the laptop and a working power outlet.
- Try a different power outlet.
- If the battery is completely drained, it may take a few minutes of charging before the laptop can power on.

Display Issues

- If the screen is blank, try pressing the function key (Fn) + F2 (or the display toggle key) to ensure the display is not turned off.
- Adjust screen brightness using the function keys.
- If connected to an external monitor, ensure the correct display output mode is selected (Fn + F7 or similar).

Wi-Fi Connectivity Problems

- Check if Wi-Fi is enabled in Windows settings.
- Restart your router and modem.
- Ensure you are within range of your Wi-Fi network.

Slow Performance

- Close unnecessary applications running in the background.
- Check for and install any pending Windows updates.
- Ensure your 1TB NVMe M.2 SSD has sufficient free space.

SPECIFICATIONS

Below are the key technical specifications for the Lenovo Slim 7 14IMH9 laptop:

Feature	Specification
Model Name	Slim 7 14IMH9
Item Model Number	83D80000

Feature	Specification
Display	14" WUXGA (1920 x 1200) Touchscreen, 400 nits, Glossy / Anti-fingerprint, 100% DCI-P3, Eyesafe, Dolby Vision, DisplayHDR True Black 500
Processor	Intel Core Ultra 7 155H (Up to 4.8 GHz, 16-Core, 22 Threads)
Graphics	Intel Arc Graphics (Integrated)
RAM	16GB LPDDR5 7467 MHz
Storage	1TB NVMe M.2 SSD
Operating System	Windows 11 Pro
Wireless Connectivity	Intel Wi-Fi 6E AX211 (2x2), Bluetooth 5.3
Ports	2x USB-C Thunderbolt 4, 1x USB 3.2 Gen 1, 1x HDMI v2.1, 1x Headphone/Mic Combo Jack
Camera	FHD 1080p + IR Camera with E-Shutter
Battery	65Wh Lithium-Ion (Up to 6 hours average battery life)
Dimensions (LxWxH)	12.29 x 8.69 x 0.6 inches
Weight	3.15 lbs (Item Weight: 7.01 pounds as per some listings, actual product weight is 3.15 lbs)
Color	Luna Grey

WARRANTY AND SUPPORT

Your Lenovo Slim 7 14IMH9 laptop comes with a standard manufacturer's warranty. Please refer to the warranty documentation included with your product for specific terms and conditions.

For technical support, service, or additional information, please visit the official Lenovo support website or contact their customer service. You can find contact details and support resources on the Lenovo website.

Online Support: support.lenovo.com