

24" White Ligh

LED Plafondlamp with Crystal Shade User Manual

Model: 24" White Ligh

1. INTRODUCTION

This manual provides detailed instructions for the safe installation, operation, and maintenance of your new Generic LED Plafondlamp with Crystal Shade. This modern flush mount ceiling light is designed to enhance various indoor spaces such as living rooms, bedrooms, dining rooms, hotels, and hallways.

The lamp features a stylish and durable design, crafted with high-quality iron paint lamp body and a high-transmittance acrylic lampshade. It offers adjustable three-tone light options (white, warm, natural) to suit different moods and environments.



Figure 1: The LED Plafondlamp with Crystal Shade installed in a room, showcasing its modern design and bright illumination.

2. IMPORTANT SAFETY INFORMATION

Please read all safety instructions carefully before installation and use. Failure to follow these instructions may result in electric shock, fire, or other injuries.

- For a safe and secure installation, ensure that the electrical box to which this fixture will be mounted is properly attached to a structural member of the building.
- All wires are connected. When unpacking, be careful not to pull with wires as a bad connection may result.
- Do not connect electricity until your fixture is fully assembled.
- To reduce the risk of fire, electrical shock, or personal injury, always turn off and unplug the fixture and allow it to cool prior to replacing the light bulb (if applicable).
- Do not touch the bulb when the fixture is turned on or look directly at the lit bulb. Keep flammable materials away from the lit bulb.

3. PRODUCT SPECIFICATIONS

| Feature | Detail |
|---------------------------|--|
| Category | Ceiling Lights / Ceiling Lamp |
| Usage | Indoor Lighting, Living room, Dining Room, Hotel, Restaurant, Bedroom, Hallway |
| Style | Modern / Simple / Creative |
| Fixture Height | 4.5 inches (11 cm) |
| Fixture Width (24" Model) | 24 inches (60 cm) |
| Bulb Type | LED |
| Bulb Base | SMD |
| Number of Lights | 1 (Integrated LED) |
| Wattage (24" Model) | 60W |
| Voltage | AC110-120V |
| Power Source | Direct Wired Electric |
| Material | Metal + Crystal + Acrylic |
| Color | White |

Product size



24"/ 32"/40"
60/80/100cm

Figure 2: Product dimensions for various sizes, including the 24-inch model.

4. SETUP AND INSTALLATION

Installation of this ceiling light requires basic electrical knowledge. If you are unsure, it is recommended to consult a qualified electrician.

Before You Begin:

1. **Turn off Power:** Always disconnect power at the circuit breaker or fuse box before beginning installation to prevent electric shock.
2. **Inspect Components:** Carefully unpack all components and inspect for any damage. Ensure all parts listed in the packaging are present.
3. **Prepare Wiring:** Ensure the electrical box is securely mounted to a structural member of the building.

Installation Steps:

1. **Mounting Bracket:** Attach the mounting bracket to the electrical box in the ceiling using the provided screws. Ensure it is firmly secured.
2. **Wire Connections:** Connect the household electrical wires to the fixture's wires according to standard electrical codes (e.g., black to black, white to white, ground to ground). Use wire nuts to secure connections. Ensure all connections are tight and no bare wires are exposed.
3. **Attach Fixture:** Carefully lift the light fixture and align it with the mounting bracket. Secure the fixture to the bracket using the screws provided. Ensure the fixture is flush against the ceiling.

4. **Final Assembly:** If there are any decorative elements or covers, attach them now according to the specific design of your lamp.

Note: Do not connect electricity until your fixture is fully assembled.



Figure 3: Detail of the crystal elements, which should be handled carefully during installation.

5. OPERATING INSTRUCTIONS

Once installed and power is restored, your LED Plafondlamp is ready for use.

Turning On/Off:

Operate the light using a standard wall switch connected to the fixture's circuit.

Adjusting Light Tones (Tri-Color Models Only):

For models with tri-color dimming (not applicable to the 24" White Light model), the light tone can typically be adjusted by toggling your wall switch. Each quick flip of the switch will cycle through the available light temperatures: White Light, Warm Light, and Natural Light.



Figure 4: Example of the lamp displaying different light temperatures (if applicable to your model).

6. MAINTENANCE

Regular maintenance will help preserve the appearance and functionality of your LED Plafondlamp.

Cleaning:

- **Always turn off power** to the fixture and allow it to cool completely before cleaning.
- Wipe the fixture with a soft, dry, or slightly damp cloth.
- Do not use abrasive cleaners, solvents, or polishes as they may damage the finish or acrylic components.
- For crystal elements, a mild glass cleaner can be applied to a cloth (not directly to the crystals) and then wiped gently.

Bulb Replacement:

This fixture uses integrated LED technology, meaning the LED light source is built into the unit and is not designed for user replacement. The LEDs are designed for a long lifespan under normal operating conditions.

7. TROUBLESHOOTING

If you encounter issues with your LED Plafondlamp, refer to the following common problems and solutions:

| Problem | Possible Cause | Solution |
|---|--|---|
| Light does not turn on. | No power to the fixture. Loose wire connection. Faulty wall switch. | Check circuit breaker/fuse. Ensure all wire connections are secure (turn off power first!). Test the wall switch with another device or replace it. |
| Light flickers or dims. | Loose wire connection. Incompatible dimmer switch (if applicable). Voltage fluctuations. | Check wire connections (turn off power first!). Ensure you are using a compatible LED dimmer switch if a dimmer is installed. Consult an electrician if voltage issues are suspected. |
| Light color does not change (Tri-Color models). | Not a tri-color model. Incorrect operation. | Verify your model supports tri-color adjustment. The 24" White Light model does not. Ensure you are toggling the wall switch quickly to cycle through colors. |

If the problem persists after trying these solutions, please contact customer support.

8. CUSTOMER SUPPORT

For any questions, concerns, or assistance with your LED Plafondlamp, our customer service team is available 24/7 to ensure a satisfactory experience.

Please refer to your purchase documentation or the retailer's website for specific contact information.

