JVC LT-43NQ7155

JVC QLED Smart 43-Inch Android Television User Manual

Model: LT-43NQ7155

Introduction Safety Contents Setup Operation Maintenance Troubleshooting Specifications Warranty

1. Introduction

Welcome to the user manual for your JVC QLED Smart 43-Inch Android Television, Model LT-43NQ7155. This manual provides essential information for the safe and efficient use of your new television. Please read it thoroughly before operating the device and retain it for future reference.

The JVC LT-43NQ7155 is a 43-inch QLED Smart TV designed to enhance your home entertainment. It features QLED technology for vibrant colors and sharp contrasts, a Full HD resolution of 3840 x 2160 for detailed images, and operates on the ASOP system for a user-friendly interface. With 1GB RAM and 8GB internal storage, it ensures smooth performance. Connectivity includes three HDMI ports and two USB ports. Its sleek black design integrates well into any living space.

2. Important Safety Information

- **Electrical Safety:** Ensure the power cord is securely plugged into a grounded outlet. Do not overload power strips. Avoid placing the TV in damp environments.
- **Ventilation:** Do not block ventilation openings. Allow adequate space around the TV for proper airflow to prevent overheating.
- **Placement:** Place the TV on a stable, level surface or mount it securely to a wall. Keep it away from direct sunlight, heat sources, and strong magnetic fields.
- **Cleaning:** Disconnect the power cord before cleaning. Use a soft, dry cloth. Avoid liquid cleaners or aerosols directly on the screen or cabinet.
- **Children:** Supervise children to prevent them from climbing on the TV or stand. Small parts can be a choking hazard.
- **Servicing:** Do not attempt to service this product yourself. Refer all servicing to qualified service personnel.

3. Package Contents

Please check that all items are present and in good condition:

- JVC QLED Smart 43-Inch Android Television (Model LT-43NQ7155)
- Remote Control
- Power Cord
- TV Stand (2 pieces)
- Screws for TV Stand
- User Manual (this document)

4. Setup Instructions

4.1 Attaching the TV Stand

1. Carefully place the TV screen-down on a soft, clean surface to prevent damage.
2. Align each stand piece with the corresponding slots on the bottom of the TV.
3. Secure the stands using the provided screws. Ensure they are tightened firmly.
4. Carefully lift the TV to its upright position on a stable surface.



Figure 4.1: Front view of the JVC 43-inch QLED Smart Android Television with its stand attached. This image illustrates the television's appearance when set up on a flat surface using the included stand, showcasing its slim bezels and the JVC logo at the bottom center.

4.2 Wall Mounting (Optional)

If you choose to wall mount your television, ensure you use a VESA-compatible wall mount kit (not included) that supports the TV's weight and size. Consult a professional for installation to ensure safety and proper mounting.



Figure 4.2: Rear view of the JVC 43-inch QLED Smart Android Television. This image highlights the back panel, including the pattern for VESA wall mounting brackets and the location of some rear-facing input/output ports.

4.3 Connecting Power

Plug the power cord into the TV's power input, then plug the other end into a wall outlet. The TV will enter standby mode.

4.4 Initial Setup Wizard

Upon first power-on, the TV will guide you through an initial setup wizard. Follow the on-screen prompts to:

- Select your preferred language.
- Connect to a Wi-Fi network.
- Sign in with your Google Account to access Android TV features and apps.
- Scan for available TV channels (if connecting an antenna).
- Agree to terms and conditions.

5. Operating Instructions

5.1 Remote Control Overview

The included remote control allows you to navigate the TV's interface and access various functions. Key features include:

- **Power Button:** Turns the TV on/off or to standby.
- **Navigation Pad (Up/Down/Left/Right/OK):** For menu navigation and selection.
- **Back/Home Buttons:** Return to previous screen or home screen.
- **Volume Up/Down:** Adjusts audio volume.
- **Channel Up/Down:** Changes TV channels.

- **Quick-Access Buttons:** Dedicated buttons for popular streaming services like Netflix and YouTube for direct access.
- **Google Assistant Button:** Activates voice control.

5.2 Navigating Android TV

The Android TV home screen provides access to your installed apps, live TV, and recommended content. Use the navigation pad on your remote to browse and select options.

5.3 Voice Control with Google Assistant

Press the Google Assistant button on your remote and speak into the microphone to:

- Search for movies, shows, or information.
- Control TV functions (e.g., "Change channel to 5", "Open Netflix").
- Get answers to questions.
- Control compatible smart home devices.

5.4 Connecting External Devices

Your TV is equipped with multiple ports for connecting external devices:

- **HDMI Ports (x3):** For connecting Blu-ray players, gaming consoles, set-top boxes, etc.
- **USB Ports (x2):** For connecting USB drives to play media files or power small devices.
- **Wi-Fi:** For wireless internet connectivity.





Figure 5.4: Side view of the JVC 43-inch QLED Smart Android Television. This image displays the television's profile and the location of conveniently accessible side-mounted ports, such as HDMI and USB, for connecting external devices.

6. Product Features

The JVC LT-43NQ7155 offers a range of advanced features for an enhanced viewing experience:

- **QLED Display Technology:** Delivers vibrant colors, improved brightness, and superior contrast compared to traditional LED displays.
- **4K Ultra HD Resolution (3840 x 2160):** Provides four times the detail of Full HD, resulting in exceptionally clear and crisp images.
- **Android TV Operating System:** Offers a smart and intuitive interface with access to a vast library of apps, games, and streaming services via the Google Play Store.
- **Integrated Google Assistant:** Allows for hands-free control and smart home integration using voice commands.
- **Multiple Connectivity Options:** Includes 3 HDMI ports for various external devices and 2 USB ports for media playback.
- **Wi-Fi Connectivity:** Seamless access to online content and network features.
- **Edgeless Design:** Ultra-thin bezels maximize the screen area for an immersive visual experience.



Figure 6.1: Angled front view of the JVC 43-inch QLED Smart Android Television. This image showcases the television's display quality and its slim design, with a vibrant picture of two storks on the screen, demonstrating its QLED capabilities.

7. Maintenance

7.1 Cleaning the Screen

To clean the screen, first unplug the TV. Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, lightly dampen the cloth with water or a specialized screen cleaner (ensure it's safe for QLED displays) and wipe carefully. Do not spray liquids directly onto the screen.

7.2 Cleaning the TV Body

Wipe the TV's body and stand with a soft, dry cloth. Avoid using abrasive cleaners, waxes, or solvents as they can damage the finish.

8. Troubleshooting

Before contacting customer support, please refer to the following common issues and solutions:

Problem	Possible Cause	Solution
No power	Power cord not connected; outlet not working.	Ensure power cord is securely plugged in. Test the outlet with another device.
No picture, but sound is present	Incorrect input source selected; faulty HDMI cable.	Press the "Input" button on the remote to select the correct source. Check/replace HDMI cable.
No sound, but picture is present	Volume muted or too low; external audio system issue.	Unmute or increase volume. Check connections to external audio devices.
Remote control not working	Dead batteries; obstruction; remote not paired.	Replace batteries. Remove obstructions. Re-pair remote if it's a Bluetooth model (refer to TV settings).
Cannot connect to Wi-Fi	Incorrect password; router issue; TV too far from router.	Verify Wi-Fi password. Restart router. Move TV closer to router or use a Wi-Fi extender.

9. Technical Specifications

Feature	Specification
Brand	JVC
Model Number	LT-43NQ7155
Display Size	43 Inches
Display Technology	QLED
Resolution	3840 x 2160 (4K Ultra HD)
Operating System	Android (ASOP system)
Refresh Rate	60 Hz
HDMI Ports	3
USB Ports	2
Connectivity Technology	HDMI, USB, Wi-Fi
Color	Black
Product Dimensions	21.4D x 96.8W x 62.2H centimetres
Included Components	1 x JVC Qled Smart 43-Inch Android Television, Black

10. Warranty and Support

10.1 Manufacturer's Warranty

This JVC QLED Smart 43-Inch Android Television comes with a**1 Year Manufacturer's Warranty** from the date of purchase. This warranty covers manufacturing defects and faults under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or natural disasters.
Please retain your proof of purchase for warranty claims.

10.2 Customer Support

For technical assistance, warranty claims, or service inquiries, please contact JVC customer support through their official website or the contact information provided with your purchase documentation.

11. Disposal Information

Do not dispose of this product with general household waste. Electronic products contain materials that can be harmful to the environment if not disposed of properly. Please recycle this product at a designated collection point for electronic waste, or return it to your retailer for proper disposal. Contact your local authorities for information on electronic waste recycling programs in your area.

© 2025 JVC. All rights reserved. Model: LT-43NQ7155

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question