

Nintieue FL16886

Nintieue Dimmable Arc Floor Lamp (Model FL16886) User Manual

Your guide to assembly, operation, and care.

INTRODUCTION

Thank you for choosing the Nintieue Dimmable Arc Floor Lamp. This manual provides essential information for the safe and efficient use of your new lamp. Please read these instructions carefully before assembly and operation, and retain them for future reference.

IMPORTANT SAFETY INSTRUCTIONS

- Ensure the power is disconnected before assembly, disassembly, or cleaning.
- Use only the specified bulb type and wattage. Do not exceed 60W for E26 base bulbs.
- Place the lamp on a stable, level surface to prevent tipping. The heavy base is designed for stability.
- Keep the lamp away from water or other liquids.
- Do not operate the lamp with a damaged cord or plug.
- This lamp is for indoor use only.

PACKAGE CONTENTS

Verify that all components are present before beginning assembly:

- Lamp Pole Sections (multiple)
- Lamp Base
- Lamp Head with Socket
- Lampshade (rolled or pre-assembled)
- E26 LED Edison Bulb (1000 Lumens, 5000K Daylight)
- Rotary Dimmer Switch (integrated)
- Power Cord (5.9 ft)

SETUP AND ASSEMBLY

Follow these steps to assemble your Nintue Dimmable Arc Floor Lamp:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface.
2. **Assemble the Pole:** Screw the individual pole sections together clockwise until secure. Ensure the power cord runs freely through the pole.
3. **Attach the Base:** Securely attach the heaviest pole section to the lamp base by screwing it clockwise. The base is weighted (6.6 lbs) for stability.
4. **Attach the Lamp Head:** Screw the lamp head onto the top pole section.
5. **Assemble the Lampshade:** If the lampshade is rolled, unroll it and attach it to the metal rings using the provided clips or Velcro. Then, secure the assembled lampshade to the lamp head.
6. **Install the Bulb:** Carefully screw the included E26 LED Edison bulb into the lamp socket. Ensure it is tightened but do not overtighten.
7. **Connect to Power:** Plug the 5.9 ft power cord into a standard 120V electrical outlet.



Figure 1: Key components of the Nintue Dimmable Arc Floor Lamp.



Figure 2: Detail of the natural linen lampshade.

OPERATING INSTRUCTIONS

Your Nintue Dimmable Arc Floor Lamp offers versatile lighting options:

- **Dimmable Function:** The lamp features a convenient rotary switch located on the pole. Rotate the knob clockwise to turn the lamp on and increase brightness from 0% to 100%. Rotate counter-clockwise to dim the light and turn it off. This stepless dimming allows for precise light adjustment.
- **Adjustable Lamp Head:** The lamp head is designed for flexibility. It can be rotated 270° horizontally and tilted 90° vertically. Adjust the lampshade to direct light precisely where needed for reading, working, or ambient lighting.



Figure 3: Stepless dimming capability from 15% to 100% brightness.



Figure 4: Flexible lamp head with 270° horizontal and 90° vertical rotation.

MAINTENANCE

- **Cleaning:** Always unplug the lamp before cleaning. Use a soft, dry cloth to wipe down the lamp pole and base. For the lampshade, a soft brush or a slightly damp cloth can be used to remove dust. Avoid abrasive cleaners or solvents.
- **Bulb Replacement:** The lamp comes with a long-lasting LED bulb (25,000 hours lifespan). When replacement is needed, ensure the lamp is unplugged and the bulb has cooled. Use an E26 base bulb with a maximum wattage of 60W.



Figure 5: Energy-efficient LED bulb included with the lamp.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not turn on.	Power cord not fully plugged in; bulb loose or faulty; power outlet not working.	Check power cord connection; tighten or replace bulb; test outlet with another device.
Light flickers or dims unexpectedly.	Bulb incompatible with dimmer; loose bulb connection; faulty dimmer switch.	Ensure a dimmable LED bulb is used; tighten bulb; contact customer support if flickering persists.
Lamp is unstable.	Pole sections not fully tightened; lamp placed on uneven surface.	Ensure all pole sections are securely screwed together; place lamp on a flat, stable surface.

SPECIFICATIONS

- **Model Name:** FL16886
- **Brand:** Nintiue
- **Product Dimensions:** 12"D x 12"W x 65"H
- **Item Weight:** 10.28 pounds
- **Material:** Metal (Base), Linen (Shade)
- **Finish Type:** Matte
- **Shade Color:** Blue
- **Light Source Type:** LED
- **Bulb Base:** E26 Medium

- **Wattage:** 11 watts (included bulb)
- **Voltage:** 120 Volts
- **Special Feature:** Dimmable (0-100%)
- **Switch Type:** Rotary
- **Power Source:** Corded Electric (5.9 ft cord)
- **Indoor/Outdoor Usage:** Indoor

WARRANTY AND SUPPORT

Nintue offers a **3-year quality warranty** for this product. If your lamp has any defect or stops working within 3 years of purchase, please contact Nintue customer service for troubleshooting assistance or a replacement product. We are committed to ensuring your satisfaction.

For support, please refer to the contact information provided with your purchase or visit the official Nintue website.

© 2025 Nintue. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question