

Akitas V10A

Akitas V10A Cordless Vacuum Cleaner User Manual

Model: V10A

1. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using your Akitas V10A Cordless Vacuum Cleaner. Retain this manual for future reference.

- This appliance is for household use only. Do not use outdoors or on wet surfaces.
- Do not allow children to operate the vacuum cleaner. Close supervision is necessary when used near children.
- Do not pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use without the dust cup and/or filters in place.
- Turn off the appliance before connecting or disconnecting the motorized brush, extension tubes, or other accessories.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not handle the charger or appliance with wet hands.
- If the charging cable is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.
- Store the appliance indoors in a cool, dry place.

2. PRODUCT OVERVIEW

The Akitas V10A is a versatile 2-in-1 cordless vacuum cleaner designed for efficient cleaning of various surfaces. It features a powerful motor, multiple suction modes, and a tangle-free brush with LED lighting.

Package Contents

- Akitas V10A Handheld Cordless Vacuum Unit

- Motorized Brush Head with Green LED
- 2-in-1 Crevice Tool
- 2 Extension Tubes
- Wall Mount
- Charger
- Integrated HEPA Filter + 1 Extra HEPA Filter



Figure 2.1: Akitas V10A Cordless Vacuum Cleaner with all included accessories, including the main unit, motorized brush, extension tubes, crevice tool, wall mount, charger, and two HEPA filters.

Key Features

- **Powerful Suction:** 450W digital brushless BLDC motor delivers up to 45,000 Pa suction for deep cleaning.
- **Long Runtime:** Integrated 8-cell lithium battery provides up to 60 minutes in ECO mode, 25 minutes in Normal mode, and 10 minutes in Max mode.
- **Lightweight Design:** Weighs 2.15 kg (full unit) and approximately 1.6 kg in handheld mode for easy maneuverability.
- **Tangle-Free Brush:** Motorized turbo brush designed to prevent hair entanglement, equipped with green LED lighting to illuminate hidden dust.

- **2-in-1 Versatility:** Easily converts from a stick vacuum to a handheld vacuum for various cleaning tasks.
- **Advanced Filtration:** Features a washable HEPA filter for capturing fine dust and allergens.



Figure 2.2: Illustration of the Akitas V10A's 450W BLDC motor, highlighting its powerful suction capability of 45,000 Pa.



Figure 2.3: Diagram showing the 8-cell battery and its approximate runtimes: Max Mode (≤10 mins), Normal Mode (≤25 mins), Eco Mode (≤60 mins). Charging time is 4-5 hours.



Figure 2.4: Comparison illustrating the tangle-free design of the Akitas V10A brush head, equipped with green LED lights to reveal hidden dirt on floors.

3. SETUP AND ASSEMBLY

3.1 Assembling the Vacuum

1. **Attach the Extension Tube:** Insert one end of an extension tube into the main handheld vacuum unit until it clicks securely into place.
2. **Attach the Motorized Brush Head:** Connect the motorized brush head to the other end of the extension tube. Ensure it clicks firmly.
3. **For Handheld Use:** To use as a handheld vacuum, attach the desired accessory (e.g., 2-in-1 crevice tool) directly to the main handheld unit.



Figure 3.1: The Akitas V10A in handheld configuration, demonstrating its lightweight design (approx. 1.6 kg) for easy overhead cleaning.

3.2 Charging the Battery

Before first use, fully charge the vacuum cleaner for 4-5 hours.

- Connect the charger to a power outlet.
- Plug the charging cable into the charging port on the main handheld unit.
- The battery indicator lights will show the charging status. Once fully charged, the lights will indicate completion.

3.3 Installing the Wall Mount

The included wall mount allows for convenient storage and charging.

1. Choose a suitable location near a power outlet.
2. Mark the drilling points for the wall mount.
3. Drill holes and insert wall plugs (if necessary).
4. Secure the wall mount to the wall using screws.
5. Hang the vacuum cleaner on the wall mount for storage and charging.



Figure 3.2: Overview of the Akitas V10A components, including the wall mount and charger, demonstrating how the vacuum can be stored and charged.

4. OPERATING INSTRUCTIONS

4.1 Powering On/Off and Suction Modes

- **Power On:** Press the power button on the handle to turn on the vacuum cleaner. It will start in ECO mode.
- **Change Suction Mode:** Press the mode button to cycle through ECO, Normal, and Max suction modes.
- **Power Off:** Press the power button again to turn off the vacuum cleaner.

4.2 Using the Vacuum

The Akitas V10A can be used in two main configurations:

- **Stick Vacuum:** Ideal for cleaning floors (carpets, hard floors) with the motorized brush head and extension tubes. The green LED lights on the brush head will illuminate dust and debris.
- **Handheld Vacuum:** Perfect for cleaning furniture, car interiors, stairs, and tight spaces. Attach the 2-in-1 crevice tool directly to the main unit for these tasks.




Figure 4.1: The Akitas V10A demonstrating its versatility for cleaning various areas of a home, including floors, upholstery, and high-reach spots.

5. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

5.1 Emptying the Dustbin

Empty the dustbin after each use or when the MAX fill line is reached.

1. Ensure the vacuum is turned off.

2. Locate the dustbin release button, usually near the bottom of the main unit.
3. Press the button to open the dustbin flap and empty contents into a trash can.
4. Close the dustbin flap securely.



Figure 5.1: A user demonstrating the one-handed dustbin emptying feature of the Akitas V10A, showing debris falling into a waste bin.

5.2 Cleaning the HEPA Filter

The HEPA filter should be cleaned regularly (e.g., monthly, depending on usage) and replaced every 3-6 months.

1. Twist and pull to remove the dustbin from the main unit.
2. Remove the HEPA filter from the dustbin.
3. Tap the filter gently to remove loose dust.
4. Rinse the filter under cold running water until the water runs clear. Do not use detergent.
5. Allow the filter to air dry completely for at least 24 hours before reinserting. Do not use a dryer or direct heat.
6. Reassemble the filter and dustbin, then reattach to the main unit.

5.3 Cleaning the Brush Roll

Although designed to be tangle-free, occasional cleaning of the brush roll may be necessary.

1. Ensure the vacuum is turned off and disconnected from the extension tube.
2. Locate the release tab on the side of the motorized brush head.
3. Open the cover and remove the brush roll.
4. Use scissors or a brush to remove any tangled hair or debris.
5. Reinsert the brush roll and close the cover securely.

6. TROUBLESHOOTING

If you encounter issues with your Akitas V10A, refer to the following table:

Problem	Possible Cause	Solution
Vacuum does not turn on	Battery is not charged Power button not pressed correctly	Charge the battery fully Ensure the power button is pressed firmly

Problem	Possible Cause	Solution
Low suction power	Dustbin is full Filter is clogged Hose/nozzle is blocked	Empty the dustbin Clean or replace the HEPA filter Check and clear any blockages in the hose or brush head
Brush roll not spinning	Brush roll is tangled Brush head is blocked Brush head not properly attached	Clean hair/debris from brush roll Check for obstructions in the brush head Ensure brush head is securely connected
Short battery runtime	Battery not fully charged Operating in Max mode frequently Battery degradation	Ensure battery is fully charged (4-5 hours) Use ECO or Normal mode for longer runtime Contact customer support if battery life significantly decreases over time

7. SPECIFICATIONS

Feature	Specification
Brand	Akitas
Model	V10A
Motor Power	450W BLDC Digital Motor
Suction Power	Up to 45,000 Pa
Voltage	30 Volts
Battery Type	8-cell Lithium Battery
Runtime (ECO/Normal/Max)	Up to 60 min / 25 min / 10 min
Charging Time	4-5 hours
Item Weight	2.15 kg
Dimensions (L x W x H)	28 x 15 x 117 cm
Filter Type	Washable HEPA Filter
Special Features	Motorized Brush, LED Headlight, Tangle-Free, Cordless
Surface Recommendation	All Floors

8. WARRANTY AND SUPPORT

Akitas products are manufactured to high-quality standards. For information regarding warranty coverage, please refer to the warranty card included with your purchase or visit the official Akitas website.

If you require technical assistance, have questions about your product, or need to order replacement parts, please contact Akitas Customer Support. Contact details can typically be found on the product packaging, the official Akitas website, or through your retailer.

When contacting support, please have your product model (V10A) and purchase information readily available.

© 2025 Akitas. All rights reserved.


Related Documents - V10A

	<p>Akitas V8 22.2v Cordless Vacuum Cleaner User Manual</p> <p>User manual for the Akitas V8 22.2v 150w 3-in-1 Cordless Upright Handheld Stick Vacuum Cleaner. Includes assembly, operation, and maintenance instructions.</p>
	<p>Akitas V8 Cordless Vacuum Cleaner Instruction Manual</p> <p>Comprehensive instruction manual for the Akitas V8 cordless vacuum cleaner, covering assembly, operation, maintenance, troubleshooting, and warranty information. Includes technical parameters and parts list.</p>
	<p>Akitas S12 Handy VAC: Instruction Manual and User Guide</p> <p>Learn how to use, assemble, and maintain your Akitas S12 2-in-1 Handy VAC with this comprehensive instruction manual. Includes safety precautions and troubleshooting tips.</p>
	<p>Akitas U10 Stickvac User Manual - Cordless Vacuum Cleaner Guide</p> <p>This user manual provides comprehensive guidance for the Akitas U10 Stickvac, covering its features, specifications, safe operation, assembly, and maintenance procedures for optimal home cleaning.</p>

Akitas®

V10 Cordless Stick Vacuum Cleaner

Seamlessly alternates between 3 modes
Wireless operation offers greater versatility



AU

[Akitas V10 Cordless Stick Vacuum Cleaner: User Manual, Features, and Warranty](#)

Comprehensive guide to the Akitas V10 Cordless Stick Vacuum Cleaner, covering features, specifications, operation, maintenance, troubleshooting, and warranty information.



[Manuel de l'utilisateur Aspirateur Balai sans Fil Akitas V8](#)

Ce manuel fournit des instructions détaillées pour l'utilisation et l'entretien de l'aspirateur balai sans fil Akitas V8. Découvrez ses fonctionnalités 3-en-1, sa puissance de 150W et sa batterie lithium rechargeable pour un nettoyage efficace de tous types de sols et poils d'animaux.