

Daewoo DGC-S965HDFP

Daewoo Gas Cooker DGC-S965HDFP User Manual

Model: DGC-S965HDFP

1. INTRODUCTION

This manual provides essential instructions for the safe and efficient operation, installation, and maintenance of your Daewoo Gas Cooker, model DGC-S965HDFP. Please read this manual thoroughly before using the appliance and retain it for future reference. Proper use and care will ensure optimal performance and extend the lifespan of your cooker.

2. IMPORTANT SAFETY INFORMATION

Always follow basic safety precautions when using this appliance to reduce the risk of fire, electric shock, burns, or injury. Keep this manual accessible for quick reference.

- **Gas Safety:** Ensure proper ventilation. Do not store or use flammable materials near the cooker. If you smell gas, immediately turn off the gas supply, open windows, and do not operate any electrical switches. Contact a qualified technician.
- **Installation:** This appliance must be installed by a qualified technician in accordance with local regulations and the manufacturer's instructions. Ensure the gas supply and electrical connections are correct.
- **Children:** Keep children away from the appliance during operation and cooling. The surfaces can become very hot.
- **Hot Surfaces:** The oven and hob surfaces become hot during use. Use oven mitts or pot holders when handling hot items.
- **Cleaning:** Disconnect the appliance from the power supply before cleaning. Allow surfaces to cool before cleaning.
- **Maintenance:** Do not attempt to repair or modify any part of the appliance. Refer all servicing to qualified personnel.

3. PRODUCT OVERVIEW

The Daewoo DGC-S965HDFP is a freestanding gas cooker featuring a gas hob with cast iron grids and a 90-liter oven with two convection fans and dual oven glass. Below is an illustration of the cooker's main components.



Figure 1: Front view of the Daewoo Gas Cooker DGC-S965HDFP. This image displays the five gas burners with cast iron grids on the top hob, the control panel with knobs for burner and oven control, and the oven door with a large viewing window. The oven interior shows two racks.

Key Components:

- **Gas Hob:** Features 5 full-safety burners with auto-ignition and sturdy cast iron pan supports for various pot and pan sizes.
- **Control Panel:** Ergonomic push-button knobs for precise control of hob burners and oven functions.
- **Oven:** A spacious 90-liter capacity oven equipped with two convection fans for even heat distribution and faster cooking. Features dual oven glass for improved insulation and safety.
- **Oven Racks:** Two adjustable racks are included for versatile cooking options.
- **Glass Lid:** A protective glass lid covers the hob when not in use.

4. SETUP AND INSTALLATION

The Daewoo DGC-S965HDFP is a freestanding appliance. Proper installation is crucial for safety and performance. It is highly recommended that installation be performed by a certified gas and electrical technician.

4.1 Unpacking

- Carefully remove all packaging materials.
- Inspect the cooker for any signs of damage. If damaged, do not install or use the appliance and contact your retailer.
- Remove all accessories from inside the oven cavity.

4.2 Location Requirements

- Place the cooker on a stable, level surface.
- Ensure adequate clearance from adjacent walls and cabinets as specified by local building codes.
- The area must be well-ventilated.

4.3 Gas Connection

- The gas connection must comply with local regulations and be performed by a qualified gas fitter.
- Ensure the gas type (Natural Gas or LPG) matches the appliance's specifications. Conversion kits may be required for different gas types.
- Check for gas leaks using a soapy water solution; never use an open flame.

4.4 Electrical Connection

- Connect the appliance to a properly grounded electrical outlet.
- Ensure the voltage and frequency match the ratings on the appliance's data plate.
- Do not use extension cords or adapters.

4.5 Leveling the Cooker

Adjust the adjustable feet at the bottom of the cooker to ensure it is perfectly level. This is important for even cooking and stability.

5. OPERATING INSTRUCTIONS

5.1 Using the Gas Hob

1. **Ignition:** Push and turn the desired burner knob counter-clockwise to the maximum flame setting. The integrated auto-ignition system will spark.
2. **Flame Control:** Once the burner ignites, hold the knob for a few seconds to allow the thermocouple (safety device) to heat up. Release the knob. If the flame extinguishes, repeat the process.

3. **Adjusting Flame:** Turn the knob to adjust the flame size from maximum to minimum. Ensure the flame does not extend beyond the base of your cookware.
4. **Turning Off:** Turn the knob clockwise to the "OFF" position.

Note: The cast iron grids provide stable support for various cookware. Always ensure cookware is centered on the burner.

5.2 Using the Oven

1. **Preheating:** Turn the oven function knob to the desired cooking mode (e.g., conventional, fan-assisted). Turn the temperature knob to the required temperature. Allow the oven to preheat for approximately 10-15 minutes.
2. **Convection Fan:** The two convection fans ensure even heat distribution, reducing cooking times and providing consistent results. Select a cooking mode that utilizes the fan for optimal performance, especially for baking multiple items or larger dishes.
3. **Loading Food:** Place food on the oven racks. The 90-liter capacity and two racks allow for cooking large quantities or multiple dishes simultaneously.
4. **Monitoring:** The dual oven glass provides good insulation and allows for clear viewing of food without opening the door, helping to maintain a stable oven temperature.
5. **Turning Off:** Turn both the oven function and temperature knobs to the "OFF" position after cooking.

Caution: The oven door and interior surfaces will be hot during and after use. Use oven mitts when accessing the oven.

6. CLEANING AND MAINTENANCE

Regular cleaning and maintenance will keep your Daewoo Gas Cooker in optimal condition.

6.1 General Cleaning

- Always ensure the cooker is cool and disconnected from the power supply before cleaning.
- Use a soft cloth and mild detergent for exterior stainless steel surfaces. Avoid abrasive cleaners that can scratch the finish.
- Wipe up spills immediately to prevent staining.

6.2 Hob and Burners

- Remove the cast iron grids and burner caps/crowns. Wash them in warm soapy water, rinse, and dry thoroughly.
- Clean the burner bases and surrounding hob area with a damp cloth. Ensure burner ports are not blocked.
- Ensure all parts are completely dry before reassembling and using the hob.

6.3 Oven Interior

- Remove oven racks and clean them separately.
- Wipe the interior with a damp cloth and a mild oven cleaner (follow cleaner instructions).
- Avoid getting water into the fan motor or electrical components.

6.4 Oven Door Glass

- Clean the dual oven glass with a glass cleaner or warm soapy water.
- Do not use abrasive pads or harsh chemicals that could damage the glass surface.

7. TROUBLESHOOTING

Before contacting customer service, please refer to the following table for common issues and their potential solutions.

Problem	Possible Cause	Solution
Burner does not ignite.	No gas supply, power outage, clogged burner port, wet burner cap.	Check gas supply valve. Verify power connection. Clean burner ports. Ensure burner parts are dry.
Flame is uneven or yellow.	Clogged burner ports, incorrect gas pressure.	Clean burner ports. Contact a qualified technician to check gas pressure.
Oven not heating.	Power outage, incorrect settings, faulty igniter/heating element.	Check power supply. Ensure oven function and temperature knobs are set correctly. Contact service if issue persists.
Oven cooking unevenly.	Improper rack placement, blocked vents, faulty convection fan.	Ensure proper rack placement. Check for obstructions. Contact service if fan is not working.
Gas smell.	Gas leak.	Immediately turn off gas supply, open windows, and evacuate. Do not operate electrical switches. Contact emergency services and a qualified gas technician.

8. SPECIFICATIONS

Technical specifications for the Daewoo Gas Cooker DGC-S965HDFP:

Feature	Detail
Brand	Daewoo
Model Name	DGC-S965HDFP
Product Dimensions	60D x 90W x 85H centimeters
Installation Type	Freestanding
Oven Capacity	90 Liters
Burner Type	Gas
Number of Heating Elements (Burners)	5
Control Type	Knob
Convection Fan	2 Fans
Grids Material	Cast Iron
Oven Glass	Dual Oven Glass
Material Type	Stainless Steel
Item Weight	57 Kilograms
Country of Origin	Turkiye (as per product description)

9. WARRANTY AND SUPPORT





For warranty information, service requests, or technical support, please refer to the warranty card included with your product or contact Daewoo customer service. Ensure you have your model number (DGC-S965HDFP) and purchase date available when contacting support.


Customer Service: Please refer to your local Daewoo distributor or retailer for contact details.



© 2025 Daewoo. All rights reserved. Information in this manual is subject to change without notice.

Related Documents - DGC-S965HDFP

	<p>DAEWOO F96CGDTE19INM-PL Free Standing Cooker User Manual</p> <p>This user manual provides important safety information, usage guidelines, and maintenance instructions for the DAEWOO F96CGDTE19INM-PL free standing cooker. Learn about installation, operation, cleaning, and troubleshooting.</p>
	<p>DAEWOO Free Standing Cooker User Manual F6EV19SM2 F6EV19WM1</p> <p>User manual and safety instructions for the DAEWOO Free Standing Cooker models F6EV19SM2 and F6EV19WM1. Covers installation, operation, cleaning, maintenance, and technical specifications.</p>
	<p>Daewoo 6.5L Stainless Steel Slow Cooker SDA1788 User Manual</p> <p>User manual for the Daewoo 6.5L Stainless Steel Slow Cooker, model SDA1788. Includes safety instructions, operating guide, cleaning and maintenance, technical specifications, and recipes.</p>
	<p>Daewoo F96EIDTE19INM-PL Free Standing Cooker User Manual</p> <p>Comprehensive user manual for the Daewoo F96EIDTE19INM-PL free-standing cooker, covering safety instructions, installation, operation, cleaning, maintenance, troubleshooting, and technical specifications.</p>



[DAEWOO KOC-8H4T Microwave Oven Parts and Assembly Guide](#)

Detailed parts list and disassembly/assembly instructions for the DAEWOO KOC-8H4T microwave oven, including component descriptions and step-by-step guidance.



HANDLEIDING / MANUAL
DR-COOKER
MODEL: DR-COOKER

[Daewoo DRCOOKER Rice Cooker User Manual and Safety Guide](#)

Official user manual and safety instructions for the Daewoo DRCOOKER rice cooker. Includes parts list, operation guide, cleaning, maintenance, and 24-month warranty details.