

[Manuals.plus](#) /

> [JRL Professional](#) /

> JRL GHOST Professional Cordless Hair Clipper (Model 2020C-B) Instruction Manual

JRL Professional 2020C-B

JRL GHOST Professional Cordless Hair Clipper

MODEL: 2020C-B - INSTRUCTION MANUAL

1. Introduction

Thank you for choosing the JRL GHOST Professional Cordless Hair Clipper, Model 2020C-B. This advanced grooming tool is designed for precision and efficiency, featuring innovative technologies to enhance your cutting experience. Please read this manual thoroughly before use to ensure proper operation and maintenance.





Image 1.1: The JRL GHOST Professional Cordless Hair Clipper, Model 2020C-B.

2. Safety Information

To reduce the risk of electric shock, injury, or damage, always follow these basic safety precautions:

- Do not reach for an appliance that has fallen into water. Unplug immediately.
- Do not use while bathing or in a shower.
- Do not place or store appliance where it can fall or be pulled into a tub or sink.
- Always unplug this appliance from the electrical outlet immediately after using.
- Unplug this appliance before cleaning, removing, or replacing parts.
- Close supervision is necessary when this appliance is used by, on, or near children or individuals with certain disabilities.
- Use this appliance only for its intended use as described in this manual.
- Never operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been dropped or damaged.
- Keep the cord away from heated surfaces.

- Never drop or insert any object into any opening.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- Always attach plug to appliance first, then to outlet. To disconnect, turn all controls to OFF, then remove plug from outlet.

3. Package Contents

Your JRL GHOST Professional Cordless Hair Clipper package includes the following items:

- 1x JRL GHOST Professional Cordless Hair Clipper (Model 2020C-B)
- 1x Reset IQ Charging Dock
- 1x Screwdriver
- 1x Cleaning Brush
- 1x Lubricant Oil
- 1x Blade Protector
- 10x Comb Guards (1/2#, 1#, 1-1/2#, 2#, 3#, 4#, 5#, 6#, 7#, 8#)
- 1x US Plug (Charger Adapter)






Image 3.1: Rear view of the JRL GHOST clipper packaging, detailing included accessories.

4. Product Overview and Features

The JRL GHOST Professional Cordless Hair Clipper is engineered with several key features for superior performance:

- **Patented Reset IQ Charge Technology:** This technology extends battery life by consistently charging the clipper to 100%, even after prolonged use. It requires 3 hours for regular charging and 5 hours for Reset IQ charging.
- **Patented Smart-Clip Technology:** The clipper senses blade resistance and automatically adjusts the motor speed to prevent dragging or stalling, ensuring a smooth, consistent cut every time.
- **Constant Power:** Offers two adjustable speeds (6,000 RPM and 7,500 RPM) to maintain consistent performance throughout operation.
- **Onyx Fade Precision Blade:** Equipped with a specialized fade blade, allowing for precise fading and blending. Maximum cutting length is 3.5mm.
- **Quiet Motor:** Designed to create a quiet work environment, reducing noise during use.
- **Max 5 Hours Run Time:** A 3-hour charge provides up to 5 hours of battery life.
- **Advanced Lever Locking Feature:** Features 5 steady level locking adjustments with infinite variable settings for precise control over cutting length.
- **Patented Cool Blade Technology:** Keeps the blade cool to the touch, outperforming most clippers in a 30-minute test. It is also compatible with most professional clipper brands.

5. Setup


5.1 Initial Charging

Before first use, fully charge your JRL GHOST clipper using the provided Reset IQ Charging Dock and US plug. Connect the charger to a power outlet and place the clipper securely on the dock. The clipper's LED display will indicate charging status. A full Reset IQ charge takes approximately 5 hours.

FF 2020C-B

OMYX

**PROFESSIONAL
CORDLESS HAIR CLIPPER**



www.jrl.com

JRL[®]
PROFESSIONAL

Image 5.1: The JRL GHOST Professional Cordless Hair Clipper placed on its Reset IQ Charging Dock.

5.2 Blade Adjustment

The clipper features an adjustable lever for precise blade length control. Move the lever up or down to select your desired cutting length. The Onyx Fade Precision Blade allows for fine adjustments, with a maximum length of 3.5mm.

5.3 Attaching Comb Guards

Select the appropriate comb guard for your desired hair length. Align the comb guard with the clipper blade and firmly push it into place until it clicks securely. Ensure the comb guard is properly seated before operating the clipper.

6. Operating Instructions

6.1 Power On/Off

To turn the clipper on, slide the power switch to the 'ON' position. The LED display will illuminate. To turn off, slide the switch back to the 'OFF' position.

6.2 Speed Selection

The JRL GHOST clipper offers two speed settings: 6,000 RPM and 7,500 RPM. Use the speed selection button to toggle between these settings. Higher speeds are suitable for thicker hair or faster cutting, while lower speeds provide more control for detailed work.

6.3 Using the Adjustable Lever

The advanced lever locking feature allows for precise control over the blade's cutting length. Adjust the lever to achieve the desired fade or blend. The lever provides 5 steady locking adjustments, plus infinite variable settings between them, for maximum versatility.

6.4 General Cutting Guidance

Always start with a clean, dry head of hair. Begin by using a longer comb guard or a higher lever setting, gradually reducing the length as needed. Use smooth, even strokes against the direction of hair growth for best results. The Smart-Clip Technology will help maintain consistent power, preventing snagging.

7. Maintenance

7.1 Cleaning the Blades

After each use, turn off and unplug the clipper. Use the provided cleaning brush to remove any loose hair from the blades. For a more thorough cleaning, you may carefully remove the blade set (refer to manufacturer guidelines for blade removal) and rinse under running water, ensuring the clipper body remains dry. Allow blades to air dry completely before reattaching.

7.2 Lubricating the Blades

Regular lubrication is crucial for maintaining blade performance and longevity. After cleaning, apply 1-2 drops of the provided lubricant oil across the top of the blades while the clipper is running for a few seconds. This ensures smooth operation and helps prevent overheating.

7.3 Blade Protection

Always use the blade protector when the clipper is not in use or during storage. This protects the delicate blades from damage and keeps them sharp.

8. Troubleshooting

- **Clipper not turning on:** Ensure the clipper is fully charged. If using the charging dock, verify it is properly plugged into a working outlet.
- **Clipper dragging or stalling:** This may indicate excessive hair buildup on the blades or a low battery. Clean and lubricate the blades, and ensure the clipper is fully charged. The Smart-Clip Technology should minimize this issue.
- **Blades getting hot:** While the Cool Blade Technology is designed to prevent this, prolonged heavy use or insufficient lubrication can cause heat buildup. Turn off the clipper, allow it to cool, then clean and lubricate the blades.
- **Reduced cutting performance:** Clean and oil the blades. If performance does not improve, the blades may need to be replaced or professionally sharpened.

9. Specifications

Feature	Specification
Model	2020C-B
Product Dimensions	2.25 x 1.75 x 7 inches
Item Weight	9.76 ounces
Batteries	1 Nonstandard Battery required
Power Source	Battery Powered
Motor Speed	6,000 RPM & 7,500 RPM
Run Time	Up to 5 hours
Charge Time (Regular)	3 hours
Charge Time (Reset IQ)	5 hours
Blade Type	Onyx Fade Precision Blade
Max Blade Length	3.5mm

10. Warranty and Support

For warranty information or technical support, please refer to the documentation included with your product or contact JRL Professional customer service directly. Keep your purchase receipt as proof of purchase for any warranty claims.

