

PayLessHere 5-Drawer Fabric Dresser

PayLessHere 5-Drawer Fabric Dresser Instruction Manual

Model: 5-Drawer Fabric Dresser

1. INTRODUCTION

Thank you for choosing the PayLessHere 5-Drawer Fabric Dresser. This instruction manual provides essential information for the safe assembly, operation, and maintenance of your new storage unit. Please read this manual thoroughly before assembly and retain it for future reference.

This fabric dresser is designed to offer versatile storage with a sturdy metal frame and a durable wood top, suitable for various rooms in your home.

2. SAFETY INFORMATION

Please observe the following safety precautions to prevent injury or damage to the product:

- **Anti-Tipping Device:** Always install the included anti-tipping accessories to secure the dresser to a wall. This prevents accidental tipping, especially in households with children or pets.
- **Weight Capacity:** The wood top supports up to 80 lbs (36 kg). Each fabric drawer has a capacity of 15 lbs (6.8 kg). Do not exceed these weight limits.
- **Level Surface:** Ensure the dresser is placed on a flat, level surface to maintain stability. Use the adjustable feet to compensate for uneven floors.
- **Assembly:** Follow all assembly steps carefully. Do not overtighten screws.
- **Children:** Do not allow children to climb on or play with the dresser. Keep small parts away from children during assembly.

SUPERIOR FABRIC



Wear-resistant



Non-deforming



Easy to clean




Figure 2.1: Illustration of the tip-resistant kit and adjustable feet for enhanced stability and safety.

STURDY CONSTRUCTION



End-Stop Design



Thickened Steel Frame



Easy-to-Pull Handles

Figure 2.2: Overview of product dimensions and the 80 lbs weight capacity for the top surface.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all parts listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Metal Frame Components
- MDF Wood Top Panel
- Fabric Drawers (5 units)
- Adjustable Feet
- Anti-Tipping Kit (Wall anchors, screws, strap)
- Assembly Hardware (Screws, Allen wrench)
- Instruction Manual

4. ASSEMBLY INSTRUCTIONS

Assembly is required for this product. Please follow the step-by-step instructions provided in the included assembly guide. Ensure all components are correctly aligned before tightening screws.

1. Unpack all components and lay them out on a clean, soft surface to prevent scratches.
2. Assemble the metal frame according to the diagrams in the separate assembly guide. Ensure all connections are secure.
3. Attach the MDF wood top panel to the assembled metal frame.
4. Insert the fabric drawers into their designated slots.
5. Install the adjustable feet at the bottom of the frame.
6. Secure the dresser to the wall using the anti-tipping kit.

Your browser does not support the video tag.

Video 4.1: This video demonstrates the assembly process and highlights key features of the fabric dresser, including its storage capacity and design elements.



Figure 4.1: Close-up view of the thickened steel frame and end-stop design, illustrating the dresser's sturdy construction.

5. OPERATING INSTRUCTIONS

The PayLessHere 5-Drawer Fabric Dresser is designed for ease of use and versatile storage.

- **Drawer Use:** Gently pull the easy-pull handles to open and close the fabric drawers. Avoid forcing drawers, especially if they feel stuck.
- **Storage:** Utilize the five spacious fabric drawers for organizing clothes, toys, accessories, and other household items. Distribute weight evenly within each drawer and avoid overloading.
- **Top Surface:** The water-resistant MDF wood top provides an additional surface for decor, lamps, books, or other personal items. Ensure items placed on top do not exceed the 80 lbs weight limit.



Figure 5.1: Depiction of the dresser's large and varied storage capacity, highlighting the 15 lbs capacity per drawer.

5 DRAWERS

THE DRESSER CAN HOLD:



The above data is for reference only 



Figure 5.2: An example of the dresser used for organized storage of various items.

6. MAINTENANCE AND CARE

Proper care will extend the life and appearance of your fabric dresser.

- **Cleaning Fabric Drawers:** The high-quality fabric drawers are wear-resistant and easy to clean. For light dust, use a soft brush or vacuum cleaner. For spills, gently blot with a damp cloth and mild detergent, then air dry. Do not machine wash or tumble dry the fabric drawers.
- **Cleaning Wood Top:** The MDF wood top is water-resistant. Wipe with a damp cloth and mild cleaner. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Frame Care:** Wipe the metal frame with a soft, dry cloth.
- **Regular Checks:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.

STURDY STRUCTURE

Height Adjustment While Providing Stable Structural Support



Anti-Tilt Device



Adjustable Feet



End-stop Design

Figure 6.1: Details of the high-quality wood top, highlighting its water-resistant and easy-to-clean properties.



Figure 6.2: Information on the superior fabric used for the drawers, emphasizing its wear-resistant, non-deforming, and easy-to-clean characteristics.

7. TROUBLESHOOTING

If you encounter any issues with your dresser, refer to the following common problems and solutions:

- **Dresser is Wobbly:**
 - Ensure all screws are tightened.
 - Adjust the leveling feet at the bottom of the frame to stabilize the dresser on uneven floors.
 - Verify that the anti-tipping device is securely installed.
- **Drawers Do Not Slide Smoothly:**
 - Check that the drawers are inserted correctly and are not overloaded.
 - Ensure no items are obstructing the drawer's path.

- **Missing Parts:**
 - Review the package contents list. If parts are missing, contact customer support for assistance.

8. SPECIFICATIONS

Brand	PayLessHere
Model Name	5-Drawer Fabric Dresser (Tall Storage Tower with Metal Frame and Easy-Pull Fabric Bins)
Product Dimensions	11"D x 39"W x 39"H
Color	Brown
Room Type	Bedroom, Nursery, Living Room, Entryway
Assembly Required	Yes
Item Weight	29 Pounds
Top Surface Weight Capacity	80 lbs
Each Drawer Weight Capacity	15 lbs
UPC	195030146696

9. WARRANTY AND SUPPORT

For warranty information, missing parts, or any product-related inquiries, please contact PayLessHere customer support through the retailer's platform or the contact information provided with your purchase. Please have your model number and purchase date available when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question