

[Manuals.plus](#) /

> [iRobot](#) /

> iRobot Roomba 205 DustCompactor Vac Robot Vacuum - Auto-Compacts Debris Within The Robot, No Emptying for 60 Days, Bagless, Intense Power-Lifting Suction, LiDAR Navigation, Multi-Surface Cleaning

iRobot U112020

iRobot Roomba 205 DustCompactor Vac Robot Vacuum User Manual

Model: U112020 | Brand: iRobot

INTRODUCTION

The iRobot Roomba 205 DustCompactor Vac Robot is an innovative solution designed to simplify your home cleaning routine. This compact robot integrates advanced features to provide powerful, hands-free cleaning, making it ideal for modern living spaces.

Key features include:

- **DustCompactor Technology:** Continuously compacts debris inside the robot, allowing for up to 60 days without emptying. This bagless system eliminates the need for a bulky self-emptying dock.
- **Intense Power-Lifting Suction:** Features a 3-stage cleaning system with 70X more suction power compared to Roomba 600 series robots, effectively capturing dirt, dust, and pet hair from various surfaces.
- **ClearView LiDAR Navigation:** Utilizes high-performance LiDAR technology to quickly map your home, navigate efficiently around obstacles, and ensure thorough, wall-to-wall coverage, even in low-light conditions.
- **Multi-Surface Cleaning:** Equipped with a multi-surface rubber brush and an edge-sweeping brush to clean different floor types, including hardwood, tile, and carpet, reaching into tight spaces and corners.
- **Extended Battery Life:** Provides over three hours of cleaning time on a single charge. The robot automatically returns to its base for recharging and resumes cleaning where it left off.
- **Smart Control:** Control your Roomba via the intuitive Roomba Home App, voice assistants (Alexa, Siri, Google Assistant), or directly using the buttons on the robot. Customize cleaning schedules, suction levels, and define keep-out zones.



The iRobot Roomba 205 DustCompactor Vac Robot Vacuum, showcasing its sleek design and compact form factor.

SETUP

Unboxing and Initial Setup

Upon unboxing your Roomba 205, you will find the robot, a compact charging base, a power cord, and a mopping pad attachment. Follow these steps for initial setup:

1. Remove all packaging materials from the robot and accessories.
2. Place the charging base against a wall in an open, uncluttered area. Ensure there is at least 1.5 feet of clear space on either side of the base and 4 feet in front of it.
3. Plug the power cord into the charging base and then into a wall outlet.
4. Place the Roomba 205 onto the charging base, ensuring the charging contacts align. The robot will emit a sound to confirm it is charging.
5. For first-time use, it is recommended to fully charge the robot before its initial cleaning cycle.

Your browser does not support the video tag.

Official unboxing video for the Roomba 205 DustCompactor Vac Robot, demonstrating initial setup steps.

Connecting to the Roomba Home App

To unlock the full potential of your Roomba 205, download and connect it to the Roomba Home App:

1. Scan the QR code provided in the product packaging or search for

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DX6N28N7>

More documents and user manuals: <https://manuals.plus/>