

Fangaci 005

Fangaci Cordless IPX7 Waterproof Wet Dry Face Razor User Manual

Model: 005

INTRODUCTION

This manual provides essential information for the safe and effective use of your Fangaci Cordless IPX7 Waterproof Wet Dry Face Razor, Model 005. Please read all instructions carefully before first use and retain this manual for future reference.

SAFETY INFORMATION

Important Safety Precautions:

- Always unplug the shaver before use.
- Do not use while charging.
- Avoid contact with eyes and sensitive areas.
- Be cautious when shaving near water.
- Clean after each use and allow to dry completely before storing.
- Keep out of reach of children.

WHAT'S INCLUDED

Your Fangaci Cordless IPX7 Waterproof Wet Dry Face Razor package includes:

- Fangaci Cordless IPX7 Waterproof Wet Dry Face Razor (Model 005)
- Charging Cable (Type-C)
- Cleaning Brush
- Protective Cap
- User Manual

MEN



Image: The Fangaci Cordless IPX7 Waterproof Wet Dry Face Razor shown with its charging cable, cleaning brush, and protective cap.

SETUP

1. **Initial Charge:** Before first use, fully charge the device using the provided Type-C charging cable. The LED display will indicate the battery percentage. Charging time is approximately 120 minutes for a full charge, providing about 90 minutes of usage.
2. **Attach Head:** Ensure the desired shaving head is securely attached to the main body of the shaver.
3. **Power On:** Press and hold the power button for 3 seconds to turn the shaver on. The LED display will show the current battery level.



Image: Close-up of the Fangaci razor's LED display, indicating battery charge level.

OPERATING INSTRUCTIONS

The Fangaci razor can be used for both wet and dry shaving. Its IPX7 waterproof rating allows for safe use in the shower.

1. **Dry Shaving:** For dry shaving, ensure your skin is clean and dry. Gently press the shaver against your skin and move it in circular motions or against the direction of hair growth.
2. **Wet Shaving:** For wet shaving, apply shaving cream or gel to your skin. The shaver can be used directly in the shower. Move the shaver gently over the skin.
3. **Body Areas:** The shaver is designed for use on various body areas including legs, arms, armpits, and

bikini line. Its ergonomic design ensures comfortable handling.

4. **Power Off:** To turn off the shaver, press and hold the power button for 3 seconds.




Image: The Fangaci razor in use on different body parts, demonstrating its versatility.

Your browser does not support the video tag.

Video: A user review demonstrating the unboxing and use of the Fangaci Cordless Electric Shaver, highlighting its features and performance.

MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and hygiene of your shaver.

1. **After Each Use:** Turn off the shaver. Remove the shaving head. Use the provided cleaning brush to remove any trapped hairs from the blades and the shaver body.
2. **Rinsing:** Since the shaver is IPX7 waterproof, you can rinse the shaving head and the body under running water. Do not immerse the entire shaver in water for extended periods.
3. **Drying:** After cleaning, shake off excess water and allow all parts to air dry completely before reassembling or storing.
4. **Storage:** Store the shaver in a cool, dry place, ideally with the protective cap on to prevent damage to the blades.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Shaver does not turn on.	Low battery or not charged.	Charge the shaver fully. Ensure the power button is pressed and held for 3 seconds.
Reduced shaving performance.	Blades are dull or clogged with hair.	Clean the shaving head thoroughly. If performance does not improve, consider replacing the shaving head (if replacement parts are available).
Skin irritation after shaving.	Incorrect shaving technique or sensitive skin.	Ensure gentle pressure and proper technique. Try wet shaving with shaving cream. If irritation persists, consult a dermatologist.

SPECIFICATIONS

- **Model Name:** 005
- **Power Source:** Battery Powered
- **Special Features:** Anti-Scratch, Battery Indicator, Cordless, Dry Shave, Fast Charging
- **Waterproof Rating:** IPX7
- **Battery Type:** 1 Nonstandard Battery (included)
- **Usage Time:** Approximately 90 minutes on a full charge
- **Charging Time:** Approximately 120 minutes
- **Product Dimensions:** 3 x 3 x 3 inches
- **Item Weight:** 7.83 ounces
- **Manufacturer:** Fangaci

WARRANTY AND SUPPORT

For warranty information or product support, please refer to the contact details provided on the product packaging or visit the official Fangaci website. Keep your purchase receipt as proof of purchase.