

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [DOOGEE](#) /

› [DOOGEE Tab G6+ Android Tablet User Manual](#)

DOOGEE Tab G6+

DOOGEE Tab G6+ Android Tablet User Manual

Model: Tab G6+ | Brand: DOOGEE

PRODUCT OVERVIEW

The DOOGEE Tab G6+ is an 11-inch FHD+ Android tablet designed for versatile use. It features a 90Hz display, runs on Android 15, and is powered by a T7280 Octa-Core processor. With 32GB RAM (8GB physical + 24GB virtual) and 256GB ROM, it offers ample performance and storage. Key features include an 8000mAh battery, a 13MP camera, Face Unlock, Widevine L1 support for high-definition streaming, and dual speakers for an enhanced audio experience.



This image displays the DOOGEE Tab G6+ Android Tablet from multiple angles. The front view shows the 11-inch FHD+ display. The rear view highlights the camera module and the tablet's available colors: black, purple, and grey, along with the DOOGEE branding.

INITIAL SETUP

Unboxing and Package Contents

Before beginning, ensure all components are present in the package:

- DOOGEE Tab G6+ Tablet
- USB-C Charging Cable
- Power Adapter
- SIM Ejector Tool (if applicable)
- Quick Start Guide

Charging the Device

Connect the provided USB-C cable to the tablet's charging port and the power adapter. Plug the adapter into a wall outlet. A full charge is recommended before first use. The battery indicator on the screen will show charging status.

Powering On/Off

- **To Power On:** Press and hold the Power button located on the side of the tablet until the DOOGEE logo appears.
- **To Power Off:** Press and hold the Power button until the power options menu appears. Select 'Power off'.
- **To Restart:** Press and hold the Power button until the power options menu appears. Select 'Restart'.

Initial Configuration

Upon first power-on, the tablet will guide you through the initial setup process:

1. Select your preferred language.
2. Connect to a Wi-Fi network.
3. Sign in with your Google Account or create a new one. This is essential for accessing the Google Play Store and other Google services.
4. Review and accept the terms and conditions.
5. Set up screen lock (PIN, pattern, password, or Face Unlock).

OPERATING INSTRUCTIONS

Navigating the Android 15 Interface

- **Home Screen:** The main screen where app icons and widgets are displayed. Swipe left or right to access additional home screens.
- **App Drawer:** Swipe up from the bottom of the screen to access all installed applications.
- **Notifications Panel:** Swipe down from the top of the screen to view notifications and quick settings toggles (Wi-Fi, Bluetooth, etc.).
- **Navigation Gestures:** Use gestures like swiping from the edge for 'Back', swiping up from the bottom for 'Home', and swiping up and holding for 'Recent Apps'.

Connecting to Wi-Fi and Bluetooth

- **Wi-Fi:** Go to *Settings > Network & internet > Internet* Turn on Wi-Fi, select your desired network, and enter the password if prompted.
- **Bluetooth:** Go to *Settings > Connected devices > Connection preferences > Bluetooth* Turn on Bluetooth, then select 'Pair new device' to connect to Bluetooth accessories.

Using the Camera

The tablet is equipped with a 13MP camera. Open the 'Camera' application from the home screen or app drawer. You can

switch between photo and video modes, adjust settings, and use features like zoom and flash.

Face Unlock

To set up Face Unlock, go to *Settings > Security & privacy > Device unlock > Face unlock*. Follow the on-screen instructions to register your face. Once set up, you can unlock your tablet by looking at the front camera.

Audio (Dual Speakers)

The DOOGEE Tab G6+ features dual speakers for an immersive audio experience. Adjust volume using the physical volume buttons on the side of the tablet or through the on-screen volume slider in the quick settings panel.

Storage Management

The tablet comes with 256GB of internal storage. To manage storage, go to *Settings > Storage*. Here you can see storage usage by category (apps, images, videos, etc.) and free up space if needed.

Widevine L1 Support

The tablet supports Widevine L1, enabling high-definition video streaming from compatible services like Netflix, Amazon Prime Video, and Disney+.

MAINTENANCE AND CARE

Cleaning the Tablet

Use a soft, lint-free cloth to clean the screen and body of the tablet. For stubborn smudges, slightly dampen the cloth with water or a screen cleaner. Avoid using harsh chemicals or abrasive materials.

Battery Care

The tablet is equipped with an 8000mAh battery. To prolong battery life:

- Avoid extreme temperatures.
- Do not let the battery drain completely before recharging frequently.
- Unplug the charger once the battery is full.
- Reduce screen brightness and disable unnecessary features (Wi-Fi, Bluetooth) when not in use.

Software Updates

Regularly check for and install software updates to ensure optimal performance, security, and access to new features. Go to *Settings > System > System update* to check for available updates.

Storage Optimization

Periodically review and delete unnecessary files, apps, and media to maintain optimal performance. Consider using cloud storage for large files.

TROUBLESHOOTING

This section addresses common issues you might encounter with your DOOGEE Tab G6+.

| Problem | Possible Solution |
|-----------------------|--|
| Tablet won't power on | Ensure the battery is charged. Connect to the charger for at least 30 minutes. Try holding the Power button for 10-15 seconds. |

| Problem | Possible Solution |
|---------------------------|---|
| Wi-Fi connection issues | Restart the tablet and your Wi-Fi router. Forget the network in Wi-Fi settings and reconnect. Ensure you are within range of the Wi-Fi signal. |
| Slow performance | Close unnecessary background apps. Clear app caches (<i>Settings > Apps > [App Name] > Storage & cache > Clear cache</i>). Free up storage space. Restart the tablet. |
| Apps crashing or freezing | Force stop the app (<i>Settings > Apps > [App Name] > Force stop</i>). Clear the app's cache and data. Reinstall the app. Ensure the tablet's software is up to date. |
| Face Unlock not working | Ensure you are in a well-lit environment. Clean the front camera lens. Re-register your face in settings. |

TECHNICAL SPECIFICATIONS

| Feature | Specification |
|-----------------------|------------------------------------|
| Model Name | DOOGEE Tab G6+ |
| Operating System | Android 15 |
| Display Size | 11 Inches |
| Max Screen Resolution | 2000*1200 Pixels |
| RAM | 32GB (8GB physical + 24GB virtual) |
| ROM | 256GB |
| Processor | T7280 Octa-Core |
| Battery Capacity | 8000mAh |
| Rear Camera | 13MP |
| Connectivity | Wi-Fi, Bluetooth |
| Security Features | Face Unlock |
| Audio | Dual Speakers |
| DRM Support | Widevine L1 |
| Product Dimensions | 14.76 x 13.62 x 8.38 inches |
| Color | Black |

WARRANTY AND SUPPORT INFORMATION

The DOOGEE Tab G6+ comes with a standard manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions, including warranty period and coverage details. For technical support, troubleshooting assistance beyond this manual, or warranty claims, please visit the official DOOGEE support website or contact their customer service. Keep your purchase receipt and product serial number handy when seeking support.

You can often find support resources, FAQs, and contact information on the official DOOGEE brand store page on Amazon: [DOOGEE Store on Amazon](#)

© 2025 DOOGEE. All rights reserved.