

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [homary](#) /
- › **homary Extendable TV Stand & Nesting Coffee Table Set Instruction Manual**

**homary GY-43429624**

# homary Extendable TV Stand & Nesting Coffee Table Set

Model: GY-43429624

## INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your homary Extendable TV Stand and Nesting Coffee Table Set. Please read all instructions carefully before beginning assembly and retain this manual for future reference. This set is designed to offer versatile storage and display solutions for your living space.



Fully Extendable



Partially Extended



Retracted

Image: The homary Extendable TV Stand and Nesting Coffee Table Set in a modern living room setting.

## SAFETY INFORMATION

Assembly may require careful handling to avoid injury. Keep fingers away from moving parts when extending or retracting the table. Ensure the table is properly assembled and stable before use. Do not overload drawers or tabletop to prevent tipping.

## PRODUCT SPECIFICATIONS

Feature	Detail
Brand	homary
Model Name	TV STAND COFFEE TABLE SET OF 2
Model Number	GY-43429624
TV Stand Dimensions (Retracted)	78.7" W x 15.7" D x 13.8" H

TV Stand Dimensions (Extended)	141.7" W x 15.7" D x 13.8" H
Coffee Table Dimensions	31.5" W x 31.5" D x 15.7" H
Material (TV Stand)	Engineered Wood
Material (Coffee Table)	Formaldehyde-Free Board, Carbon Steel
Color	Grey (TV Stand), Gray & Black (Coffee Table)
Storage	3 Drawers in TV Stand
Assembly Required	Yes
Recommended People for Assembly	2
Tools Recommended for Assembly	Allen Key, Screw Driver, Wrench




Image: Detailed dimensions of the TV stand components.

31.5"/800mm



Image: Detailed dimensions of the nesting coffee tables.

## ASSEMBLY INSTRUCTIONS

For a visual guide, please refer to the assembly video below. Ensure all parts are present and undamaged before starting assembly.

Your browser does not support the video tag.

Video: How to install the homary Wood Extendable TV Stand Media Console with 3-Drawer.

- Prepare Panels:** Lay out all panels and identify them according to the assembly diagram. Attach cam locks to designated holes on panels F and E.
- Install Drawer Slides:** Secure the main tracks (drawer slides) to panels B, D, and C using the provided screws. Ensure they are aligned correctly for smooth drawer operation.
- Assemble TV Stand Frame:** Connect panels B, C, and D to the base panels E and F. Use the cam locks and screws to firmly secure the structure.
- Attach Top Panel:** Carefully place and secure the top panel (A) onto the assembled frame, ensuring all connections are tight.
- Assemble Drawers:** Construct the three drawers using panels J, K, L, N, and O. Attach the secondary rails (drawer slides) to the sides of the drawer boxes.
- Install Drawers:** Insert the assembled drawers into their respective compartments in the TV stand. Ensure they slide in and out smoothly.
- Attach Support Legs:** Secure the support legs (G) to the bottom of the TV stand using the provided screws. These legs provide stability and allow for the extendable feature.
- Assemble Coffee Tables:** Follow the separate instructions for assembling the nesting coffee tables. Attach the carbon steel bases to the tabletops.



Image: The TV stand features three spacious drawers with a hidden pull design for organized storage.

## Steel Frame in Black



Image: Detail of the carbon steel frame providing stability to the nesting coffee tables.

## USAGE AND OPERATION

### Extendable TV Stand

The TV stand features an extendable design, allowing you to adjust its width to fit your space. Gently pull or push the movable section of the TV stand to extend or retract it. Ensure the stand is stable in its desired position before placing heavy items on it.

### Nesting Coffee Tables

The two coffee tables are designed to nest together, saving space when not in use. The smaller table can be tucked under the larger one. Separate them for additional surface area when entertaining or for individual use.



Image: The TV stand demonstrating its partially extended and fully retracted configurations.

## CARE AND MAINTENANCE

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Spills:** Clean up spills immediately to prevent staining, especially on engineered wood surfaces.
- **Heat and Moisture:** Avoid placing hot items directly on the surface. Use coasters or protective pads. Protect from excessive moisture.
- **Sunlight:** Prolonged exposure to direct sunlight may cause fading or discoloration.
- **Moving:** When moving the furniture, lift it rather than dragging to prevent damage to the legs and frame.

## TROUBLESHOOTING

- **Wobbly Stand/Table:** Check all screws and bolts to ensure they are tightened securely. Re-tighten if necessary. Ensure the furniture is on a level surface.
- **Drawers Not Sliding Smoothly:** Verify that the drawer slides are correctly installed and free from obstructions. Apply a

silicone-based lubricant if needed.

- **Difficulty Extending/Retracting:** Ensure the movable section is free from obstructions. Check the sliding mechanisms for any debris or misalignment.

## WARRANTY INFORMATION

---

This product comes with a 1-year manufacturer's warranty. Please retain your proof of purchase for warranty claims.

## CUSTOMER SUPPORT

---

If you have any questions, require assistance with assembly, or need to report a damaged part, please contact homary customer support:

**Phone:** +1 909 808 9057

**Email:** [service@homary.com](mailto:service@homary.com)

Please provide your order number when contacting us.