DOOGEE Tab A9 PRO

DOOGEE Tab A9 PRO Tablet User Manual

Model: Tab A9 PRO

1. Introduction

Thank you for choosing the DOOGEE Tab A9 PRO Tablet. This manual provides essential information for setting up, operating, and maintaining your device. Please read it carefully before using the tablet to ensure proper functionality and longevity.



Figure 1.1: DOOGEE Tab A9 PRO Tablet. This image displays the tablet from both the front, highlighting its display, and the back,

2. WHAT'S IN THE BOX

Verify that all items are present in the package:

- DOOGEE Tab A9 PRO Tablet
- Charger
- Type-C USB Cable
- Tool for taking card (SIM/SD card tray ejector)

3. SETUP

3.1 Initial Charging

Before first use, fully charge the tablet using the provided charger and Type-C USB cable. Connect the Type-C cable to the tablet's charging port and the charger to a power outlet.

3.2 Powering On/Off

- To power on: Press and hold the power button until the DOOGEE logo appears.
- To power off: Press and hold the power button, then select "Power off" from the options.

3.3 Initial Setup Wizard

Upon first power-on, the tablet will guide you through an initial setup process. This includes selecting your language, connecting to Wi-Fi, setting up your Google account, and configuring security options like face recognition.

The Latest Android 15 System Smarter, Smoother & Safer Live Caption , parental controls ANDROID • • C

Figure 3.1: Android 15 System Interface. This image illustrates the clean and intuitive interface of the Android 15 operating system, showing various application icons and system settings.

3.4 Inserting a MicroSD Card (Optional)

The tablet supports expandable memory up to 2TB via a MicroSD card (purchased separately). Use the provided tool to open the card tray and insert the MicroSD card as indicated.

4GB RAM + 128GB ROM Massive Storage

20GB Max RAM

4GB Basic + 16GB Virtual RAM **128GB ROM**

Basic Storage

2TB

Expandable Memory



* 2TB TF card needs to be purchased separately.

Figure 3.2: Storage Capabilities. This image highlights the tablet's 20GB Max RAM (composed of 4GB Basic and 16GB Virtual RAM) and 128GB internal storage, with the option to expand up to 2TB using a TF card.

4. OPERATING THE TABLET

4.1 Display and Navigation

The DOOGEE Tab A9 PRO features a 10.1-inch IPS HD+ display with a resolution of 1280x800 pixels, offering clear visuals and a wide field of view.

10.1" IPS HD Display for Wide Field of View 80.2% 1280*800 Resolution Screen-to-body ratio Million Colors 16:10 16:10 1200:1 2.5D Aspect Ratio Contrast Cover Glass

Figure 4.1: Display Specifications. This image details the 10.1-inch IPS HD display, including its 1280x800 resolution, 80.2% screen-to-body ratio, and 16.7 million colors.

4.2 Camera Functions

The tablet is equipped with an 8MP main camera and a 5MP front camera, suitable for capturing photos, videos, and video calls.




Figure 4.2: Camera Features. This image highlights the tablet's 8MP main camera and 5MP front camera, demonstrating their use for capturing moments and video calls.

4.3 Audio

The tablet features 1217 BOX Dual Speakers for enhanced audio experience. It also includes a 3.5mm headphone jack for private listening.



Figure 4.3: Dual Speaker System. This image illustrates the tablet's 1217 BOX Dual Speakers, designed to provide clear and immersive audio.

4.4 Connectivity

- Wi-Fi: Connect to available Wi-Fi networks via Settings > Network & internet > Wi-Fi.
- **Bluetooth 5.0:** Pair with Bluetooth devices (headphones, speakers, etc.) via Settings > Connected devices > Bluetooth.
- OTG (On-The-Go): Supports connecting USB peripherals like flash drives or keyboards via a compatible OTG adapter (not included).
- Wireless Screencasting: Easily connect to a large TV or display for screen mirroring.

5. MAINTENANCE

5.1 Cleaning

Use a soft, lint-free cloth to clean the screen and body of the tablet. Avoid using harsh chemicals or abrasive materials.

5.2 Battery Care

The tablet is equipped with a 6580mAh Lithium Polymer battery. To prolong battery life:

- Avoid extreme temperatures.
- Do not let the battery completely drain frequently.
- Use the provided charger.
- Enable power saving mode when needed.

5.3 Software Updates

Regularly check for and install system updates to ensure optimal performance, security, and access to new features. Go to Settings > System > System update.

6. TROUBLESHOOTING

6.1 Common Issues and Solutions

Problem	Solution
Tablet does not turn on	Ensure the battery is charged. Press and hold the power button for 10-15 seconds to force a restart.
Slow performance	Close unused applications. Clear cache. Restart the tablet. Check for system updates.
Wi-Fi connection issues	Restart the tablet and your Wi-Fi router. Forget and reconnect to the network.
Apps crashing	Clear the app's cache and data (Settings > Apps > [App Name] > Storage). Reinstall the app.

7. SPECIFICATIONS

Feature	Detail
Model	DOOGEE Tab A9 PRO
Operating System	Android 15
Processor	Quad-Core (Unisoc T310)
RAM	12GB
Internal Storage	128GB ROM
Expandable Storage	Up to 2TB (MicroSD, sold separately)
Display	10.1-inch IPS HD+ (1280x800)
Main Camera	8MP
Front Camera	5MP
Battery	6580mAh Lithium Polymer
Connectivity	Wi-Fi, Bluetooth 5.0, OTG, Type-C USB
Audio	1217 BOX Dual Speakers, 3.5mm headphone jack

Feature	Detail
Dimensions	25.7 x 16.88 x 0.79 cm
Weight	400 g

Unisoc T310 Processor

Boosts Speed & Efficiency



Unisoc T310 Powerful Quad-Core



2.0GHzUltimate Frequency



12nmAdvanced Process
Technology




Figure 7.1: Unisoc T310 Processor. This image details the specifications of the Unisoc T310 processor, highlighting its powerful quad-core architecture, 2.0GHz ultimate frequency, and 12nm advanced process technology.

8. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official DOOGEE website or contact their customer service. Keep your purchase receipt for warranty claims.

DOOGEE Official Website: www.doogee.cc

Documents - DOOGEE - Tab A9 PRO



[pdf] User Manual Dimension Guide Accessories

DOOGEE Tab A9 Pro TABLET PC WiFi Version 23 ore fa — User Manual Android 15 Black Gray Blue 644g 257 3*168 8*7 9mm IPS HD 11 inch 1280*800 138 Full angle Support Bluetooth keyboard · Display 90Hz 30GB RAM 6GB Up to 24GB Extended LPDDR4X 128GB ROM eMMC 05dd6f18 9ea5 4647 aae9 d8bccf2f95ea d otto de files |||

DOOGEE **Tab A9 Pro** TABLET PC WiFi Version Android 15 11 inch HD IPS Display / 90Hz 30GB RAM 6GB Up to 24GB Extended RAM / LPDDR4X 128GB ROM / eMMC 8580mAh Large Battery Unisoc T7200 / Octa Core / 1.6GHz / 12nm 13MP Main camera 5MP Front Camera High quality dual speakers With 3.5mm headph... lang:en score:30 filesize: 228.19 K page_count: 1 document date: 2025-05-20

DOOGEE Tab A9 Pro TABLET PC WIFI Version



[pdf] User Manual Dimension Guide Accessories

DOOGEE Tab A9 Pro TABLET PC WiFi Version pirms 10 stundām — User Manual Android 15 Black Gray Blue 512g 242 5*160 9*9 7mm IPS Bluetooth 5 0 GSM NO WCDMA TDD FDD Unisoc T310 octa core · 1 inch HD Display 2 5D cover glass 6580mAh Large Battery Quad Core 0GHz · 1280*800 149 Full angle 80 2% 802 11 a b g n ac 4GHz See more 1bc43bd5 901f 4447 9ec8 bd45355ee7ba d otto de files

DOOGEE **Tab A9 Pro** TABLET PC WiFi Version Android 15 10.1 inch HD IPS
Display / 2.5D cover glass 6580mAh Large Battery Unisoc T310 / Quad Core /
2.0GHz 20GB RAM 4GB Up to 16GB Extended RAM / LPDDR4 128GB ROM / eMMC
8MP Main camera 5MP Front Camera High quality dual speakers With 3.5mm hea...
lang:en score:27 filesize: 219.49 K page_count: 1 document date: 2025-05-20