

[Manuals.plus](#) /

> [aiprotabket](#) /

> aiprotabket T50 11-inch Android 15 Tablet User Manual

aiprotabket T50

aiprotabket T50 11-inch Android 15 Tablet User Manual

Model: T50

1. INTRODUCTION

Thank you for choosing the aiprotabket T50 11-inch Android 15 Tablet. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your device. Please read it carefully to ensure optimal performance and longevity of your tablet.

2. PACKAGE CONTENTS

Please check the package for the following items:

- aiprotabket T50 11-inch Android 15 Tablet
- USB Type-C Cable
- Power Adapter
- User Manual (this document)

3. PRODUCT OVERVIEW

The aiprotabket T50 features an 11-inch LCD display and a slim, portable design. Familiarize yourself with the physical components of your tablet.

New T5 Pro Tab

Power & Portability Perfected

T7200 Octa-Core / 11 inch LCD Display / 802.11.ac WIFI 5

1080P
WideVine L1


Android
15




Image 3.1: Front and back view of the aiprotab T50 Tablet, highlighting its sleek design and rear camera module.

9.6 mm slim. 500g light.



Slip into your bag and go!




Image 3.2: The aiprotab[™] T50 Tablet showcasing its 9.6mm slim profile and light 500g weight, demonstrating its portability for various uses like reading or watching videos.

3.1 Physical Features

- **Display:** 11-inch LCD screen with Full Lamination IPS Incell technology.
- **Cameras:** Front (5MP) and Rear (8MP+13MP) cameras.
- **Ports:** USB Type-C interface, Micro SD card slot, Headphone jack.
- **Audio:** Dual speakers, Microphone.
- **Buttons:** Power button, Volume buttons.

4. SETUP

4.1 Charging the Tablet

1. Connect the USB Type-C cable to the tablet's charging port.
2. Connect the other end of the cable to the power adapter.
3. Plug the power adapter into a wall outlet.
4. Allow the tablet to charge until the battery indicator shows full. The tablet supports 18W PD fast charging.

4.2 Powering On/Off

- **To Power On:** Press and hold the Power button until the aiprotab[™] logo appears.
- **To Power Off:** Press and hold the Power button, then select "Power off" from the options on the screen.
- **To Restart:** Press and hold the Power button, then select "Restart" from the options on the screen.

4.3 Initial Setup

Upon first power-on, follow the on-screen prompts to:

- Select your preferred language.
- Connect to a Wi-Fi network.
- Sign in with your Google account or create a new one.
- Set up screen lock and other security features.

4.4 Inserting a Micro SD Card

The tablet supports Micro SD cards up to 2TB for expanded storage.

1. Locate the Micro SD card slot on the side of the tablet.
2. Gently insert the Micro SD card into the slot until it clicks into place.
3. The tablet will detect the new storage. You may be prompted to format the card for optimal use with the device.

5. OPERATING INSTRUCTIONS

5.1 Basic Navigation

The T50 tablet runs on Android 15 OS, offering intuitive touch-based navigation.

- **Tap:** Select an item or open an app.
- **Swipe:** Scroll through screens or lists.
- **Pinch:** Zoom in or out on images and web pages.
- **Long Press:** Access contextual menus or move icons.

5.2 Connectivity


- **Wi-Fi:** Go to *Settings > Network & internet > Wi-Fi* to connect to 2.4GHz or 5GHz networks.
- **Bluetooth:** Go to *Settings > Connected devices > Connection preferences > Bluetooth* to pair with Bluetooth 5.0 devices.

5.3 Media Consumption

The 11-inch LCD display with IPS In-cell technology provides a sharp and colorful viewing experience. With Widevine L1 support, you can stream 1080p copyrighted content smoothly from popular services.

16:10 Ratio canvas

The perfect ratio for streaming media



Common 10.1 inch



Larger 11 inch

Screen area increased by 20%

Image 5.1: The aiprotabket T50 Tablet displaying a video, illustrating its 16:10 screen ratio optimized for media streaming and its larger 11-inch screen compared to a common 10.1-inch tablet.

5.4 Multitasking

The T50 tablet, powered by the UNISOC T7200 Octa-Core processor and 20GB RAM, ensures seamless multitasking across various applications.

More ways to enjoy the Pad



Image 5.2: The aiprotabket T50 Tablet demonstrating multiple ways to enjoy the device, including e-books, music, videos, and kid-friendly applications, highlighting its multitasking capabilities.

5.5 Battery Management

The 8000mAh battery provides extended usage. To optimize battery life:

- Adjust screen brightness.
- Close unused applications.
- Disable Wi-Fi or Bluetooth when not in use.
- Utilize power-saving modes in *Settings > Battery*.

Large battery and 18W fast charging solve your battery anxiety.

8000 MAH



Image 5.3: The aiprottablet T50 Tablet screen showing a battery charge indicator, emphasizing its 8000mAh battery capacity and 18W fast charging capability.

6. MAINTENANCE

6.1 Cleaning

Use a soft, lint-free cloth to clean the screen and body of the tablet. Avoid using harsh chemicals or abrasive materials.

6.2 Software Updates

Regularly check for and install system updates to ensure your tablet has the latest features and security patches. Go to *Settings > System > System update*

6.3 Storage Management

To optimize performance, periodically manage your tablet's storage. Delete unnecessary files, uninstall unused apps, and move large media files to your expandable Micro SD card. Go to *Settings > Storage*.

7. TROUBLESHOOTING

This section addresses common issues you might encounter with your aiprottablet T50.

7.1 Tablet Not Turning On

- Ensure the tablet is sufficiently charged. Connect it to the charger for at least 30 minutes.
- Press and hold the Power button for 10-15 seconds to force a restart.

7.2 Wi-Fi Connection Issues

- Check if Wi-Fi is enabled in *Settings > Network & internet > Wi-Fi*
- Restart your Wi-Fi router.
- Forget the network and reconnect by entering the password again.

7.3 Apps Crashing or Freezing

- Close the problematic app and reopen it.
- Clear the app's cache and data in *Settings > Apps > [App Name] > Storage & cache*
- Ensure the app is updated to its latest version from the Google Play Store.
- If the issue persists, consider uninstalling and reinstalling the app.

7.4 Slow Performance

- Close background applications.
- Free up storage space by deleting unnecessary files or apps.
- Restart the tablet.
- Check for system updates.

8. SPECIFICATIONS

Detailed technical specifications for the aiprotab[®] T50 Tablet.




Image 8.1: Diagram showing the dimensions of the aiprotablen T50 Tablet: 11-inch screen (16:10 ratio), 260mm width, 165mm height, and 9.6mm thickness.

Feature	Specification
Brand	aiprotablen
Model Name	T50
Operating System	Android 15
CPU	UNISOC T7200 Octa-Core, 1.6 GHz
RAM	20GB (6GB Physical + 14GB Virtual)
Internal Storage	128GB
Expandable Storage	Up to 2TB via Micro SD card (not included)
Screen Size	11 inches
Display Resolution	1280x800 Pixels (supports 1080p video playback)
Graphics Coprocessor	Mali-G57
Front Camera	5 MP
Rear Camera	8MP + 13MP

Battery Capacity	8000mAh (approx. 8-10 hours battery life)
Charging	18W PD Fast Charging, Type-C port
Connectivity	Wi-Fi (802.11ac, 2.4G/5GHz Dual-band), Bluetooth 5.0, Hotspot, FM
Dimensions (L x W x H)	24.64 x 16 x 0.76 cm
Weight	1.12 Kilograms
Color	Black

9. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation included with your purchase or visit the official aiprotabket website. Keep your proof of purchase for warranty claims.