

Truely M16 Pro

Truely M16 Pro Mini 3G Smartphone User Manual

Model: M16 Pro

INTRODUCTION

This manual provides comprehensive instructions for the safe and efficient use of your Truly M16 Pro Mini 3G Smartphone. Please read this guide thoroughly before operating the device to ensure optimal performance and longevity.



Image: The Truly M16 Pro Mini Smartphone, pink in color, held in a hand, demonstrating its compact size. A credit card is shown behind it for scale. The phone displays various app icons on its screen.

PACKAGE CONTENTS

Verify that all items are present in the package:

- Truely M16 Pro Mini Smartphone
- USB Type-C Charging Cable
- User Manual (this document)
- Phone Case
- Screen Protector
- SIM Tray Ejector

SETUP

1. SIM Card and Micro SD Card Installation

The Truely M16 Pro supports dual SIM cards and an external Micro SD card for expanded storage. Use the provided SIM tray ejector tool to open the SIM tray.

1. Locate the SIM tray slot on the side of the phone.
2. Insert the SIM tray ejector tool into the small hole next to the tray and press gently until the tray pops out.
3. Carefully pull out the SIM tray.
4. Place your Nano SIM card(s) and/or Micro SD card into the designated slots on the tray. Refer to the diagram on the tray for correct orientation.
5. Gently push the tray back into the phone until it is flush with the device's side.

3G network dual card dual standby

High speed network world connectivity

High speed and stable network connection, fully enjoy the era of high-speed networks, with faster and more stable connections.



Image: A visual representation of the SIM tray, illustrating how to insert two Nano SIM cards or one Nano SIM card and one Micro SD card into the Truely M16 Pro Mini Smartphone.

2. Initial Charging

Before first use, it is recommended to fully charge the device.

- Connect the USB Type-C charging cable to the phone's charging port.
- Connect the other end of the cable to a compatible USB power adapter (not included) and plug it into a power outlet.
- The charging indicator will appear on the screen.

Dynamic and shining, eye-catching focus

The essence of intelligent interaction innovation

Pop up incoming calls and charging in a prominent way, allowing you to easily interact without having to put down your current tasks.



Image: The Truely M16 Pro Mini Smartphone screen showing a charging icon and battery percentage, indicating the device is being charged.

3. Power On/Off

- **To Power On:** Press and hold the Power button (located on the right side of the phone) until the Truely logo appears.
- **To Power Off:** Press and hold the Power button until the power options menu appears on the screen. Select "Power off".
- **To Restart:** From the power options menu, select "Restart".

OPERATING INSTRUCTIONS

1. Basic Navigation (Android 10.0)

Your Truely M16 Pro runs on Android 10.0, offering an intuitive user experience.

- **Touch Screen:** Tap to select, swipe to scroll, pinch to zoom.
- **Home Screen:** Access your apps and widgets. Swipe left or right to navigate between screens.
- **Notification Panel:** Swipe down from the top of the screen to view notifications and quick settings.

- **App Drawer:** Swipe up from the bottom of the screen to access all installed applications.

Mini Smart phone

- 4.0-inch full screen display
- 2000mAh high battery capacity
- 10.0 Android System
- HD camera
- Flagship multi-core

Image: The Truely M16 Pro Mini Smartphone showcasing its 4.0-inch display with a grid of application icons, highlighting its compact design and Android interface.

2. Dual SIM Functionality

The device supports two Nano SIM cards, allowing you to manage two different phone numbers or network providers simultaneously.

- Navigate to **Settings > Network & Internet > SIM cards**.
- Here you can configure preferences for each SIM card, such as default SIM for calls, messages, and mobile data.

3. Camera Usage

Capture moments with the integrated cameras.

- Open the **Camera** application from your home screen or app drawer.
- Tap the shutter button to take a photo.

- Switch between the 5MP rear camera and 2MP front camera using the camera switch icon.
- The rear flash can be activated for improved low-light photography.

4. Security Features

Protect your device and data using various unlock methods.

- Navigate to **Settings > Security**.
- Choose from **Pattern, PIN, Password, or Face Unlock** to secure your device.
- Follow the on-screen instructions to set up your preferred security method.



Image: A graphic illustrating the facial recognition and password unlocking features available on the Truely M16 Pro Mini Smartphone for enhanced security.

5. Connectivity

The M16 Pro supports 3G cellular networks and Bluetooth connectivity.

- **Mobile Data (3G):** Ensure your SIM card is active and mobile data is enabled in **Settings > Network & Internet > Mobile**

network.

- **Bluetooth:** To connect to Bluetooth devices, go to **Settings > Connected devices > Bluetooth**. Turn Bluetooth on and pair with your desired device.

MAINTENANCE

1. Battery Care

To maximize battery life and performance:

- Avoid extreme temperatures.
- Use only compatible chargers and cables.
- Do not allow the battery to fully discharge frequently.
- For optimal charging, use the Type-C port.



Image: An infographic detailing the 2000mAh battery capacity, Type-C fast charging, and estimated battery life (24-48 hrs standby, 8 hrs continuous call, 3-4 hrs video play) for the Truely M16 Pro Mini Smartphone.

2. Cleaning

Gently wipe the screen and body of the phone with a soft, lint-free cloth. Avoid using harsh chemicals or abrasive materials.

3. Software Updates

Periodically check for software updates to ensure your device has the latest features and security patches. Go to **Settings > System > System update**.

TROUBLESHOOTING

Problem	Solution
Device does not power on.	Ensure the battery is charged. Connect the charger and wait a few minutes before attempting to power on again.
Cannot connect to 3G network.	Check if your SIM card is properly inserted and active. Verify mobile data is enabled in settings. Contact your network provider if issues persist.
Screen is unresponsive.	Restart the device by holding the power button. If unresponsive, perform a forced restart (refer to device support for specific instructions if standard power off fails).
Apps are crashing or slow.	Close background applications. Clear app caches (Settings > Apps > [App Name] > Storage > Clear cache). Consider a factory reset as a last resort (backup data first).

SPECIFICATIONS

Feature	Detail
Model Name	M16 Pro
Brand	Truely
Operating System	Android 10.0
Display Size	4.0 Inches
RAM	2 GB
Internal Storage	16 GB
Expandable Storage	Yes, Micro SD (up to unspecified capacity)
Cellular Technology	3G (WCDMA B1/B2/B4/B5/B8, GSM 850/900/1800/1900)
SIM Card Support	Dual Nano SIM
Rear Camera	5 MP
Front Camera	2 MP
Battery Capacity	2000 mAh
Charging Port	USB Type-C
Connectivity	Bluetooth
Dimensions	3.94 x 1.93 x 0.39 inches (approx.)

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation provided with your purchase or contact Truely customer service. Keep your proof of purchase for warranty claims.

For further assistance, visit the official Truely website or contact their support channels.

© 2025 Truely. All rights reserved.

Related Documents - M16 Pro

	<p><u>Vbestlife IP12 PRO+ Unlocked Android Smartphone User Manual</u></p> <p>This user manual provides comprehensive instructions for the Vbestlife IP12 PRO+ Unlocked Android Smartphone, covering setup, features, connectivity, troubleshooting, and safety guidelines.</p>
	<p><u>Infinix NOTE 40 Pro User Manual</u></p> <p>User manual for the Infinix NOTE 40 Pro smartphone, model X6850. This guide provides essential information on operation, safety, and maintenance.</p>
	<p><u>Maxwest Astro 4 PRO User Manual - Setup and Features Guide</u></p> <p>Comprehensive user manual for the Maxwest Astro 4 PRO smartphone, covering setup, SIM card installation, battery charging, sound profiles, phone features, camera, email, file transfer, and FCC compliance information.</p>
	<p><u>TECNO CAMON 40 Pro User Manual</u></p> <p>This user manual provides comprehensive guidelines for the TECNO CAMON 40 Pro smartphone, covering safety precautions, device features, SIM card installation, charging, package contents, technical specifications, and SAR certification.</p>
	<p><u>POCO M4 Pro 5G Quick Start Guide Setup, Features, and Safety Information</u></p> <p>Get started with your POCO M4 Pro 5G smartphone. This quick start guide covers essential setup, MIUI features, dual SIM capabilities, and critical safety information from Xiaomi.</p>

