

Generic RC-200

Super Box RC-200 Smart Voice Remote Control User Manual

Model: RC-200

1. PRODUCT OVERVIEW

The RC-200 is an original and authorized smart voice remote control designed as a perfect replacement for various Super Box models. It offers stable Bluetooth 5.2 connectivity and voice control capabilities for compatible devices, ensuring a seamless user experience.



Image 1: The Super Box RC-200 Smart Voice Remote Control, showcasing its ergonomic design and button layout.

2. SETUP GUIDE

2.1 Battery Installation

The RC-200 remote control requires two (2) 1.5V AAA batteries for operation. Batteries are not included with the remote and must be purchased separately.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the indicators inside the compartment.
4. Replace the battery cover by sliding it back into position until it clicks securely.



Image 2: View of the RC-200 remote control with the battery compartment open, showing the slots for two 1.5V AAA batteries.

2.2 Pairing and Connection

The RC-200 remote utilizes Bluetooth 5.2 for stable connection and voice control. For initial setup or re-pairing, follow the on-screen instructions provided by your Super Box device to establish a Bluetooth connection. The remote also supports IR control for basic functions.

Original remote control RC-200



Bluetooth connection,
Voice control



IR control



Powered by 2 PCs AAA batteries



Image 3: An illustration highlighting the RC-200's features: Bluetooth connection, voice control, IR control, and power source (2 AAA batteries).

3. OPERATING INSTRUCTIONS

3.1 Button Functions

Familiarize yourself with the functions of each button on the RC-200 remote control:

Remote Control



Button Definition

	Power on/off		Mute
	Blue TV		Blue VOD
	YouTube		Netflix
	Play/Pause		Stop
	Rewind		Forward
	HOME		Return
	Cursor/ IR		Information
<p>Navigation: Press to navigate Left/Right/ Up/ Down Press OK to confirm your choose</p>			
	Volume Up		Next One
	Volume Down		Last One
	Voice Control (Press the button and follow the on-screen instructions for Bluetooth pairing.)		
	Settings		Menu
	Figure Button		Delete

Image 4: A visual guide to the RC-200 remote control, detailing the function of each button, including power, navigation, volume, and dedicated app buttons.

Button Icon	Function
Power	Power on/off
Input	Input selection
Vol+ / Vol-	Volume Up / Volume Down
TV Control	Dedicated TV control buttons (Input, Vol+, Vol-)
Mute	Mute/Unmute audio
Play/Pause	Play/Pause media playback

Button Icon	Function
Stop	Stop media playback
Rewind	Rewind media
Forward	Fast forward media
Home	Return to home screen
Return	Go back to previous screen
Navigation (Up/Down/Left/Right/OK)	Navigate menus and confirm selections
Information	Display information
Next One	Skip to next item/track
Last One	Go to previous item/track
Voice Control	Activate voice assistant (follow on-screen instructions for Bluetooth pairing)
Settings	Access settings menu
Menu	Open menu options
Number Buttons (0-9)	Direct input for channels or numbers
Delete	Delete character/item

3.2 Voice Control

The RC-200 remote supports voice control for enhanced navigation and command input. To use voice control, press the dedicated voice control button (microphone icon) and follow the on-screen prompts on your Super Box device. Ensure your remote is properly paired via Bluetooth for this feature to function.

Note: Voice control is **not** supported on Super Box S1, S2, S3 PRO, and S4 PRO models.



The S4 PRO, S3, S2 and S1 don't support voice control

Image 5: Demonstrates the voice control capability of the RC-200 remote and lists compatible Super Box devices (S5 Max, S5 Pro, S6 Max, S6 Ultra, S6 Pro). It also explicitly states that S4 Pro, S3, S2, and S1 models do not support voice control.

3.3 Compatibility

The RC-200 remote control is a perfect replacement and is compatible with the following Super Box series models:

- Super Box S6 Max
- Super Box S6 Ultra
- Super Box S6 Pro
- Super Box S5 Max
- Super Box S5 Pro
- Super Box S4 Pro (Voice control not supported)
- Super Box S3 (Voice control not supported)
- Super Box S2 (Voice control not supported)
- Super Box S1 (Voice control not supported)

4. MAINTENANCE

To ensure the longevity and optimal performance of your RC-200 remote control, follow these maintenance guidelines:

- **Cleaning:** Wipe the remote with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** If the remote will not be used for an extended period, remove the batteries to prevent leakage, which can damage the device.
- **Avoid Drops:** Protect the remote from physical shocks and drops, as this can damage internal components.

5. TROUBLESHOOTING

If you encounter issues with your RC-200 remote control, refer to the following common problems and solutions:

- **Remote Not Responding:**
 - Check if the batteries are inserted correctly with the correct polarity.
 - Replace old or depleted batteries with new 1.5V AAA batteries.
 - Ensure there are no obstructions between the remote and the Super Box device.
- **Voice Control Not Working:**
 - Verify that your Super Box model supports voice control (S1, S2, S3 PRO, S4 PRO do not).
 - Ensure the remote is properly paired with your Super Box device via Bluetooth. Re-pair if necessary.
 - Check your Super Box device's settings to ensure voice control is enabled.
- **Intermittent Connection:**
 - Move closer to your Super Box device to ensure a strong Bluetooth signal.
 - Minimize interference from other electronic devices.
 - Try re-pairing the remote with your device.

6. PRODUCT SPECIFICATIONS

Feature	Detail
Model Number	RC-200
Product Dimensions	6.9 x 1.85 x 0.75 inches
Item Weight	0.634 ounces
Batteries Required	2 x 1.5V AAA batteries (not included)
Connectivity	Bluetooth 5.2, IR
Special Feature	Voice Search
Color	Black
Max Number of Supported Devices	1

Feature	Detail
Manufacturer	innovanexus
Country of Origin	China

7. WARRANTY AND SUPPORT

The RC-200 remote control is an original and authorized product from innovanexus. The authorization code is SP20240214001, valid from 2025-02-14 to 2026-02-14. This authorization ensures the product's authenticity and quality.



Image 6: Certificate of Authorization issued by Super Media Technology Co., LTD, confirming InnovaNexus as an authorized dealer for SUPERBOX series products on Amazon.com.

For any product inquiries, technical support, or warranty claims, please contact the seller or manufacturer directly. Refer to your purchase documentation for specific contact information.