

[Manuals.plus](#) /

› [RYGHT](#) /

› RYGHT L-Buds Wired Headphones User Manual

RYGHT R484772

RYGHT L-Buds Wired Headphones User Manual

Model: R484772

INTRODUCTION

Thank you for choosing RYGHT L-Buds Wired Headphones. These headphones are designed to provide clear and balanced stereo sound with the convenience of a built-in microphone and intuitive controls. Featuring a durable flat cable and a reliable Lightning connection, they are perfect for everyday use with your Apple devices.



Image: RYGHT L-Buds Wired Headphones, showcasing the Lightning connector, flat cable, in-line remote, and earbud design.

PACKAGE CONTENTS

Your RYGHT L-Buds Wired Headphones package should contain the following:

- L-BUDS Wired Lightning Headphones

SETUP

Connecting your RYGHT L-Buds Wired Headphones is straightforward. Follow these steps to begin using your headphones:

1. **Identify the Lightning Connector:** Locate the Lightning connector at the end of the headphone cable. This connector is specifically designed for Apple devices.
2. **Connect to Your Device:** Insert the Lightning connector firmly into the Lightning port of your compatible Apple device (iPhone, iPad, iPod).
3. **Confirmation:** Your device should automatically recognize the headphones. No additional drivers or software installation is typically required.



Image: Close-up of the Lightning connector and earbuds, highlighting "Made for iPhone | iPad | iPod" compatibility.

OPERATING INSTRUCTIONS

Your RYGHT L-Buds headphones feature an in-line remote with three buttons for easy control of audio playback and calls.

Télécommande 3 boutons




Image: Detailed view of the 3-button in-line remote control, illustrating its functions for volume adjustment, media playback, and call management.

Music and Media Control:

- **Volume Up (+):** Press the top button to increase the volume.
- **Volume Down (-):** Press the bottom button to decrease the volume.
- **Play/Pause:** Press the middle button once to play or pause audio.
- **Next Track:** Press the middle button twice quickly to skip to the next track.
- **Previous Track:** Press the middle button three times quickly to go back to the previous track.

Call Management:

- **Answer/End Call:** Press the middle button once to answer an incoming call or end an active call.

- **Reject Call:** Press and hold the middle button for approximately two seconds to reject an incoming call.
- **Activate Siri/Voice Control:** Press and hold the middle button for approximately two seconds when not on a call to activate Siri or your device's voice control.

The built-in microphone allows for clear communication during calls without needing to remove your smartphone.

MAINTENANCE AND CARE

Proper care will extend the lifespan of your RYGHT L-Buds headphones and ensure optimal performance.

- **Cleaning:** Gently wipe the earbuds and cable with a soft, dry, lint-free cloth. Do not use harsh chemicals, cleaning solvents, or strong detergents.
- **Storage:** When not in use, store your headphones in a clean, dry place. The flat cable design helps prevent tangles, but avoid tightly coiling the cable to prevent damage.
- **Avoid Moisture:** Do not expose the headphones to water, rain, or excessive moisture. They are not waterproof.
- **Temperature:** Avoid exposing the headphones to extreme temperatures (hot or cold).

Câble plat 1,2m



Image: The 1.2-meter flat cable design of the RYGH T L-Buds headphones, illustrating its tangle-resistant feature.

TROUBLESHOOTING

If you encounter issues with your RYGH T L-Buds headphones, please refer to the following common problems and solutions:

Problem	Possible Solution
---------	-------------------

Problem	Possible Solution
No sound from headphones.	Ensure the Lightning connector is fully inserted into your device. Check your device's volume settings. Try connecting the headphones to another compatible Apple device to rule out a device issue. Clean the Lightning port on your device for any debris.
Microphone not working.	Ensure the headphones are fully connected. Check your device's microphone privacy settings for the app you are using. Test the microphone with another app or during a different call.
Remote control buttons are unresponsive.	Ensure the headphones are properly connected. Restart your Apple device. Ensure there is no physical damage to the remote.

If the problem persists after trying these solutions, please contact customer support.

SPECIFICATIONS

Feature	Detail
Model Name	L-BUDS
Model Number	R484772
Brand	RYGHT
Connectivity Technology	Wired (Lightning)
Form Factor	In Ear
Color	White
Cable Length	1.2 meters (approx. 3.9 feet)
Built-in Microphone	Yes
In-line Remote	Yes (3-button)
Compatible Devices	Apple devices with Lightning port (iPhone, iPad, iPod)
Item Weight	34 Grams (1.2 ounces)
Manufacturer	MOBILITY

WARRANTY AND SUPPORT

Warranty Information:

RYGHT products are manufactured with high-quality standards. For specific warranty terms and conditions, please refer to the warranty card included with your product or visit the official RYGHT website. Typically, a limited warranty covers manufacturing defects from the date of purchase.

Customer Support:

If you require further assistance, have questions, or experience issues not covered in this manual, please contact RYGHT customer support. Contact details can usually be found on the product packaging, the official RYGHT website, or through your retailer.

Please have your product model number (R484772) and proof of purchase ready when contacting support.

© 2025 RYGHT. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question