



Manuals.plus /

- › Desk /
- › Desk Flexi Monitor Arm Instruction Manual

## Desk Flexi Monitor Arm

# Desk Flexi Monitor Arm Instruction Manual

Model: Flexi Monitor Arm

## 1. INTRODUCTION

Thank you for choosing the Desk Flexi Monitor Arm. This manual provides detailed instructions for the safe and efficient installation, operation, and maintenance of your new monitor arm. Please read this manual thoroughly before installation and retain it for future reference.

## 2. SAFETY INFORMATION

Please observe the following safety precautions to prevent injury or damage to the product:

- Ensure all components are present and undamaged before assembly. Do not use if any parts are missing or defective.
- Do not exceed the maximum weight capacity of 24.2 lbs (11 kg).
- Ensure your desk surface is strong enough to support the combined weight of the monitor arm and your monitor.
- Tighten all screws firmly, but do not overtighten. Overtightening can damage threads.
- Keep children away from small parts that could be swallowed.
- Adjust the tension of the arm carefully according to your monitor's weight to prevent sudden movement.

## 3. PACKAGE CONTENTS

Verify that all the following components are included in your package:

- Monitor Arm Assembly
- Desk Clamp Mount
- Grommet Mount
- VESA Plate

- Hardware Kit (screws, washers, Allen keys)
- Instruction Manual

*Note: Specific screw sizes and quantities may vary. Refer to the hardware kit for exact contents.*

## 4. SPECIFICATIONS

Feature	Specification
Brand	Desky
Model	Flexi Monitor Arm
Mounting Type	Clamp or Through Desk (Grommet)
Movement Type	Articulating
Material	Steel, Plastic, Aluminium
Color	Black
Compatible Monitor Size	17" to 35"
Weight Capacity	6.6 to 24.2 lbs (3 to 11 kg)
VESA Compatibility	75x75mm, 100x100mm
Tilt Angle	+60° to -60°
Rotation	360° (with 180° rotation stop)
Maximum Height	500mm (from desk surface)
Minimum Height	250mm (from desk surface)

The monitor arm supports a wide range of screen sizes and weights, offering flexibility for various setups.

# Weight Capacity **11KG**



Image: The monitor arm is designed to support monitors up to 11 kg (24.2 lbs).

# Max screen size



Image: The monitor arm is compatible with screens ranging from 17 to 35 inches.

## 5. SETUP INSTRUCTIONS

### 5.1 Choose Your Mounting Option

The Desky Flexi Monitor Arm offers two installation methods: Desk Clamp or Grommet Mount.

#### 5.1.1 Desk Clamp Installation

1. Attach the desk clamp to the bottom of the monitor arm pole.
2. Position the clamp on the edge of your desk.
3. Tighten the clamp screw until the arm is securely fastened to the desk. Ensure it is stable and does not wobble.

#### 5.1.2 Grommet Mount Installation

1. If your desk has a grommet hole, insert the grommet base through the hole.
2. Secure the grommet base from underneath the desk using the provided plate and nut.

3. Attach the monitor arm pole to the grommet base.
4. Tighten all fasteners to ensure stability.

## 5.2 Attaching the Monitor

1. Attach the VESA plate to the back of your monitor using the appropriate screws from the hardware kit. Ensure the VESA mounting holes (75x75mm or 100x100mm) align.
2. Slide the monitor (with the attached VESA plate) onto the VESA head of the monitor arm until it clicks into place.
3. Secure the monitor by tightening any safety screws on the VESA head, if applicable.



Image: A Deskly Flexi Monitor Arm securely mounted to a desk with a monitor attached, demonstrating a typical setup.

## 6. OPERATING INSTRUCTIONS

The Deskly Flexi Monitor Arm allows for various adjustments to achieve an ergonomic viewing experience.

### 6.1 Height Adjustment

The arm features a spring-assisted mechanism for effortless vertical movement. Gently push or pull the monitor to the desired height. If the monitor does not stay in position, adjust the tension screw on the arm using the provided Allen key. Turn clockwise to increase tension for heavier monitors, and counter-clockwise to decrease tension for lighter monitors.



Image: The monitor arm can be adjusted vertically from a minimum height of 250mm to a maximum height of 500mm.

## 6.2 Tilt, Swivel, and Rotation

- **Tilt:** The monitor can be tilted  $+60^\circ$  to  $-60^\circ$  to reduce glare and optimize viewing angles.
- **Swivel:** The arm can swivel horizontally to share your screen or adjust your viewing position.
- **Rotation:** The VESA plate allows for  $360^\circ$  rotation, enabling easy switching between landscape and portrait modes. A  $180^\circ$  rotation stop prevents the arm from swinging too far.



Image: The monitor arm allows for a tilt range of +60° to -60° and rotation of +/-90° at the VESA plate.

### 6.3 Cable Management

Utilize the integrated cable management system to keep your workspace tidy. Route cables through the designated channels along the arm to conceal them.



Image: A monitor arm with a cable routed through its built-in cable management system, keeping the desk organized.

## 7. MAINTENANCE

---

Regular maintenance ensures the longevity and optimal performance of your monitor arm.

- **Cleaning:** Wipe the arm with a soft, damp cloth. Avoid abrasive cleaners or solvents.
- **Inspection:** Periodically check all screws and connections to ensure they are tight. Retighten if necessary.
- **Lubrication:** The internal spring mechanism is designed for maintenance-free operation. Do not attempt to lubricate internal components.

## 8. TROUBLESHOOTING

---

If you encounter issues with your Deskly Flexi Monitor Arm, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Monitor sags or does not hold position	Arm tension is too low for monitor weight.	Increase tension by turning the adjustment screw clockwise with the provided Allen key.
Monitor is difficult to move up or down	Arm tension is too high for monitor weight.	Decrease tension by turning the adjustment screw counter-clockwise with the provided Allen key.
Arm feels unstable or wobbles	Mounting clamp/grommet is not tight enough.	Ensure the desk clamp or grommet mount is securely tightened to the desk.
Monitor does not attach to VESA head	Incorrect VESA plate attachment or incompatible VESA pattern.	Verify VESA plate is correctly attached to monitor and that monitor supports 75x75mm or 100x100mm VESA patterns.

## 9. WARRANTY INFORMATION

The Desky Flexi Monitor Arm comes with a **5 Years Supplier Warranty**. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims. For specific terms and conditions, please refer to the warranty documentation included with your product or contact Desky customer support.

## 10. CUSTOMER SUPPORT

For further assistance, technical support, or warranty inquiries, please contact Desky customer service. Visit the official Desky website for contact details and additional resources.

**Website:** Desky Store on Amazon

*Please have your product model (Flexi Monitor Arm) and purchase information ready when contacting support.*