

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Tamagotchi](#) /
- › [Tamagotchi Paradise Blue Water Electronic Pet Instruction Manual](#)

## Tamagotchi 43422

# Tamagotchi Paradise Blue Water Electronic Pet Instruction Manual

**Brand:** Tamagotchi | **Model:** 43422

## INTRODUCTION

The Tamagotchi Paradise Blue Water electronic pet offers an enhanced virtual pet experience. Nurture your Tamagotchi character from cell to space by turning the zoom dial. Engage in traditional nurturing activities like feeding, cleaning, and playing, alongside new features in Lab Mode, including mini-games and shopping. Connect with friends' devices to interact and unlock new fields for expanded gameplay.



*Image: The Tamagotchi Paradise Blue Water device, showcasing its vibrant blue shell and digital screen.*

## SETUP

1. **Unboxing:** Carefully remove the Tamagotchi Paradise device from its packaging.
2. **Battery Installation:** The device requires 2 AAA batteries (not included). Locate the battery compartment on the back of the device, open it, insert the batteries according to the polarity markings, and close the compartment securely.
3. **Initial Power-On:** Once batteries are installed, the device will power on. You will be prompted to select a language (English, French, Spanish, German, Portuguese, Italian, Chinese, Korean, Japanese). Use the control buttons to navigate and select your preferred language.
4. **Date and Time Setting:** Set the current date and time using the device's controls.
5. **Planet Naming:** You will be prompted to name your Tamagotchi Planet.
6. **First Tamagotchi Birth:** An egg will hatch, and your first Tamagotchi character will be born.




Image: The Tamagotchi Paradise Blue Water packaging, illustrating the device and its key features.

**OPERATING INSTRUCTIONS**

The Tamagotchi Paradise features a unique "zoom" dial and multiple levels of interaction to care for your virtual pet.

### Nurturing Your Tamagotchi

- **Feeding:** Select the "Food" option to feed your Tamagotchi. Choose from various foods and snacks to keep it happy and full.
- **Cleaning:** Regularly check for and clean up your Tamagotchi's waste to maintain its health and happiness.
- **Playing:** Engage your Tamagotchi in mini-games and activities to boost its happiness and earn currency.
- **Health Check:** Access the "Tama Cell" level by turning the zoom dial to view your Tamagotchi's hunger, happiness, and age.

### Zoom Dial Functionality

The zoom dial allows you to navigate through different levels of gameplay:

- **Tama Space Level:** The broadest view of your Tamagotchi Planet. Here you can decorate your planet, visit Tama Stars (memories of past Tamagotchis), meet goals for rewards, and travel to other planets once enough currency is earned.
- **Field Level:** This level allows you to clean up waste, go on egg hunts, play with toys, and switch between unlocked fields (Water, Land, Sky).
- **Tama Cell Level:** The closest view, showing your Tamagotchi's internal status (hunger, happiness) and its visual character type.



*Image: A user's hands operating the Tamagotchi Paradise device, demonstrating the zoom dial and button interactions.*

## Lab Mode

Hold down the zoom dial to enter Lab Mode, which offers advanced features:

- **Missions:** Complete various missions to earn rewards and progress in the game.
- **Mini-Games:** Play mini-games to earn Planet Money, which can be used to buy food, decorations, or hire a Tama Sitter.
- **Breeding:** Breed new Tamagotchi characters, passing traits to new generations and creating over 50,000 possible variations across 12 species.

## Connecting with Friends

Physically connect your Tamagotchi Paradise device with a friend's device to enable playdates, send gifts, and observe character interactions.



Image: Two Tamagotchi Paradise devices, one pink and one blue, connected side-by-side, illustrating the connection feature.

## Official Product Video

Your browser does not support the video tag.

Video: An official overview of the Tamagotchi Paradise, demonstrating its core features, nurturing gameplay, and character evolution.

## MAINTENANCE

- **Screen Protection:** The device's screen can be prone to scratches. It is highly recommended to apply a screen protector to maintain screen clarity and longevity.
- **Battery Management:** The device uses 2 AAA batteries. Battery life can vary with usage. For continuous play, consider using rechargeable AAA batteries.
- **Cleaning:** Use a soft, dry cloth to gently clean the device's exterior. Avoid using harsh chemicals or abrasive materials.

## TROUBLESHOOTING

- **Device Not Turning On:** Ensure batteries are correctly installed and are not depleted. Replace with fresh batteries if necessary.
- **Unresponsive Buttons:** Check for any debris around the buttons. If the issue persists, try removing and reinserting the batteries.
- **Screen Issues:** If the screen is dim or flickering, check battery levels. If the screen is unresponsive, a device reset (by removing and reinserting batteries) might resolve the issue, though this may reset game progress.
- **Character Unhappiness:** Regularly check your Tamagotchi's hunger and happiness levels in the Tama Cell view. Feed, clean, and play with it as needed.

## SPECIFICATIONS

Feature	Detail
Model Number	43422
Product Dimensions	1.5"L x 3"W x 3"H
Item Weight	6 ounces (0.17 Kilograms)
Screen Size	3.81 Centimeters
Power Source	Battery Powered (2 AAA batteries required, not included)
Material	ABS, Metal, PVC
Age Range	6 years and up
Number of Players	1
Manufacturer	Bandai Namco Toys & Collectibles America

## WARRANTY AND SUPPORT

For warranty information, technical support, or service inquiries, please refer to the contact details provided in the product packaging or visit the official Tamagotchi website. Keep your purchase receipt as proof of purchase.

**Online Resources:** For additional tips, tricks, and community support, visit the official [Tamagotchi Store](#) or search for online fan communities.