

[Manuals.plus](#) /

> [TISHLED](#) /

> TISHLED Wireless Keyboard AN-800 User Manual

TISHLED AN-800

TISHLED Wireless Keyboard AN-800 User Manual

Model: AN-800 | Brand: TISHLED

1. PACKAGE CONTENTS

Please check the package carefully to ensure all items are present:

- 1 x Dual-Mode Wireless Keyboard (AN-800)
- 1 x USB A-C Cable
- 1 x User Manual



Image: The TISHLED AN-800 Wireless Keyboard, showcasing its compact 99-key layout with a volume knob and a black, grey, and yellow color scheme.

2. PRODUCT OVERVIEW AND FEATURES

The TISHLED AN-800 Wireless Keyboard offers versatile connectivity and ergonomic design for enhanced productivity.

- **Dual Mode Connection:** Supports Wireless 2.4GHz and Bluetooth 5.0, allowing connection to up to three Bluetooth devices and one 2.4G device.
- **Comfortable Scissor Switches:** Features fast-responding, silent scissor-switch keys for comfortable tactile feedback, similar to MacBook keyboards.
- **Ergonomic 2-Stage Feet Design:** Provides three different typing angles for personalized comfort and reduced wrist discomfort during long-term use.
- **Compact 99-Key Layout & Volume Roller:** Space-saving design retaining arrow keys and numeric keypad, equipped with a convenient volume roller and clear indicator lights.
- **Rechargeable & Energy Saving:** Built-in 300mAh lithium battery with low-power chip and energy-saving technology, offering 20-45 days of use depending on usage. Includes a power switch to conserve battery.



Dual-mode connect



Scissor-switch



Type-C rechargeable



99 keys layout



Volume roller

Image: Visual representation of the keyboard's key features including dual-mode connectivity, scissor-switch mechanism, 99-key layout, Type-C charging port, and volume roller.



Comfortable Scissor-switch

Comfortable Scissor-Switch

Laptop style scissor-switch, low-noise typing, comfortable feel



Image: A close-up view illustrating the comfortable scissor-switch key mechanism of the keyboard.



Two Stage Foot Brace

3 angles with the desktop to meet different typing postures



Image: The keyboard's two-stage adjustable feet, demonstrating the different typing angles they provide for ergonomic comfort.

3. SETUP AND CONNECTION

3.1 Powering On/Off

Locate the power switch on the side of the keyboard. Slide it to the "ON" position to power on the keyboard and to "OFF" to power it off.

3.2 Bluetooth Connection (BT1/BT2/BT3)

1. Ensure the keyboard is powered on.
2. Long press **FN + 1**, **FN + 2**, or **FN + 3** to enter Bluetooth pairing mode for the desired channel. The corresponding indicator light will flash rapidly.
3. On your PC, laptop, smartphone, or tablet, open the Bluetooth settings.
4. Search for and select "AN-800 BT1", "AN-800 BT2", or "AN-800 BT3" from the list of available devices.
5. Once paired, the indicator light will stop flashing and remain solid, indicating a successful connection.

You can pair up to 3 Bluetooth devices. Short press **FN + 1/2/3** to switch between paired Bluetooth devices.



Dual-Mode Connect

BT1/2/3+2.4G , up to 4 devices can be connected



Mode switch



Pilot light

- BT1
- BT2
- BT3
- Battery light

- Short press FN+1/2/3/4 change connect channel
- Long press FN+1/2/3/4 pairing

- Fast flash = into pairing stage
- Extinguish = pairing completed

computer screen.

3.3 2.4G Wireless Connection

1. Locate the 2.4G USB receiver, typically stored under the left foot brace of the keyboard.
2. Plug the USB receiver into an available USB port on your computer.
3. Long press **FN + 4** to enter 2.4G pairing mode.
4. Wait a few seconds for your computer to automatically recognize the keyboard. No additional drivers are required.



Image: A diagram showing how to connect the keyboard using the 2.4G USB receiver, including its storage location and the FN key combination for pairing.

4. OPERATING INSTRUCTIONS

4.1 FN Shortcut Keys (Windows System Example)

The keyboard features FN shortcut keys for quick access to multimedia and system functions. Press and hold the **FN** key, then press the corresponding function key:

Key Combination	Function
FN + F1	Brightness -
FN + F2	Brightness +
FN + F3	Media Player
FN + F4	Volume -
FN + F5	Volume +
FN + F6	Mute
FN + F7	Stop
FN + F8	Previous Track
FN + F9	Play/Pause
FN + F10	Next Track
FN + F11	Web Browser

Key Combination	Function
FN + F12	Calculator



FN Shortcut Keys For Fast

FN shortcut key combination, can achieve multimedia shortcut operation
(Windows system for exemple)

FN + F1 Brightness -	FN + F5 Volume +	FN + F9 Play/pause
FN + F2 Brightness +	FN + F6 Mute	FN + F10 Next
FN + F3 Media player	FN + F7 Stop	FN + F11 Web
FN + F4 Volume -	FN + F8 Previous	FN + F12 Calculator



Volume roller

- Turn left = volume -
- Turn right = volume +

- Short press = mute

Image: A visual guide to the FN shortcut keys and their corresponding functions on the keyboard.

4.2 Volume Roller

The dedicated volume roller provides convenient audio control:

- Turn the roller left to decrease volume.
- Turn the roller right to increase volume.
- Short press the roller to mute/unmute audio.

5. CHARGING AND BATTERY

The keyboard is equipped with a built-in 300mAh lithium battery and is rechargeable via a USB-C cable.

- Connect the provided USB A-C cable to the keyboard's USB-C port.
- Connect the other end of the cable to a computer's USB port, a power bank, or a regular charging head (5V/1A recommended).
- The indicator light will show charging status.
- When the battery is low, the indicator light will flash slowly to remind you to charge.

For safety reasons, please do not use fast charging adapters.



Built-in High Capacity Battery

Built-in large capacity lithium battery, Type-C rechargeable



Use the Type-C charging cable connected to a computer's USB port, power bank, or regular charging head for charging

For safety reasons, please do not use fast charging

Image: A close-up of the keyboard's USB-C charging port, with illustrations showing connection to a laptop, power bank, and

6. SPECIFICATIONS

Feature	Detail
Model Number	AN-800
Connectivity Technology	Bluetooth 5.0, Wireless 2.4G
Number of Keys	99
Battery Capacity	300mAh Lithium Battery (included)
Product Dimensions	15.8"L x 5.6"W x 1.2"H (40.1cm x 14.2cm x 3.0cm)
Item Weight	1.5 pounds (0.68 kg)
Compatible Devices	Laptop, PC, Smart TV, Smartphone, Tablet (Windows, Mac OS, iOS, Android)
Special Features	Dual Mode Connection, Ergonomic, Rechargeable, Scissor Switches, Volume Roller

7. TROUBLESHOOTING

If you encounter issues with your TISHLED AN-800 keyboard, please refer to the following common solutions:

- **Keyboard not connecting:**

- Ensure the keyboard is powered on and fully charged.
- Verify the correct connection mode (Bluetooth or 2.4G) is selected on the keyboard.
- For Bluetooth, ensure your device's Bluetooth is enabled and try re-pairing.
- For 2.4G, ensure the USB receiver is securely plugged into a working USB port. Try a different USB port.
- Restart your computer/device and the keyboard.

- **Keys not responding:**

- Check battery level and charge the keyboard if low.
- Ensure the keyboard is properly connected to your device.
- Try connecting the keyboard to a different device to rule out device-specific issues.

- **Lag or intermittent connection:**

- Move the keyboard closer to your device to reduce interference.
- Avoid using the keyboard near strong electromagnetic interference sources (e.g., microwaves, Wi-

Fi routers).

- For 2.4G, ensure the USB receiver is not obstructed.

8. MAINTENANCE

To ensure the longevity and optimal performance of your keyboard, follow these maintenance tips:

- Keep the keyboard clean by regularly wiping it with a soft, dry cloth.
- Avoid spilling liquids on the keyboard. If a spill occurs, immediately power off the keyboard and allow it to dry completely before use.
- Do not expose the keyboard to extreme temperatures or direct sunlight.
- Store the keyboard in a dry, dust-free environment when not in use.

9. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the contact details provided with your purchase or visit the official TISHLED website.

If you have any questions or require further assistance, do not hesitate to contact TISHLED customer service.

Note: Warranty terms and conditions may vary by region and retailer. Please retain your proof of purchase.