



[Manuals.plus](#) /

› [Lenovo](#) /

› [Lenovo Yoga Tab Plus User Manual](#)

Lenovo ZAEG0096US

Lenovo Yoga Tab Plus User Manual

Model: ZAEG0096US

INTRODUCTION

This manual provides comprehensive instructions for setting up, operating, maintaining, and troubleshooting your Lenovo Yoga Tab Plus. Designed for creativity and productivity, this tablet features a 12.7-inch 3K display, a powerful Snapdragon 8 Gen 3 processor, and comes with a Lenovo Tab Pen Pro and an ergonomic keyboard. Please read this manual thoroughly to ensure optimal performance and longevity of your device.

PACKAGE CONTENTS

Before proceeding, verify that all items are present in your package:

- Lenovo Yoga Tab Plus Tablet
- Lenovo Tab Pen Pro
- Keyboard Stand
- Power Adapter and USB-C Cable
- Quick Start Guide (this manual)

SETUP

1. Initial Power On and Charging

To power on your tablet for the first time, press and hold the power button located on the side of the device until the Lenovo logo appears. It is recommended to fully charge the tablet before first use. Connect the provided USB-C cable to the tablet's charging port and the power adapter to a wall outlet.



Figure 1: Lenovo Yoga Tab Plus with its accompanying keyboard and pen, showcasing the complete setup.

2. Attaching the Keyboard Stand

The keyboard stand attaches magnetically to the tablet. Align the magnetic connectors on the keyboard with the corresponding points on the tablet's bottom edge. The stand allows for multiple viewing angles.



Figure 2: Side view of the Lenovo Yoga Tab Plus demonstrating its integrated kickstand for versatile positioning.

3. Pairing the Lenovo Tab Pen Pro

The Lenovo Tab Pen Pro typically pairs automatically when brought near the tablet. If not, ensure Bluetooth is enabled on your tablet and follow the on-screen prompts for pairing. The pen can be magnetically attached to the side of the tablet for storage and charging.

OPERATING INSTRUCTIONS

1. Basic Navigation (Android 14)

Your tablet runs on Android 14. Swipe up from the bottom to access the app drawer, swipe down from the top for quick settings and notifications. Use gestures or the navigation bar for Home, Back, and Recent Apps functions.

2. Using the Lenovo Tab Pen Pro

The Tab Pen Pro offers precise input for drawing, writing, and navigating. It supports pressure sensitivity for artistic applications. Specific pen functions and customizable buttons can be configured in the tablet's settings under "Stylus" or "Pen settings."

3. Utilizing the Keyboard Stand

The keyboard stand transforms your tablet into a productivity workstation. It features a full QWERTY layout and a trackpad for mouse input. Ensure the tablet is securely seated in the magnetic slot for proper connection.

4. Display and Audio Features

The 12.7-inch 3K PureSight Pro display offers vibrant visuals with a 144Hz refresh rate for smooth scrolling and gaming. The anti-reflection coating minimizes glare. Experience immersive sound with the integrated Harman Kardon audio system, providing rich and clear sound for media consumption.



Figure 3: Front view of the Lenovo Yoga Tab Plus tablet, highlighting its large 3K display.

5. Camera Usage

The tablet is equipped with a 13MP wide-angle front camera with a privacy lens and a 13MP AF + 2MP (Macro) FF back camera. Open the Camera app to capture photos and videos. Explore various modes and settings for optimal results.

MAINTENANCE

1. Cleaning the Device

Use a soft, lint-free cloth to clean the screen and body of the tablet. For stubborn smudges, slightly dampen the cloth with water or a screen-safe cleaning solution. Avoid harsh chemicals or abrasive materials.

2. Battery Care

To prolong battery life, avoid exposing the tablet to extreme temperatures. It is not necessary to fully discharge the battery before recharging. For long-term storage, charge the battery to about 50% and store the device in a cool, dry place.

3. Software Updates

Regularly check for and install software updates to ensure your tablet has the latest features, security patches, and performance improvements. Navigate to **Settings > System > System update** to check for updates.

4. Storage Management

Your tablet comes with 256GB of UFS 4.0 storage. To manage storage, go to **Settings > Storage**. You can clear cached data, uninstall unused apps, and move files to cloud storage to free up space.

TROUBLESHOOTING

This section addresses common issues you might encounter with your Lenovo Yoga Tab Plus.

- **Device not powering on:** Ensure the battery is charged. Connect the charger and wait a few minutes before attempting to power on again. If unresponsive, press and hold the power button for 10-15 seconds to force a restart.
- **Screen is unresponsive:** Try restarting the tablet. If the issue persists, perform a factory reset (data will be lost, back up important files).
- **Wi-Fi or Bluetooth connectivity issues:** Toggle Wi-Fi/Bluetooth off and on. Restart your router or the tablet. Ensure you are within range of the network/device.
- **Apps crashing or freezing:** Close and reopen the app. Clear the app's cache (**Settings > Apps > [App Name] > Storage & cache > Clear cache**). Update the app or the tablet's operating system.
- **Lenovo Tab Pen Pro not working:** Ensure the pen is charged and properly paired via Bluetooth. Check pen settings in the tablet's system settings.

SPECIFICATIONS

Feature	Detail
Processor	Qualcomm Snapdragon 8 Gen 3 Processor (3.30 GHz)
Memory	16 GB LPDDR5X (Soldered)
Display	12.7" 3K (2944 x 1840), LTPS, 650 nits (Type), 900 nits (Peak), 144Hz
Storage	256 GB UFS 4.0
Operating System	Android 14
Cameras	13MP Wide-Angle FF Front + Privacy Lens + 13MP AF + 2MP (Macro) FF Back
Pen	Lenovo Tab Pen Pro
Item Weight	4 pounds
Product Dimensions	11.45 x 0.33 x 7.41 inches

WARRANTY AND SUPPORT

Your Lenovo Yoga Tab Plus is covered by a limited warranty. For detailed warranty terms and conditions, please refer to the warranty card included in your product packaging or visit the official Lenovo support website. For technical assistance, driver downloads, and further support, please visit support.lenovo.com.

For protection plans, consider options such as the 2-Year or 4-Year Protection Plans available for extended coverage.

